

User Manual for Wireless 433 Remote Control

Precautions:

1. Do not place the remote control at high temperatures, as it may be affected by water and fire,
2. Do not remove the remote control battery
3. Prohibit swallowing batteries
4. If not used for a long time, please insert the insulation sheet into the battery door to prevent battery feeding
5. Battery model (CR2023 3V)

product overview:

This remote control is used for Christmas tree products.

The main buttons are: power, timer, brightness adjustment, and function mode

Technical Parameter:

model: xx-21RF

Battery model: CR2025

Working voltage: 3V

Effective distance: 8 meters to 12 meters

Common problem solutions.

Check if the battery of the remote control is properly installed

Check if the battery of the remote control is charged

Check if the insulation sheet inserted into the remote control battery is removed from the product

Product illustration description.



FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.