


Starlink Install Guide

ENGLISH



Find A Clear View of the Sky

Your Starlink needs a clear view of the sky so it can stay connected with satellites as they move overhead. Objects that obstruct the connection between your Starlink and the satellite, such as a tree branch, pole, or roof, will cause service interruptions.




To find a location with a clear view of the sky:

1. Download the Starlink App.
2. Use the "Check for Obstructions" tool to find an install location that will deliver the best service.
3. Ensure your Starlink is installed within 35 degrees of vertical.


If you could not find a clear field of view from the ground level, consider installing in an elevated location, like a roof, pole, or wall. Additional mounts and accessories are available for purchase on the Starlink Shop.

Plug Starlink In

1. Put Starlink into base and plug into power.



2. Starlink will automatically level itself to search for satellites overhead. **Do NOT attempt to manually adjust your Starlink.**
3. After a few minutes, Starlink will make an initial connection to the Starlink constellation and tilt to the optimum angle for satellite coverage (slightly north or south based on your location in the northern or southern hemisphere).




Connect to WiFi

1. On your device, find and connect to the STARLINK network in your WiFi settings. If needed, the Network ID is located on the back of the router.



2. Once connected, a browser window will open prompting you to enter a new SSID (Network name) and password. This step is optional but recommended.
3. You are now connected! Open the Starlink App to customize additional settings, check your connection, and more.



Can't Get Online?

1. Open the Starlink App to check for any alerts, outages, or obstructions.
2. Check the WiFi router light.
If the router cannot connect to the internet in 20 minutes, the light will go from pulsing white to red.
3. Make sure everything is securely plugged in and there is no damage to hardware or cables.
4. Confirm you are at the correct service address listed on your account.
5. Power cycle Starlink by unplugging from power and then plugging back in.
6. If none of these works, contact **Starlink Customer Support** by logging into your account on starlink.com.

For Further Assistance

Find answers to frequently asked questions, installation education, and additional troubleshooting in the Starlink App and the Support section of starlink.com.