



Manual and Warranty • Manuel et Garantie • Handbuch und Garantieschein • Manual y Garantía

## Important Monster® Performance and Safety Tips

### Listen Responsibly

To avoid hearing damage, make sure that the volume on your music player is turned down before connecting your headphones. After placing headphones in / on your ears, gradually turn up the volume until you reach a comfortable listening level.

Noise levels are measured in decibels (dB), exposure to any noise at or above 85 dB can cause gradual hearing loss.

Monitor your use; hearing loss is a function of loudness versus time. The louder it is, the less time you can be exposed to it. The softer it is, the more time you can listen to it.

This decibel (dB) table compares some common sounds and shows how they rank in potential harm to hearing.


SOUND	NOISE LEVEL (dB)	EFFECT
Whisper	30	Very quiet
Quiet Office	50–60	Comfortable hearing levels are under 60 dB
Vacuum Cleaner, Hair Dryer	70	Intrusive; interferes with telephone conversations
Food Blender	85–90	85 dB is the level at which hearing damage (8 hrs.) begins
Garbage Truck, Cement Mixer	100	No more than 15 minutes of unprotected exposure recommended for sounds between 90–100 dB
Power Saw, Drill/Jackhammer	110	Regular exposure to sound over 100 dB of more than 1 minute risks permanent hearing loss
Rock Concerts (varies)	110–140	Threshold of pain begins around 125 dB

Chart information obtained from [www.nidcd.nih.gov/health/education/teachers/pages/common\\_sounds.aspx](http://www.nidcd.nih.gov/health/education/teachers/pages/common_sounds.aspx)

Get the most out of your equipment and enjoy great audio performance even at safe levels. Our headphones will allow you to hear more details at lower volume levels than ever before.

Learn how to establish a safe listening level and review other important safety guidelines from the Consumer Electronics Association at [www.ce.org](http://www.ce.org). Important information on how to prevent Noise-Induced Hearing Loss (NIHL) and a comprehensive list of which noises can cause damage can be found on the Deafness Research Foundation's website, [www.drf.org](http://www.drf.org).

## Physiology of the Ear and Hearing



For additional information on what loud noises do to your ear and chart reference [www.abelard.org/hear/hear.php#loud-music](http://www.abelard.org/hear/hear.php#loud-music)

## Use Responsibly

Do not use headphones when it's unsafe to do so – while operating a vehicle, riding a bike, crossing streets, or during any activity or in an environment where your full attention to your surroundings is required.

It's dangerous to drive while wearing headphones, and in many places, illegal because it decreases your chances of hearing life-saving sounds outside of your vehicle, such as another car's horn and emergency vehicle sirens.

Please avoid wearing your headphones while driving. Use one of Monster's FM transmitters to listen to your mobile media devices instead.

## Headphones “Break-in”

Break in time for headphones? We're kidding, right? No we're not. Like any high performance product, whether it's cars or headphones, they're mechanical devices that settle in after use. Your new headphones will sound incredible out of the box, but will “mellow” out after use and sound even better. We recommend playing them for 8 hours. After 20 hours of playing, they should be fully broken in. Enjoy.

## Battery

If applicable, battery must be recycled or disposed of properly.



### Information to consumers in application of EU WEEE Directive 96/2002

This product is subject to European Union regulations that promote the re-use and recycling of used electrical and electronic equipment. This product required the extraction and use of natural resources and may contain hazardous substances. The symbol above, on the product or on its packaging, indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service, or the store from which you purchased the product. For more information about Monster products, please visit us at: [www.MonsterProducts.com](http://www.MonsterProducts.com).

## Monster® Service Have a Problem with Your Headphones? Our Customer Service Team is here for you.

Please don't return headphones to your retailer, CALL our customer service center, 1-877-800-8989 for United States or Latin America, or email us at [www.MonsterProducts.com/service/](http://www.MonsterProducts.com/service/). For Canadian, European, and Asian Pacific customer service numbers, please see the **"Telephone Numbers"** section in the following **"Limited Warranty for Consumers"**. Our team of experts will assist you with all questions and technical difficulties.


We stand behind our products. Monster headphones deliver the best in sound, quality, and design.

Thank you for your purchase.

**Download the complete manual at:**  
[www.MonsterProducts.com](http://www.MonsterProducts.com)

## Product Overview

1. Microphone
2. Charge jack
3. Indicator light
4. Volume + / Track Forward
5. Multifunction button  
(Power On/Off, Pairing,  
Activate Voice Dialing)
6. Volume - / Track Backward



## Guide to Indicator Lights

INDICATOR LIGHT	DESCRIPTION	VOICE PROMPTS
Power on	Stays blue 1 second	Power on
Power off	Stays red 2 seconds	Power off
Standby (connected)	Blink blue once every 5 seconds	/
Pairing	Flashes Red and Blue alternately	Pairing
Incoming call	Flashes blue continuous	/
Charging	Stays on blue while charging	/

## Basic operation

### Charge the Battery

Your ISport Wireless initially has enough power to complete the pairing and a few calls. When battery is low, you will hear warning tone and indicator light changes to red. The headphone includes a Micro USB cable that can be connected to your computer or other device made for USB charging. Plug the Micro USB end of the included USB cable into the USB micro port on the control talk box. Plug the other end into a USB port on your computer or other devices made for USB charging. The indicator light will be blue while charging. Once fully charged, the indicator light will be off. Charge time is approximately 1.5 hours on an empty battery.

**Note:** The lifetime of the battery will be significantly reduced if your headphone is left uncharged for a long period. We recommend that you recharge your headphone at least once a month.

### Power On/ Power Off

Press the Multifunction button for about 1 second to power on the headphone. To power off the headphone, press the Multifunction button for about 3 seconds.

## Volume Control

Press the Volume "+" or "-" to turn volume up or down, you hear beep once you reach the maximum volume or minimum volume.

## Pairing

### Pair One Phone

1. Press and hold the Multifunction button for about 5 seconds until indicator light flashes blue and red alternately, you hear "Power on" and "Pairing". Now headphone is in pairing mode.
2. Activate *Bluetooth*® on your phone and set it to search for new devices.
3. Select "**ISport Wireless**". If your phone asks, enter 0000 (four zeros) for the passcode or accept the connection. The indicator light stops flashing red and blue once successfully paired, you hear "Paired, phone 1 connected". Some phone list an option to "Play through earphone", select to use the headphone.

**Note:** When you unbox the headphone and power it on for the first time, it will enter to pairing mode automatically.

## Pair Another Phone

Multipoint technology enables you to pair another phone and take a call from either.

To pair with another mobile phone, power off the headphone, then follow the steps for "Pair one phone". After pairing successfully, restart the headphone to connect to 2 paired mobile phone automatically and manually.

**Note:** You may need to connect the second phone manually.

## Call

**Answer a Call:** Press the Multifunction button once.

**Reject a Call:** Press and hold the Multifunction button for about 1 second.

**End a Call:** Press the Multifunction button once.

**Redial the Last Call:** Press Volume "+" and "-" for about 3 seconds in standby mode. The mobile phone will redial the last call number.

**Mute On/Off:** Press the Volume "-" for about 3 seconds to mute on/off.

**Switch Between the Headphone and Phone:** Press the Multifunction button for about 1 second during a call, the call will be switched to the mobile phone, redo this operation again, the call will be switched to the headphone.

**End Current Call and Answer New Call:** When a new call rings during a call, press the Multifunction button once to answer new call and end current call simultaneously.

**On Hold Current Call and Answer New Call:** When a new call rings during a call, double press the Multifunction button to hold current call and answer new call. To switch between held call and active call, double press the Multifunction button.

**Activate Voice Dialing:** Double press the Multifunction button to trigger the voice dialer, this function varies with user's smartphone.

## Music

**Play / Pause Music:** Press Multifunction button once to play / pause music. (Some phones may require you to start a media player first).

**Track Back / Forward:** Press the Volume "-" for 1 second once to skip track backward, press Volume "+" for 1 second once to skip track forward.

**Switch Music and Call:** When a call rings during a music playing, the music automatically pauses to allow you to answer or ignore the call. Once the call is ignored or ends, the music is resumed.

## More Features

### Battery Indicator

When the headphone is connected to a device with iOS system, a battery indicator will appear at the upper right of the system, indicating battery status of the headphone.

### Auto Power-Off

When the distance between the headphone and the mobile phone is beyond effective range, a warning tone will be alerted and headphone will try to reconnect with the mobile phone for 10 minutes. If no phone is reconnected within 10 minutes, the headphone will go to connectable mode and wait for 5 more minutes before automatically power off.

### Automatic Connection After Powering On

When the headphone and phone have been paired once, they will automatically connect when the headphone is on and *Bluetooth* is activated on the phone.

### Connection Standby

After successful pairing and connection, you will hear the voice prompt "Phone 1 connected". The headphone will be in turning on mode or standby mode automatically and the blue LED will flash

once every 5 seconds. When the phone disconnects the headphone, you will hear the disconnect tone.

### Reset Paired Device(s)

Go to the Pairing mode (hold the Multifunction button for 5 seconds from Power off state), then hold the Volume "+" to reset the paired device(s), indicator light flashes blue and red alternatively and rapidly few times, you will also hear the tone.

### Hardware Reset

Plug the Micro USB cable into the USB micro port of headphone to connect it to the computer or other device made for USB charging to have the hardware reset.

## Certification

### FCC ID: RJE190688

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Changes or modification not expressly approved by the party responsible for Compliance could void the user's authority to operate the equipment. Connecting of peripherals requires the use of grounded shielded



signal cables. The socket-outlet shall be installed near the equipment and shall be easily accessible.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**CAUTION:** Changes or modifications not expressly approved by the party responsible for compliance

could void the user's (or your) authority to operate the equipment. Avoid storage in extreme heat or cold. Avoid exposure to liquids, temperature extremes and high humidity. The product's working temperature range is 0–45°C (32–113°F). This device complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment.

## Canada Notice — IC: 5153A-190688

This Class B digital apparatus complies with Canadian ICES-003.

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme aux CNR exemptés de licence d'Industrie Canada. Son fonctionnement est soumis aux deux conditions suivantes :

- ( 1 ) Ce dispositif ne peut causer d'interférences ; et
- ( 2 ) Ce dispositif doit accepter toute interférence , y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.

### Canadian Class B Statement

This digital device does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the interference causing equipment standard entitled "Digital Apparatus," ICES-003 of the Department of Communications.

### CAN ICES-3 (B)/NMB-3(B)

#### Modification

Any changes or modifications not expressly approved by the grantee of this device could void

the user's authority to operate the device.

## Europe—EU Declaration of Conformity

The equipment complies according to the Radio Equipment and Telecommunications Terminal Equipment Directive 1999/5/EC.

This equipment meets the following conformance standards:



<b>Safety</b>	EN 60950-1/A 12:2011
<b>Health</b>	EN 62479:2010
<b>EMC</b>	EN 301489-1 V1.9.2 EN 301489-17 V2.2.1 EN 55022:2010/AC:2011 EN 55024:2010
<b>Radio</b>	EN 300 328 V1.8.1

**CAUTION:** Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

Certification Model Number:  
190688

Import: Monster, LLC  
Address: 7251 West Lake Mead Blvd.,  
Las Vegas, NV 89128

Import: Monster Technology International, Ltd.  
Address: Ballymaley Business Park,  
Gort Rd., Ennis, Co. Clare, Ireland

## LIMITED WARRANTY FOR CONSUMERS

Monster, LLC, 7251 West Lake Mead Blvd., Las Vegas, NV 89128, USA, **[PLEASE NOTE THAT MONSTER DOES NOT ACCEPT PRODUCTS SHIPPED TO THIS ADDRESS – FOLLOW INSTRUCTIONS IN “HOW TO MAKE A CLAIM” BELOW]** (415) 840-2000 (“Monster”) extends You this Limited Warranty. Statutory or common law may provide You with additional rights or remedies, which shall not be affected by this Limited Warranty.

### DEFINITIONS

**“Adequate Use”** means personal use of the Product (i) for private (as opposed to commercial) purposes, (ii) in conformance with all applicable law, code or regulations (including without limitation building and/or electrical codes), (iii) in accordance with manufacturer recommendations and/or instructions in the materials and documentation that accompany the Product, and (iv) if applicable, with proper electrical grounding.

**“Authorized Dealer”** means any distributor,

reseller or retailer that (i) was duly authorized to do business and permitted to sell You the Product under the laws of the jurisdiction where You bought the Product, (ii) purchased the Product directly from Monster or from a party with a contractual relationship with Monster and in accordance with the authorized terms and conditions of such agreement, and (iii) sold You the Product new and in its original packaging.

**“Formal Warranty Claim”** means a claim made in accordance with the section “Formal Warranty Claims” herein.

**“Product”** means a Product (i) that is listed in the Specifications Table below, (ii) that You bought from an Authorized Dealer new and in its original packaging, and (iii) whose serial number, if any, has not been removed, altered, or defaced.

**“Product Defect” or “Defective Product”** means an inadequacy of the Product that existed at the time when You received the Product from an Authorized Dealer and that causes a failure of the Product to perform in accordance with Monster’s documentation accompanying the Product, unless such failure has been caused completely or partly by (a) any use other than Adequate Use, (b) transportation, neglect, misuse or abuse by anyone other than Monster’s employees; (c) alteration, tampering or modification of the product by anyone other than a Monster employee; (d) accident (other than a malfunction that would otherwise qualify as a Product Defect);

(e) maintenance or service of the Product by anyone other than a Monster employee; (f) exposure of the Product to heat, bright light, sun, liquids, sand or other contaminants; or (g) acts outside the control of Monster, including without limitation acts of God, fire, storms, earthquake or flood.

**“Warranty Period”** means the time period during which Monster must have received Your Formal Warranty Claim. The different Warranty Periods related to Product Defects are defined in the Specifications Table below. The Warranty Period commences on the date when You purchased or received (whichever occurs later) the Product from an Authorized Dealer as evidenced by the Authorized Dealer’s invoice, sales receipt or packing slip. If You do not have written proof of the date of purchase or receipt, then the Warranty Period commences three (3) months after the date when the Product left Monster or its factory as evidenced by Monster’s records. The Warranty Period ends after the time defined in the Specifications Table has expired or after You have transferred ownership of the Product, whichever occurs earlier. Also, You must call Monster and obtain a Return Authorization Number (as described under “How to Make a Claim”) within two (2) months after You discover a Product Defect (or should have discovered it, if such Product Defect was obvious).

**“You”** means the first individual person that

purchased the Product in its original packaging from an Authorized Dealer. This Limited Warranty does not apply to persons or entities that bought the Product (i) in used or unpackaged form, (ii) for resale, lease or other commercial use, or (iii) from someone other than an Authorized Dealer.

### SCOPE OF THIS LIMITED WARRANTY

**PRODUCTS.** If a Product contained a Product Defect when You bought it from an Authorized Dealer, and Monster receives a Formal Warranty Claim from You (i) within two (2) months after You discover such Product Defect (or should have discovered it, if such Product Defect was obvious) and (ii) before the end of the Warranty Period for Product Defects applicable to the Defective Product, then Monster will provide You with one of the following remedies: Monster will (1) repair or, at Monster's sole discretion, replace the Defective Product, or (2) refund to You the purchase price You paid to Monster or the Authorized Dealer for the Defective Product if repair or replacement is not commercially practicable or cannot be timely made. NOTE: TO THE FULLEST EXTENT PERMITTED BY APPLICABLE LAW, MONSTER DOES NOT ASSUME ANY LIABILITY FOR ANY INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES UNDER THIS LIMITED WARRANTY.

### GENERAL PROVISIONS

**CHOICE OF LAW/JURISDICTION.** This Limited

Warranty and any disputes arising out of or in connection with this Limited Warranty ("Disputes") shall be governed by the laws of the jurisdiction where You bought the Product.

**OTHER RIGHTS.** THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM JURISDICTION TO JURISDICTION, AND WHICH SHALL NOT BE AFFECTED BY THIS LIMITED WARRANTY.\* THIS WARRANTY EXTENDS ONLY TO YOU AND CANNOT BE TRANSFERRED OR ASSIGNED. If any provision of this Limited Warranty is unlawful, void or unenforceable, that provision shall be deemed severable and shall not affect any remaining provisions. In case of any inconsistency between the English and other versions of this Limited Warranty, the English version shall prevail.

**REGISTRATION.** Please register Your Product at [www.MonsterProducts.com](http://www.MonsterProducts.com). Failure to register will not diminish Your warranty rights.

### SPECIFICATIONS TABLE

Product Model	Warranty Period for headphone
Product that accompanies this warranty statement	One (1) year for product sold in North America, South America and Asia Pacific
	Two (2) years for product sold in Europe

## FORMAL WARRANTY CLAIM

**HOW TO MAKE A CLAIM.** In the event of a Product Defect, You must follow these instructions: (1) Call Monster within two (2) months after You discover a Product Defect (or should have discovered it, if such Product Defect was obvious); (2) Give a detailed explanation of how the damage occurred; (3) Obtain a Return Authorization Number; (4) Return the Product, shipping prepaid by You (to be refunded if You are entitled to a remedy under the Scope of this Limited Warranty), to Monster for verification of damage, along with a copy of **Your original sales receipt or proof of purchase** (invoice or packing slip) for such Product, the completed claim form, and printed Return Authorization Number on the outside of the return package (the claim form will include instructions for return).

**TELEPHONE NUMBERS.** If You bought the Product in the **United States** (1-877-800-8989), **Latin America** (**Mexico** 011-882-800-8989), or **Asia Pacific** (**China** 400-820-8973), contact Monster, LLC via postal service at 455 Valley Drive, Brisbane, CA 94005 (**PLEASE NOTE THAT MONSTER DOES NOT ACCEPT PRODUCTS SHIPPED TO THIS ADDRESS – FOLLOW INSTRUCTIONS IN “HOW TO MAKE A CLAIM” ABOVE**). If You bought the Product in Australia, contact Monster’s agent, Convoy

International Pty Ltd (02 9700 0111), Unit 7, 1801 Botany Rd, Banksmeadow, NSW 2019 Australia. If You bought the Product anywhere else, contact Monster Technology International Ltd., Ballymaley Business Park, Gort Road, Ennis, Co. Clare, Ireland. You can use one of the following telephone numbers:

<b>United States</b>	1-877-800-8989
<b>Canada</b>	866-348-4171
<b>Mexico</b>	011-882-800-8989
<b>China</b>	400-820-8973
<b>Ireland</b>	353 65 68 69 354
<b>Austria</b>	0800296482
<b>Belgium</b>	0800-79201
<b>Denmark</b>	8088-2128
<b>Finland</b>	800-112768
<b>France</b>	0800-918201
<b>Germany</b>	0800-1819388
<b>Greece</b>	00800-353-12008
<b>Italy</b>	800-871-479
<b>Netherlands</b>	0800-0228919
<b>Norway</b>	800-10906
<b>Russia</b>	810-800-20051353
<b>Spain</b>	900-982-909
<b>Sweden</b>	020-792650
<b>Switzerland</b>	0800834659
<b>Czech Republic</b>	800-142471
<b>United Kingdom</b>	0800-0569520

**FURTHER PROCEEDINGS.** Monster will determine

whether a Product Defect existed. Monster may, at its discretion, direct You to obtain a repair estimate at a service center. If a repair estimate is required, You will be instructed on how to properly submit the estimate and the resulting invoice to Monster for payment. Any fees for repairs may be negotiated by Monster.

**TIMING.** If You bring a Formal Warranty Claim and fully comply with all terms and conditions of this Limited Warranty, Monster will use its best efforts to provide You with a remedy within thirty (30) days after receipt of Your Formal Warranty Claim (if You reside in the United States – forty-five (45) days if You reside elsewhere), unless obstacles outside Monster's control delay the process.

\* Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.