



User manual V1.



IW100: Wi-Fi Smart Wall Socket US Type IW101: Wi-Fi Smart Wall Switch US Type


Use Instructions

1 Power off




- To avoid electric shocks, please consult the dealer or a qualified professional for help when installing and repairing.
- 2 Wiring instruction

IW100



IW101



① Ensure correct wiring for live, neutral and earth wire.

3 Download the APP




4 Power on



After powering on, the device will enter the quick pairing mode (Touch) during the first use. The Wi-Fi LED indicator changes in a cycle of two short and one long flash.

- The device will exit the quick pairing mode (Touch) if not paired within 3mins. If you want to enter this mode, please long press the touch switch for about 5s until the Wi-Fi LED indicator changes in a cycle of two short and one long flash and release.
- 6 Add the device



Tap "+" to operate following the prompt on the APP.

Specifications

B/IW101
60Hz
incandescent or CFL load.
cent: 600W/120V W/120V
4.1 & iOS 9.0) or higher
.11 b/g/n 2.4GHz
-
5mm

IW101

A cover plate approved in this report or a listed non-metallic flush cover plate shall be used when installed in the intended manner.

Strippable insulated conductor length: 8mm


Wire gauge: 12AWG


Wire quantity required: 3

Material: copper

⚠ For control of incandescent or CFL luminaires only.

Product Introduction





Features

Turn on/off the devices from anywhere, schedule power on/off and share devices with your family to control.




Factory Reset

Sync Status

Long press the configuration button for about 5s until the Wi-Fi LED indicator changes in a cycle of two short and one long flash and release, then the reset is successful. The device enters quick pairing mode (Touch).

Camera Feature

LAN Control



① Please reset the device to factory defaults if you want to use other Wi-Fi networks, then reconnect the network.

Common Problems

- Q: Why my device stays "Offline"?
- A: The newly added device needs 1-2mins to connect Wi-Fi and network. If it stays offline for a long time, please judge these problems by the blue Wi-Fi indicator status:
- The blue Wi-Fi indicator quickly flashes once per second, which means that the switch failed to connect your Wi-Fi:
 - ① Maybe you have entered a wrong Wi-Fi password.
 - ② Maybe there's too much distance between the switch your router or the environment causes interference, consider getting close to the router. If failed, please add it again.
 - 3 The 5G Wi-Fi network is not supported and only supports the 2.4GHz wireless network.
 - Maybe the MAC address filtering is open. Please turn it off.

If none of the above methods solved the problem, you can open the mobile data network on your phone to create a Wi-Fi hotspot, then add the device again.

Blue indicator quickly flashes twice per second, which means your device has connected to Wi-Fi but failed to connect to the server.

Ensure a steady enough network. If double flash occurs frequently, which means you access an unsteady network, not the product problem. If the network is normal, try to turn off the power to restart the switch.

Scan the QR code to read the voice control instruction for Amazon Echo and Google Home.



https://www.sonoff.tech/usermanuals Scan the QR code or visit the website to learn the detailed user guide.

FCC Warning

Changes or modifications not expressly approved by the party responsible for compliance could avoid the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or televisionneception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different
- from that to which the receiver is connected.

 Consult the dealer or an experienced radio/TV technician for help.

Shenzhen Sonoff Technologies Co., Ltd.

Room 1001, 10F, Building 8, Lianhua Industrial Park, Longyuan Road, Longhua District, Shenzhen, GD, China

Website: https://sonon.ceci.
Service email: support@itead.cc Website: https://sonoff.tech









