# Installation meethods and precautions

Receiver and transmitter key schematic diagram



Model: A10/A20/A86/A60/A88/A50/A78/A96/A58/A19/A28/A29

# - Installation meethods and precautions

### A series wireless doorhell.

A series wireless doorbell is A smart doorbell different from the traditional wireless doorbell, the transmitter and receiver can be freely paired, simple operation and easy to use, no electromagnetic interference.

### Product features:

- ◆ Fashionable design ◆ Easy installation ◆ Multiple music
- ◆5 levels of volume (including mute) ◆ The receiving distance is long
- ◆ Up to 300 meters in a straight line (laboratory test data)
- ◆ And the transmitter and receiver can be freely matched.

### Music Settings:

After selecting music, long press the volume button for 4 seconds, and the receiver lights up and enters the learning state; When the transmitter is pressed, the receiver flashes light and emits a ring tone to lock the ring tone successfully.

## Free matching mode of transmitter and receiver:

Long press the volume button of the receiver for 4 seconds, the receiver lights up and enters the learning state; When the transmitter is pressed, the receiver flashes light and rings to indicate that a match has been made.

#### NOTE:

- Non-professional personnel are forbidden to open the device whichmay result in destroy precision electronic components.
- High-voltage circuit in the device, don't open it when it's working. Or it may result in electrical shock.
- 3. Use the doorbell in the right way can makes it long life.
- 4. Functional range may be adversely affected by one or more of the following factors: weather, radio frequency interference, low transmitter battery and obstructions between the transmitter and receiver.
- 5. Old batteries can also corrode the connections and damage the button or doorbell. If you found out the function range decrease shorter, please change fresh battery in time.
- 6. Do not install on metal objects (such as iron doors, stainless steel doors, etc.)

Tansmitter USE a 23A12V alkaline battery Receiver voltage: 100-240V Size:

Size:

Transmitter 75x51x20mm, Receiver 95x65x24mm.



Please refer to the relevant laws and regulations if there are any outstanding issues or disputes. The company reserves the right to amend and ultimately interpret this statement