





Model XDT13M/R/Z Parts List

A = Standard Equipment

O= Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	183E34-9	HOUSING SET	1
	C10 263005-3	RUBBER PIN 6	2 PC.
	C20 252126-6	HEX. LOCKING NUT M4-7	2 PC.
	D10	INC. 35	
002	852K78-3	XDT13 NAME PLATE	1
003	266429-2	TAPPING SCREW 3X16	9 PC.
004	455053-8	F/R CHANGE LEVER	1 PC.
005	143975-1	SWITCH COMPLETE	1
006	619404-1	ROTOR	1
007	629224-5	STATOR	1
008	620557-1	LED CIRCUIT	1
009	643860-3	TERMINAL	1 PC.
010	231951-8	RING SPRING 11	1 PC.
011	267085-1	FLAT WASHER 12	1 PC.
012	233005-7	COMPRESSION SPRING 13	1 PC.
013	326068-1	BIT SLEEVE	1 PC.
014	424888-8	BUMPER	1
016	143957-3	HAMMER CASE COMPLETE	1
017	261151-6	NYLON WASHER 19	1 PC.
018	216040-0	STEEL BALL 3.5	2 PC.
019	326563-1	ANVIL M	1
020	326564-9	HAMMER	1
021	216040-0	STEEL BALL 3.5	24 PC.
022	267175-0	FLAT WASHER 24	1 PC.
023	234251-5	COMPRESSION SPRING 25	1 PC.
025	216041-8	STEEL BALL 5.6	2
026	227362-3	SPUR GEAR 22	2 PC.
027	326562-3	SPINDLE	1
028	256253-1	PIN 5	2 PC.
029	253314-8	THIN WASHER 15	1 PC.
030	227378-8	INTERNAL GEAR 51	1
031	213606-7	O RING 48	1 PC.
032	213507-9	O RING 40	1 PC.
033	143958-1	BEARING BOX COMPLETE	1
035	183E34-9	HOUSING SET	1
	C10 263005-3	RUBBER PIN 6	2 PC.
	C20 252126-6	HEX. LOCKING NUT M4-7	2 PC.
	D10	INC. 1	
039	266490-9	TAPPING SCREW PT 2X6	3 PC.
040	652069-6	FLAT HEAD SCREW M3X6	3 PC.
041	620556-3	CONTROLLER	1
	D10	INC. 8	
042	809R90-6	CAUTION LABEL	1
A01	266622-8	+ TRUSS HEAD SCREW M4X12	1 PC.
A02	346449-3	HOOK	1 PC.
A03	450128-8	BATTERY COVER	1 PC. (XDT13M/R)
A04	***DC18RC	DC18RC FAST CHARGER	1 PC. (XDT13M/R)
	D10	COMPO-PARTS	
A05	BL1840B	BATTERY BL1840B SET	2 (XDT13M)

	BL1820B	BATTERY BL1820B SET	2	(XDT13R)
A06	141856-3	PLASTIC CARRYING CASE COMPLETE	1 PC.	(XDT13M/R)
C10	162302-3	LATCH	2 PC.	(XDT13M/R)




Model XPH12 M/R/Z Parts List

A = Standard Equipment

○= Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	183E71-3	HOUSING SET	1	
	C10 263005-3	RUBBER PIN 6	2	PC.
	C20 252126-6	HEX. LOCKING NUT M4-7	2	PC.
	D10	INC. 21		
002	852L95-9	XPH12 NAME PLATE	1	
003	266429-2	TAPPING SCREW 3X16	7	PC.
004	419041-9	F/R CHANGE LEVER	1	PC.
005	650710-5	SWITCH C3JW-4B	1	
006	619406-7	ROTOR	1	
007	629225-3	STATOR	1	
008	620549-0	LED CIRCUIT	1	
009	643874-2	TERMINAL	1	PC.
010	123738-1	SPEED CHANGE LEVER ASSEMBLY	1	
	C10 233438-6	COMPRESSION SPRING 4	2	PC.
011	251497-8	TAPPING SCREW 3X20	4	
012	251468-5	- FLAT HEAD SCREW M6X22	1	PC.
013	766027-7	KEYLESS DRILL CHUCK 13	1	
014	123736-5	GEAR ASSEMBLY	1	
015	266490-9	TAPPING SCREW PT 2X6	3	PC.
016	620548-2	CONTROLLER	1	
017	652069-6	FLAT HEAD SCREW M3X6	3	PC.
018	424517-3	CUSHION	1	PC.
019	456966-6	REAR COVER	1	
020	809U04-3	CAUTION LABEL	1	
021	183E71-3	HOUSING SET	1	
	C10 263005-3	RUBBER PIN 6	2	PC.
	C20 252126-6	HEX. LOCKING NUT M4-7	2	PC.
	D10	INC. 1		
022	266429-2	TAPPING SCREW 3X16	2	PC.
A01	251314-2	+ SCREW M4X12	1	PC.
A02	346449-3	HOOK	1	PC.
A04	158597-4	PLASTIC CASE COMPLETE	1	PC. (XPH12M/R)
	C10 417724-5	LATCH	2	PC. (XPH12M/R)
A05	450128-8	BATTERY COVER	1	PC. (XPH12M/R)
A06	***DC18RC	DC18RC FAST CHARGER	1	PC. (XPH12M/R)
	D10	COMPO-PARTS		
A07	BL1840B	BATTERY BL1840B SET	2	(XPH12M)
	BL1820B	BATTERY BL1820B SET	2	(XPH12R)




Model XRJ05M/Z Parts List

A = Standard Equipment

O= Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	424763-8	PROTECTOR	1
002	257952-8	RETAINING RING (EXT) 18	1 PC.
003	310662-9	DRIVING SLEEVE	1
004	256569-4	SHOULDER PIN 5	1
005	234381-2	COMPRESSION SPRING 6	1
006	331720-8	GUIDE SLEEVE	1 PC.
007	268094-3	PIN 3	1 PC.
008	256158-5	PIN 3	1 PC.
009	417791-0	DRIVING SLEEVE GUIDE	1 PC.
010	418311-3	SLEEVE	1 PC.
011	345214-7	PUSH PLATE	1 PC.
012	233025-1	COMPRESSION SPRING 2	1 PC.
013	231687-9	TORSION SPRING 17	1 PC.
014	424762-0	RUBBER RING	1
015	143365-8	SLIDER GUIDE COMPLETE	1 PC.
	C10 213151-2	OIL SEAL 14	1 PC.
	C20 213174-0	X RING 14	1 PC.
016	161376-1	SLIDER	1
017	310663-7	ROLLER	1
018	268341-2	PIN 6	1
019	310663-7	ROLLER	1
020	620434-7	LED CIRCUIT	1 PC.
021	922117-8	HEX. SOCKET HEAD BOLT M4X12	2 PC.
022	346936-2	ROD GUIDE R	1
023	143362-4	GEAR HOUSING R COMPLETE	1 PC.
024	911128-8	PAN HEAD SCREW M4X16	5 PC.
026	922107-1	HEX. SOCKET HEAD BOLT M4X8	1 PC.
027	267491-0	FLAT WASHER 4	1
028	143359-3	GEAR COMPLETE	1 PC.
029	267490-2	FLAT WASHER 54	1
030	424764-6	SEAL RING	1
031	922117-8	HEX. SOCKET HEAD BOLT M4X12	2 PC.
032	346935-4	ROD GUIDE L	1
034	424765-4	INSULATION COVER	1
035	161374-5	SHOE	1
037	912112-6	COUNTERSUNK HEAD SCREW M4X10	1 PC.
038	253825-3	FLAT WASHER 6	1 PC.
039	123509-6	GEAR HOUSING L ASSEMBLY	1 PC.
	D10	INC. 37,38	
040-1	519418-9	ROTOR ASS'Y	1
	D10	INC. 41-45	
041	961052-5	RETAINING RING S-12	1 PC.
042	211129-9	BALL BEARING 6201DDW	1 PC.
043	253744-3	FLAT WASHER 12	1 PC.
044	285740-3	BEARING RETAINER 66	1
045	210062-2	BALL BEARING 607ZZ	1 PC.
046	911128-8	PAN HEAD SCREW M4X16	2 PC.
047	266069-6	TAPPING SCREW 4X45	2 PC.
048	456178-1	BAFFLE PLATE	1

049	629179-4	STATOR	1	
050	456179-9	MOTOR HOUSING	1	
051	911243-8	PAN HEAD SCREW M5X25	4 PC.	
052	456177-3	CHANGE BUTTON	1	
053	650759-5	SWITCH C3JW-6B-2	1	
054	620432-1	CONTROLLER A	1 PC.	
055	643899-6	TERMINAL	1 PC.	
056	183C47-8	HANDLE SET	1	
	C10 263005-3	RUBBER PIN 6	2 PC.	
	D10	INC. 60		
057	266326-2	TAPPING SCREW 4X18	6 PC.	
058	851P11-2	XRJ05 NAME PLATE	1	
059	807Y38-4	CAUTION LABEL	1	
060	183C47-8	HANDLE SET	1	
	C10 263005-3	RUBBER PIN 6	2 PC.	
	D10	INC. 56		
061	456176-5	LOCK LEVER	1	
062	266979-7	HEX.SOCKET HEAD BOLT M4X35 WR	2	
063	231231-2	COMPRESSION SPRING 12	1 PC.	
064	346938-8	SHOE LOCK PLATE	1	
065	326599-0	LOCK PIN	1	
066	346937-0	SHOE GUIDE PLATE	1	
067	123510-1	SLIDER ASSEMBLY	1 PC.	
	D10	INC. 1-16		
071	123455-3	HOOK ASSEMBLY	1 PC.	
	D10	INC. 72-77		
072	281223-1	HOOK	1	
073	262561-0	SLEEVE 6	1 PC.	
074	233455-6	COMPRESSION SPRING 7	1 PC.	
075	319344-0	JOINT	1	
076	951057-3	SPRING PIN 3-12	1 PC.	
077	310661-1	LOCK SLEEVE	1	
078	911206-4	PAN HEAD SCREW M5X10	2 PC.	
079	264002-2	SQUARE NUT M5	2 PC.	
080	424858-7	FELT 16X16	1 PC.	
081	263002-9	RUBBER PIN 4	1 PC.	
A01	194502-7	RECIPRO SAW BLADE SET	1 SET	
A03	821620-5	PLASTIC TOOL CASE	1	(XRJ05M)
	C10 162271-8	LATCH	2 PC.	(XRJ05M)
A05	450128-8	BATTERY COVER	1 PC.	(XRJ05M)
A06	***DC18RC	DC18RC FAST CHARGER	1 PC.	(XRJ05M)
	D10	COMPO-PARTS		
A07	BL1840B	BATTERY BL1840B SET (197268-8)	2	(XRJ05M)



Model XSH04RB/ZB Parts List

A = Standard Equipment

O= Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	458591-9	FRONT GRIP	1
002	265995-6	TAPPING SCREW 4X18	1 PC.
006	265995-6	TAPPING SCREW 4X18	7 PC.
007	854N74-5	XSH04 NAME PLATE	1
008	144251-6	INDICATION PLATE COMPLETE	1 PC.
009	140C50-2	MOTOR HOUSING COMPLETE	1
	C10 263005-3	RUBBER PIN 6	2 PC.
	C20 817J81-5	CAUTION LABEL	1
010	911263-2	PAN HEAD SCREW M5X40	3 PC.
011	419704-7	LOCK OFF BUTTON	1 PC.
012	651083-9	SWITCH C3XA-1PSPM	1
013	231433-0	COMPRESSION SPRING 4	2 PC.
015	458594-3	SWITCH LEVER	1
016	632L80-6	SWITCH UNIT	1 PC.
019	644809-6	TERMINAL	1 PC.
020	854N79-5	XSH04 SERIAL NO. LABEL	1
021	629362-3	STATOR	1
022	251517-8	TAPPING SCREW 4X40	2 PC.
023	620936-3	LED CIRCUIT	1
024	620935-5	CONTROLLER	1
025	458585-4	HANDLE COVER	1
026	458586-2	BAFFLE PLATE	1
027	458593-5	COVER	1
028	519527-4	ROTOR ASS'Y	1
	D10	INC. 29-31	
029	211012-0	BALL BEARING 606ZZ	1 PC.
030	240045-8	FAN 55	1 PC.
031	210059-1	BALL BEARING 6000DDW	1 PC.
032	233117-6	COMPRESSION SPRING 6	1 PC.
033	347400-6	SHAFT LOCK	1
034	911223-4	PAN HEAD SCREW M5X16	1 PC.
035	458589-6	DUCT	1
036	140D07-9	BLADE CASE COMPLETE	1
	C10 213821-3	O-RING 26	1 PC.
037	262511-5	RUBBER SLEEVE 6	1 PC.
038	265115-2	+ PAN HEAD SCREW M5	1 PC.
039	211012-0	BALL BEARING 606ZZ	1 PC.
040	961052-5	RETAINING RING S-12	1 PC.
041	226192-9	HELICAL GEAR 49	1
042	257173-2	RING 12	1 PC.
043	213512-6	O RING 39	1 PC.
044	135993-3	BEARING BOX ASSEMBLY	1
	D10	INC. 43	
045	265034-2	+ COUNTERSUNK HEAD SCREW M5X16	2 PC.
046	211131-2	BALL BEARING 6001DDW	1 PC.
047	285843-3	BEARING RETAINER 19-29	1 PC.
048	327244-0	SPINDLE	1
049	345469-4	THICKNESS RING	1 PC.
050	231832-6	TENSION SPRING 3	1 PC.

051	458587-0	SAFETY COVER	1	
052	961152-1	RETAINING RING (EXT) S-34	1 PC.	
053	224411-7	INNER FLANGE 35	1 PC.	
054	224409-4	OUTER FLANGE 35	1 PC.	
055	266925-0	HEX.SOCKET HEX.BOLT M6X18	1	
056	286036-5	CAP	1	
057	347399-5	LEVER PLATE	1	
058	257982-9	BOW STOP RING E-8	1 PC.	
059	264096-7	HEX. NUT M6	1	
060	267118-2	FLAT WASHER 6	1 PC.	
061	266737-1	FLAT HEAD SQ. NECK BOLT M6X20	1 PC.	
062	252631-3	SCREW M6	1 PC.	
063	942151-2	SPRING WASHER 6	1 PC.	
064	941151-9	FLAT WASHER 6	1 PC.	
065	161898-1	DEPTH GUIDE COMPLETE	1	
066	265939-6	FLAT HEAD SQ. NECK BOLT M6X14	1 PC.	
067	347401-4	REAR GUIDE PLATE	1	
068	265648-7	PAN HEAD SCREW M4X8	2	
069	252103-8	HEX. LOCK NUT M5-8	1 PC.	
070	345590-9	ANGULAR GUIDE	1 PC.	
071	256480-0	SHOULDER PIN 6-7	1 PC.	
072	318823-5	STOPPER	1 PC.	
073	213977-2	O RING 7	1 PC.	
074	266734-7	+ TRUSS HEAD SCREW M5	1 PC.	
075	251896-4	SCREW M5X20	1 PC.	
076	231007-7	COMPRESSION SPRING 6	1 PC.	
077	319715-1	ANGULAR PLATE	1	
078	941151-9	FLAT WASHER 6	1 PC.	
079	266735-5	HEX.BOLT M6X20	1 PC.	
080	271446-9	LEVER 45	1	
081	257982-9	BOW STOP RING E-8	1 PC.	
082	347397-9	BASE	1	
083	265085-5	+ COUNTERSUNK HEAD SCREW M4X8	2 PC.	
084	912212-2	COUNTERSUNK HEAD SCREW M5X12	4 PC.	
085	266436-5	H.S.SET SCREW(FLAT POINT)M5X8	3	
A01	783203-8	HEX. WRENCH 5	1 PC.	
A02	A-85092	T.C.T.SAW BLADE 165X24TX15.88	1 PC.	
A04	199230-9	DUST NOZZLE SET	1	
C10	911233-1	PAN HEAD SCREW M5X20	1 PC.	
A09	450128-8	BATTERY COVER	1 PC.	(XSH04RB)
A10	***DC18RC	DC18RC FAST CHARGER	1 PC.	(XSH04RB)
D10		COMPO-PARTS		
A11	197257-3	BATTERY BL1820B SET	2	(XSH04RB)
A12	831303-9	TOOL BAG	1	(XSH04RB)