

ZHJ007



INSTRUCTION MANUAL

ASSEMBLY INSTRUCTIONS


Carefully unpack all the components and verify that all the necessary parts are included as listed in the packaging.

Identify each component and refer to the provided assembly diagram or step-by-step instructions. Assemble the furniture in the order specified to ensure proper alignment and fit.

Use the provided tools or recommended tools for assembly. Do not use excessive force when tightening screws or bolts.

If any difficulties arise during assembly, consult the troubleshooting section or contact our customer support.

SOFA ASSEMBLY



Tools Required




PART


NO.	PICTURE	QTY	NO.	PICTURE	QTY	NO.	PICTURE	QTY
M		1	E	 M6x25mm	4	H		12
N		1	F	 M6x30mm	2	I		12
C	 Left	1	G	 M6x45mm	4	O		1
D	 Right	1	P	 M6x15mm	2	Z		4

Do not fully tighten all bolts until assembly is complete.

STEP 1




STEP 2




Do not fully tighten all bolts until assembly is complete.

STEP 3




STEP 4



Do not fully tighten all bolts until assembly is complete.

STEP 5



STEP 6





TABLE ASSEMBLY



Tools Required




PART


NO.	PICTURE	QTY	NO.	PICTURE	QTY	NO.	PICTURE	QTY
T		1	E	 M6x25mm	8	I		8
U		2	H		8	Z		4

Do not fully tighten all bolts until assembly is complete.

STEP 1



STEP 2





MAINTENANCE AND CARE

Protect your furniture from extreme weather conditions by moving it to a covered area. Alternatively, use furniture covers or traps for added protection.

Avoid dragging or placing heavy objects on the furniture to prevent potential damage.

Regularly inspect your furniture for signs of wear, loose strands, or damage. Address any issues promptly.

Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary.

Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.

Do not use sharp objects to scratch the painted surface. We do not recommend the use of chemical cleansers, abrasives or furniture polish on our lacquered finish.

Clean with a damp cloth soaked in warm soapy water or a specialized, suitable cleaning product.

Conclude the cleaning process by wiping with a clean, dry cloth.

Ensure proper drying after cleaning or exposure to rain to prevent mold or mildew growth.

Avoid placing transparent glasses on the wood-plastic panel surface for long to prevent concentrating sunlight, which could lead to melting of the surface.



WARRANTY INFORMATION

Warranty Coverage: Our warranty provides protection against manufacturing defects in materials and workmanship for a specified period from the date of purchase, as outlined in the accompanying warranty documentation.

Exclusions: The warranty does not cover damages resulting from misuse, negligence, accidents, normal wear and tear, unauthorized repairs or modifications, improper assembly, or failure to adhere to the care and maintenance guidelines provided.



Contact Information

If you have any questions, concerns, or need assistance,
please reach out to our customer support team using the contact information
provided below:

Customer Support Email

support@royalcraft.store
