


## User Manual

## HDMI2.12X1 SWITCH

4K@120Hz 4:4:4 8bit VRR ALLM Dolby Vision, Dolby Atmos SONOS ARC/eARC TV ARC/eARC

F7-SW21H21A-F0





#### **OVERVIEW**


EZ-SW21H21A-EO is a 2x1 HDMI2.1 switch with Ultra HD 4K@120Hz support.It supports HDMI 2.1 specification features including data rates up to 4K@120Hz 4:4:4 8bit, VRR, ALLM, HDR and HDCP2.3, Deep Color, 3D, Lip Sync, and HD lossless Audio/Video formats. And Audio DE-embed, Optical Audio out without TV connected.And the product can use for SONOS ARC/eARC, OR TV ARC/eARC, OR HDMI2.1/HDMI2.0 AV receiver.


#### **FEATURES**

- Supports HDMI 2.1 4K@120Hz 4:4:4 8bit HDR, HDCP 2.3
- Supports Dolby Vision, VRR, ALLM, Dolby Atmos
- Supports EDID copy, multiple EDID setting for compatibility
- Supports 3D, Support deep color 30bit, 36bit
- Supports Blue-Ray 24/50/60fs/HD-DVD/xvYCC
- Supports HDMI signal re-timing, never lose quality
- Plug and Play; No driver required; Installs in minutes
- HDMI OUT1 support CEC ('AUDIO SOURCE(DIP1)' MUST SET TO 'HDMI IN')
- HDMI OUT1 support TV eARC/ARC ('AUDIO SOURCE (DIP1)' MUST SET TO 'eARC/ARC TV APP')
- HDMI OUT2 support soundbar eARC/ARC ('AUDIO DEVICE(DIP2)' MUST SET TO 'soundbar eARC/ARC')
- HDMI OUT2 support AV receiver ('AUDIO DEVICE(DIP2)' MUST SET TO 'AV RECEIVER IN PORT')

#### PRODUCT DIAGRAM










#### Package Accessories:

- HDMI Switch x1
- Power adapter x1
- 3 Reusable Cable Tie x2
- 4 User Manual x1
- 6 IR remote control x1
- 6 IR extender cable x1

## **INSTALLATION**



- 1.Connect HDMI2.1 cable(<3M) from HDMI source devices to HDMI switch inputs.
- 2.Connect HDMI2.1 cable(<3M) from display (monitor or projector) to the HDMI switch output.
- 3.Connect HDMI2.1 cable(<3M) from the HDMI switch Audio
- output to AVreceiver HDMI IN OR Soundbar ARC/eARC port .

4. Connect the power adapter into the HDMI switch.

## **EDID SETTING**

	EDID SETTING				
ATMOS/4K7.1	Copy TV'EDID, and audio will be Atmos/7.1CH				
SPDIF/4K5.1	Copy TV'EDID, and audio will be 5.1CH				
FIX EDID/4K7.1	Video will be 4K@120Hz VRR and audio will be Atmos/7.1CH				
COPY	EDID passthrough				

## **AUDIO SETTING**

1 0N		DIP SWITCH	Option		Function
		1	Audio source	HDMI IN	Audio OUT comes from HDMI INPUT of extractor
	1 2			eARC/ARC TV	Audio OUT comes from eARC/ARC port of TV(Play TV APPs)
	ON	2	Audio device	Soundbar eARC/ARC	Audio OUT connect to Soundbar eARC/ARC port
				AV Receiver IN	Audio OUT connect to AV Receiver input port

## **SPECIFICATIONS**

HDMI vertion	HDMI 2.1	HDCP version	HDCP 2.3		
HDMI 8k/4K/1080p/1080i/720p/ 576p/576i/480p/480i		Video format	24bit/30bit/36bit		
Audio format	Dolby true HD/DTS-HD/DTS5.1/Dolby AC3/DSD/ Dolby Atmos				
Input/Output TMDS signal 0.5~1.5Volts p-p(TTL)		Max working current	2A		
Input/Output DDC signal	5Volts p-p (TTL)	Operating Humidity range	5 to 90%RH (No Condensation)		
Power adapter format	Input AC 100V-240V/ 50HZ,60HZ; Output: 5V2A	Operating Temperature range	(~15 to +55°C)		
Dimension (LxWxH) 130*64*20 (mm)		Weight	150g		


#### **USING TIPS**

- Re-powering and unplugging the HDMI cable is a common troubleshooting method.
- Please use qualified or brand-new HDMI 2.1 standard cable less than 3 meter.
- SPDIF can only support up to 5.1 (no Atmos) if you need 7.1 or Atmos, please use HDMI OUT
- If use eARC/ARC function, please make sure your TV and soundbar support eARC/ARC.

#### Soundbar mode

AUDIO DEVICE: SET TO "SOUNDBAR eARC/ARC" AUDIO SOURCE: SET TO "HDMI IN"


----- Audio source will be PS5 or APPLE TV



#### Soundbar mode

AUDIO DEVICE: SET TO "SOUNDBAR eARC/ARC" AUDIO SOURCE: SET TO "eARC/ARC TV APP"


----- Audio source will be TV APPs



#### **AV Receiver Mode**

AUDIO DEVICE: SET TO "AV RECEIVER IN PORT" AUDIO SOURCE: SET TO "HDMI IN"


----- Audio source will be PS5 or APPLE TV



#### **AV Receiver Mode**

AUDIO DEVICE: SET TO "AV RECEIVER IN PORT" AUDIO SOURCE: SET TO "eARC/ARC TV APP"

----- Audio source will be TV APPs



#### **NOTES**

# Please use this machine based on below instructions to keep longer lifetime.

- The machine should be placed at the spot far away from the Damp, High-Temperature, Dusty, Erosive, and Oxidant environment.
- 2. All parts will be free from the strong shake, hit, fall.
- 3. Touching the device with the wet hands is prohibited.
- 4. Please turn power off when machine is not used for long time.
- Please do not open the cover and do not touch the inside parts.
- 6. Please use the original factory power adaptor.
- Before power on, please check the connection cable carefully.And make sure that all interfaces are normally connected.

#### **DISCLAIMERS**

The information in this manual has been carefully checked and is believed to be accurate. EZCOO TECHNOLOGY INC. assumes no responsibility for any infringement of patents or other rights of third parties which may result from its use. EZCOO TECHNOLOGY INC. assumes no responsibility for any inaccuracies that may be contained in this document. EZCOO TECHNOLOGY INC. also makes no commitment to update or to keep current the information contained in this document. EZCOO TECHNOLOGY INC. reserves the right to make improvements to this document and/or product at any time and without notice.

#### **CONTACTS**

When you need any technical assistance, please send e-mail to support@easycoolav.com

Visit to learn more.

https://www.easycoolav.com



EZCOO TECHNOLOGY INC support@easycoolav.com https://www.easycoolav.com