



Home » NEXCOM » Nexcom MD88SFA Bluetooth LE Module User Manual 🏗



Nexcom MD88SFA Bluetooth LE Module User Manual


July 27, 2025

> Nexcom International Co., Ltd. 10F, No.920, Chung-Cheng Road Zhonghe Dist., New Taipei City Taiwan 235, R.O.C

Contents [hide]
1 Bluetooth LE Module
1.1 MD88SFA
1.1.1 Version Note
1.1.2 Part Number
1.1.2.1 MS88SFA-nRF52833
1.1.2.2 FEATURES
1.1.2.3 KEY PARAMETER
1.1.2.4 1 BLOCK DIAGRAM
1.1.2.5 2 ELECTRICAL SPECIFICATION
1.1.2.6 3 PIN DESCRIPTION
1.1.2.7 4 PIN DEFINITION
1.1.2.8 5 MECHANICAL DRAWING
1.1.2.9 6 ELECTRICAL SCHEMATIC
1.1.2.10 7 PCB LAYOUT
1.1.2.11 8 REFLOW AND SOLDERING
1.1.2.12 9. label
1.1.2.13 10 STORAGE CONDITIONS
1.1.2.14 11 HANDLING CONDITIONS
1.1.2.15 12 QUALITY
1.1.2.16 13.
2 Documents / Resources
2.1 References

Bluetooth LE Module

MD88SFA





Version Note

Version	Details	Contributor(s)	Date	Notes
1.0.0	First edit	Michelle, Leo	2024.05.09	

Part Number

Model	Hardware Code
MS88SFA8	8Y33AI

MS88SFA-nRF52833

Low Power, Multi-Protocol Bluetooth 5.4 PA Module

The MS88SFA is a BLES.4 PA/LNA module base on Nighty flexible and very low power-loss nRFS2833 SoC. It owns o RF transceiver of Cortex-M4F ARM core operating at speed of 64Mhz. Besides. it has 512kB FLASH programmer space. 128kB RAM and other matching powerful resources. The nRF52833 is able to support ANT. BLE. BLE MESH. ZIGBEE and THREAD protocols. etc. Communication distance up to 600m under condition of 1Mbps rote and PA/LNA built in.







Power up to Maximurn+20dbm



Support ANT, BLE, BLE MESH, ZIGBEE and THREAD protocols, etc.



Transmission distance up to 600 meters in open space


KEY PARAMETER

MS88SFA-nRF52833

Chip Model	Nordic nRF52833
Module Site	23.2×17.4×2mm
Flash	512kB
Receiving Sensitivity	-96dBm
Antenna	APEX(MHF 5)
GPIO	29

RAM	128KB
Transmission Power	~+20dBm

1 BLOCK DIAGRAM




2 ELECTRICAL SPECIFICATION

Parameters	Value	Notes
Working Voltage	1.7V-5.5V	To ensure RF work, supply voltage suggest not low er than 3V
Working Tempera ture	-40 °C ~+85 °C	Storage temperature is -40 °C ~+125 °C
Transmission Po wer	~+20dBrn	Configurable

Module Dimensio	23.2*17.4*2
n	mm
Quantity of IO Po	29

3 PIN DESCRIPTION

. . .




4 PIN DEFINITION


Pin Num ber	Sym bol	Туре	Definition
14	VDD	Power sou rce	Power supply: 1.7V-3.6V, short-circuit VDD and VDD H to use the pin to supply power
27	VDD H	Power sou rce	Power supply 2.5V-5.5V; When supply 5V electricity, use this pin to supply power, not connect vin pin.


1/13/26/	GND	Ground	Ground
37/38	SWC LK/S WDI O	Debug	Debug, when debugging only need to connect power supply pin, ground and these 2 pins.
2-12/16- 24/30-36 /39-40	P0.02 -P0.3 1 P1.00 -P1.0	I/O	IO port for general purpose
25	VBU S	Power sou rce for US B port	5V input current for USB 3.3V modulator Need to sup ply 5V current and short-circuit this pi with VDDH Wh en use USB port
15	VCC_ PA	PA supply power pin	Must provide electricity of 2.7-3.6V stably, 1.7V-3.6V chip voltage, this pin can be shorted to VDD/VDDH
29	D+	Digital inte	USB D+
28	D-	Digital inte	USB D-

5 MECHANICAL DRAWING



6 ELECTRICAL SCHEMATIC





TXEN	RXEN	MODE	Operational Mode
0	0	0	Shutdown mode
0	1	0	Rx High Current/Low NF Mode
1	0	0	TX Mode
1	1	0	TX Mode

0	0	1	Bypass Mode
0	1	1	Rx Low Current Mode

⚠ Notice: Before placing an order, please confirm the specific configuration required with the salesperson.


7 PCB LAYOUT


There should be no GND plane or metal cross wiring in the module antenna area, and components should not be placed nearby. It is best to make a hollow or clear area, or place it on the edge of the PCB board.

A Notice: Refer to examples as below, and highly suggest to use the first design and the adjustment of modules antenna design according to the first wiring.

Layout Notes:

- 1) Preferred Module antenna area completely clearance and not be prevented by metals, otherwise it will influence antenna's effect (as above DWG. indication).
- 2) Cover the external part of module antenna area with copper as far as possible to reduce the main board's signal cable and other disturbing.
- 3) It is preferred to have a clearance area of 4 square meter or more area around the module antenna (including the shell) to reduce the influence to antenna.
- 4) Device should be grounded well to reduce the parasitic inductance.
- 5) Do not cover copper under module's antenna in order to avoid affect signal radiation or lead to transmission distance affected.
- 6) Antenna should keep far from other circuits to prevent radiation efficiency reduction or affects the normal operation of other lines.
- 7) Module should be placed on edge of circuit board and keep a distance away from other circuits.
- 8) Suggesting to use magnetic beads to insulate module's access power supply.






8 REFLOW AND SOLDERING

1) Do SMT according to above reflow oven temperature deal curve. Max. Temperature is 260°C;

Refer to IPC/JEDEC standard; Peak TEMP<260 °C; Times: ≤2 times, suggest only do once reflow soldering on module surface in case of SMT double pad involved. Contact us if special crafts involved.

- 2) Suggesting to make 0.2mm thickness of module SMT for partial ladder steel mesh. then make the opening extend 0.8mm
- 3) After unsealing, it cannot be used up at one time, should be vacuumed for storage, couldn't be exposed in the air for long time. Please avoid getting damp and soldering-pan oxidizing. If there are 7 to 30 days interval before using online SMT, suggest to bake at 65-70 °C for 24 hours without disassembling the tape.
- 4) Before using SMT. please adopt ESD protection measure.



9. label

NE(COM

FCC ID: YHIMD88SFA

Model: MD88SFA

10 STORAGE CONDITIONS

- Please use this product within 6 months after signing the receipt.
 - This product should be stored without opening the package at an ambient temperature of 5-35°C and a humidity of 20-70%RH.
 - This product should be left for more than 6 months after receipt and should be confirmed before use.
 - The product must be stored in a non-corrosive gas (CI2, NH3, SO2, NOx, etc.).
 - To avoid damaging the packaging material, do not apply any excessive mechanical shocks, including but not limited to sharp objects adhering to the packaging material and product dropping.
- This product is suitable for MSL2 (based on JEDEC standard J-STD-020).
 - After opening the package. the product must be stored at ≤30°C/<60%RH. It is recommended to use the product within 3-6 months after opening the package.
 - When the color of the indicator in the package changes, the product should be baked before welding.
- Baking is not required for one year if exposure is limited to <30°C and 60%RH.
 Refer to MSL2 for exposure criteria for moisture sensitivity level. If exposed to (≥168h©85°C/60%RH) conditions or stored for more than one year,

recommended baking conditions.

1. 120 +5/-5°C, 8 hours, 1 time

Products must be baked individually on heat-resistant trays because the materials (base tape, reel tape. and cover tape) are not heat-resistant. and the packaging material may be deformed at temperatures of 120 °C;

2. 90°C +8/-0°C , 24hours, 1times

The base tape can be baked together with the product at this temperature. Please pay attention to the uniformity of heat.

11 HANDLING CONDITIONS

- Be careful in handling or transporting products because excessive stress or mechanical shock may break products.
- Handle with care if products may have cracks or damages on their terminals. If there
 is any such damage, the characteristics of products may change. Do not touch
 products with bare hands that may result in poor solder ability and destroy by static
 electrical charge.

12 QUALITY

Cognizant of our commitment to quality, we operate our own factory equipped with state-of-the-art production facilities and a meticulous quality management system. We hold certifications for ISO9001, ISO14001, ISO27001, OHSA18001, BSCI.

Every product undergoes stringent testing, including transmit power, sensitivity, power consumption, stability, and aging tests. Our fully automated module production line is now in full operation, boasting a production capacity in the millions, capable of meeting high-volume production demands.

13.

FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/ TV technician for help.

CAUTION:

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

RF Exposure warning

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

Information for OEMs and host integrators

The OEM or integrator is obligated to adhere to these requirements and restrictions as a condition for using the module's certification.

The OEM or integrator is responsible to perform the required additional host regulatory testing and/or obtaining the required host approvals for compliance.

Per KDB 996369 D03 v01r01 OEM Manual section 2.2 to 2.12, this module is intended for OEM integrators under the following conditions:

2.2 List of applicable FCC rules

This module has been tested for compliance to FCC Part 15 Subpart C (15.247).

2.3 Summarize the specific operational use conditions

The module is tested for standalone mobile RF exposure use condition. Any other usage conditions such as colocation with other transmitter(s) will need a separate reassessment through a class II permissive change application or new certification.

2.4 Limited module procedures

Not applicable, this device is a single modular approval and meets FCC 47 CFR 15.212 requirement.

2.5 Trace antenna designs

Not applicable. This module should use an external antenna, and use of internal PCB antenna is prohibited. The module has been approved to operate with the antenna types listed below, with the maximum permissible gain indicated.

No.	1
Manufacturer	ARISTOTLE
Part No.	RFA-25-T42-U-M70
Antenna Type	OMNI
Peak Gain (dBi)	2.6 dBi
Freq. Range (GHz)	2.4~2.4835
Connector Type	RP SMA PLUG

2.6 RF exposure considerations

This equipment complies with FCC mobile radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a

minimum distance of 20cm between the radiator & your body. A separate SAR/Power Density evaluation is required to confirm compliance with relevant FCC portable RF exposure rules.

2.7 Label and compliance information

Label of the end product:

The final end product must be labeled in a visible area with the following: "Contains FCC ID: YHIMD88SFA". The grantee's FCC ID can be used only when all FCC compliance requirements are met

2.8 Information on test modes and additional testing requirements

This transmitter is tested in a standalone mobile RF exposure condition and any colocated or simultaneous transmission with other transmitter(s) class II permissive change re-evaluation or new certification.

2.9 Additional testing, Part 15 Subpart B disclaimer

This transmitter module is tested as a subsystem and its certification does not cover the FCC Part 15 Subpart B (unintentional radiator) rule requirement applicable to the final host. The final host will still need to be reassessed for compliance to this portion of rule requirements if applicable. As long as all conditions above are met, further transmitter test will not be required. However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements required with this module installed.

IMPORTANT NOTE: In the event that these conditions cannot be met (for example certain laptop configurations or co-location with another transmitter), then the FCC authorization is no longer considered valid and the FCC ID cannot be used on the final product. In these circumstances, the OEM integrator will be responsible for reevaluating the end product (including the transmitter) and obtaining a separate FCC authorization.

Manual Information To the End User

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module. The end user manual shall include all required

regulatory information/warning as show in this manual.

OEM/Host manufacturer responsibilities

OEM/Host manufacturers are ultimately responsible for the compliance of the Host and Module. The final product must be reassessed against all the essential requirements of the FCC rule such as FCC Part 15 Subpart B before it can be placed on the US market. This includes reassessing the transmitter module for compliance with the Radio and EMF essential requirements of the FCC rules. This module must not be incorporated into any other device or system without retesting for compliance as multi-radio and combined equipment.

Warning message

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Documents / Resources



Nexcom MD88SFA Bluetooth LE Module [pdf] User Manual MD88SFA, YHIMD88SFA, md88sfa, MD88SFA Bluetooth LE Module, MD 88SFA, Bluetooth LE Module, LE Module, Module

References

- User Manual
- NEXCOM
- ▶ Bluetooth LE Module, LE Module, MD88SFA, MD88SFA Bluetooth LE Module, Module, NEXCOM, YHIMD88SFA

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *		
Name		
Email		
Website		
Save my name, email, and website in this browser for the next time I com	nment.	
Post Comment		
Search:		
e.g. whirlpool wrf535swhz	Search	

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.