



Remodo X Remote Control User Manual

[Home](#) » [Remodo X](#) » Remodo X Remote Control User Manual 

Contents

- [1 Remodo X Remote Control](#)
- [2 Introduction](#)
- [3 Product Overview](#)
- [4 Features](#)
- [5 Setup Mode and Control Mode](#)
- [6 Pairing](#)
- [7 Adding or Modifying Commands](#)
- [8 Programming HID Keys](#)
- [9 Adding & Controlling IR Devices](#)
- [10 Technical Specifications](#)
- [11 Maintenance](#)
- [12 Warranty](#)
- [13 Customer Service & FAQ](#)
- [14 Documents / Resources](#)
 - [14.1 References](#)
- [15 Related Posts](#)



Remodo X


Remodo X Remote Control



Introduction

Remodo X is an elegantly designed Bluetooth remote for Raspberry Pi. With 4 programmable buttons, Remodo X can be optimized to carry out 8 commands and shortcuts (short & long press). It also boasts the capability to be used as a presentation clicker or a universal IR remote controller that supports over 6000 branded devices.

Product Overview



Features

- Programmable HID keys
- Presentation mode & IR remote controller mode
- Comprehensive access to cloud-based infrared code library database

- LED indication
- Upgradeable firmware over-the-air (OTA)

Requirements:

iOS 13 or above (Supports BLE4.2)

Android – Android 5.0 or above (Supports BLE4.2)


Application Software (App) Installation Scan QR code or search “REMODO” to download



Setup Mode and Control Mode

Setup Mode serves to pair to and configure keys through our Remodo app. Hold “Key 3” and “Key 4” until you hear the “beep” sound and see blinking red light in order to switch the remote to this mode. This mode should be used for the initial pairing and key configurations setup and whenever you want to change the key commands and configurations.


Setup Mode Example



Setup Mode and Control Mode:


Control Mode serves to connect to and operate your targeted platform or device. Hold Keys 1 & 2 until you hear a “beep” sound and see blinking green light to switch to this mode. Switching the remote to Control mode is required in order to control your devices after setup and/or configuring keys.

Control Mode Example




Pairing

Pairing the remote controller requires both Wi-Fi and Bluetooth to be turned on. Insert 2 AAA batteries to battery compartment and place the remote near the smart phone handset. Hold “Key 3” and “Key 4” until you hear the “beep” sound and see blinking red light indicating setup mode then press “Start Pairing” to pair the remote with the app.




Each remote has a unique id (e.g. Remodo_X_setup_00006) and the app will scan for this remote controller and indicate it to you. If the app fails to find the remote controller, please repeat the above steps to reinitialize the pairing process.

*Please ensure the remote controller has batteries inside and is placed nearby




Connecting



Failure to connect


Platform Selection & Pairing

If the app pairing is successful, you will be able to download the relevant HID commands for the platform of your device (Windows or MacOS). After selecting the platform, you can name the remote. Press "Complete" to confirm the remote name. Then you can proceed to holding Keys 1 & 2 until you hear a "beep" sound and see green light indicating Control mode in order to pair the remote with your PC or laptop through Bluetooth.




Clear bonding information with your platform (MacOS or Windows):

If there is a situation that you want to configure other keys but the Mac OS / Windows keeps showing the loading icon and is unable to connect to Remodo X, you can clear the bonding information by pressing and holding Keys 1 & 4 until you hear the "beep" sound and see a green light indicating Control mode after which you should be able to pair the remote with your platform through Bluetooth.




Adding or Modifying Commands

In order to add additional commands or change the device/application, first switch to setup mode through following the steps on p.5, then select the remote on app home page and proceed to “Key Mapping” then press on the “+” icon next to “Key Mapping Profiles” in order to select the relevant device/application.




After selecting the relevant device/application, you can choose the key that you want to program and press on it to select between 3 options: third-party apps/services shortcuts, HID keys and Infrared device keys. The third-party apps/services shortcuts are pre-programmed shortcuts for popular apps/services that you can conveniently link to your chosen key.




Programming HID Keys

In order to add customized commands, go to “Key Mapping” and either press on “+” icon to add new key profile or press on existing profile to edit. You can select the HID keys option and select HID keyboard to customize the key in accordance to a keyboard shortcut (e.g. increase volume) by selecting the relevant keyboard commands from the given.



Adding & Controlling IR Devices

To add and control IR devices, go to “Key Mapping” and either press on “+” icon to add new key profile or press on existing profile to edit then select the key you want to link the device with and go to “Infrared Device Keys” then add the device by selecting category and brand which will prompt you test the device by pressing the “Tap Me” button. If successful, you will now be able to control the device through the relevant keys and even edit commands.



Find My Remote:

Misplaced your remote? Don't worry. Press the magnifying glass icon next to the remote on the home screen of the app which will make the remote will emit beeping sound to assist you in locating it.



Technical Specifications

Model No.	Remodo X
Bluetooth	BLE 4.2, Class 2 device
RF Operating Distance	Up to 30meters outdoor line of sight, in unobstructed environment
IR Operating Distance	Up to 10meters line of sight, in unobstructed environment
Power input	Powered by AAA x 2pcs Alkaline batteries are recommended
Operating and Storage Temp.	Operating: 0 – 40 °C Storage: -10 – 60 °C
Dimension (L x W x T)	114 x 36 x 13mm
Weight	37g (without bracket, without packaging)

Maintenance

1. Do not expose your unit to dust, strong sunlight, humidity, high temperatures or mechanical shocks.
2. Use new batteries of the recommended type and size only.
3. Do not use old and new batteries together as old batteries tend to leak.
4. To avoid chemical leaks, remove batteries from the unit if you do not intend to use the unit for an extended period of time.
5. Do not use corrosive or abrasive cleansers on your unit.
6. Use a wet water cloth to clean the soft plastic surface, do not use any detergent or cleaning agent.
7. Keep the unit dust free by wiping it with a soft, dry cloth.

Warnings:

- Do not modify the unit in any way.
- Risk of fire.
- Risk of electrical shock.
- Risk of burns.
- Do not dispose of electrical appliances and unsorted municipal waste. Use separate collection facilities. Contact your local government for information regarding the collection systems available.
- There are no user serviceable parts in this unit.

Caution:

- Risk of explosion if battery is replaced by an incorrect type.
- Dispose of used batteries according to the instructions.

Warranty

ONE-YEAR LIMITED WARRANTY: Remotec warrants this product to be free from defects in materials and workmanship under normal use and service for a period of one year from the original date of purchase from the distributor or dealer.


REMOTEC shall not be liable for:

- Damages caused by defective devices for indirect, incidental, special, consequential or punitive damages, including, inter alia, loss of profits, savings, data, loss of benefits, claims by third parties and any property damage or personal injuries arising from or related to the use of the device.
- Service trips to provide instruction on product use.
- Shipping costs for replacement products.

This warranty is limited to the repair or replacement of this product only, if the purchase date cannot be substantiated, the warranty period will begin on the date of manufacture as indicated on this product. All warranty claims must be made to Remotec appointed distributors or dealers during the applicable warranty period. This warranty gives you specific legal right and you may also have other rights which vary in each country.

Customer Service & FAQ

Please press the “question mark” on the top right of the mobile app to be directed to FAQ and feel free to drop any questions!




For further assistance, please contact Customer Service at: Customer Service Website:

<http://support.remotec.com.hk> Tel: +852 2270 9238

E-mail: info@remodo.net

Web: <https://remodo.net/remodo-x/>

Documents / Resources

 The image shows the cover of the 'Remodo X User Manual'. It features a black remote control with a silver button. The text 'Remodo X User Manual' is at the top. Below the remote, there are logos for 'App Store' and 'Google Play'. At the bottom, there are logos for 'Bluetooth' and 'InfraRED'. The version 'Version 1.0' is printed at the bottom left.	<p>Remodo X Remote Control [pdf] User Manual Remote Control, Remote, Control</p>
---	--

References

-  [Remotec](#)
-  [Remotec](#)
-  [Remodo X – Remodo Official Website](#)

Manuals+.