



## sensorswitch Push-Button SwitchPod Instruction Manual

[Home](#) » [sensorswitch](#) » sensorswitch Push-Button SwitchPod Instruction Manual 

### Contents

- [1 sensorswitch Push-Button Switc](#)
- [2 OVERVIEW](#)
  - [2.1 FEATURES](#)
- [3 Warranty](#)
- [4 ORDERING INFORMATION](#)
- [5 TYPICAL CONFIGURATIONS](#)
- [6 PROGRAMMING INSTRUCTIONS](#)
  - [6.1 \(Please read all 7 steps before programming\)](#)
- [7 SPECIFICATIONS](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)
- [9 Related Posts](#)



**sensorswitch Push-Button Switc**



## OVERVIEW

The Push-Button SwitchPod (sPODM) Series of low voltage wall stations interface with standard Sensor Switch occupancy sensors and power packs in order to implement a wide range of single and bi-level switching applications. These switch devices provide an elegant and cost effective way of deploying bi-level lighting control that meet energy and building codes without having to source special sensors or power packs.

## FEATURES

- Enables Standard Occupancy Sensors to be used for Manual On Operation
- Alternative Usage as Override Switch for Auto-On Applications
- Single Gang Decorator Style w/ either 1 or 2 On/Off Switches
- Soft-Click Push-Buttons
- Programmable w/o Removing Switch Plate
- Optional Dual Manual On Operation
- Optional Multi-way Operation
- Optional 0-10 VDC Dimming Control
- Auto return to last set level – on dimmable devices, returns to last set dim level before switched off

## Warranty

Five-year limited warranty.

This is the only warranty provided and no other statements in this specification sheet create any warranty of any kind.

All other express and implied warranties are disclaimed.

Complete warranty terms located at: [www.acuitybrands.com/support/warranty/terms-and-conditions](http://www.acuitybrands.com/support/warranty/terms-and-conditions)

**Note:** Actual performance may differ as a result of end-user environment and application.

Specifications subject to change without notice


## ORDERING INFORMATION


sPODM										Example: sPODM 347
Series		Dimming*		# of Switches/Default on Oper.		Multi-Way*		Color		Temperature / Humidity
sPODM Switchpod		[blank] None D Dimming Operation		[blank] 1 Switch / Auto On SA 2P 1 Switch/ Manual On 2 Switches (Pole 1 Manual / Pole 2 Auto) 2P 2SA 2 Switches (Both Poles Manual)		[blank] None 3X Multi-Way (e.g. 3-way)		WH White IV GY AL Ivory Gray Light Almond BK Black		[blank] Standard LT Low Temp

## TYPICAL CONFIGURATIONS


(NOTE: 18 AWG wire is recommended for all wiring)

BI-LEVEL (MANUAL ON / AUTO ON) SOLUTION w/ OCCUPANCY SENSOR: 1 GANG






### MANUAL ON w/ DIMMING & OCCUPANCY SENSOR



Note: If sensor also has dimming output (e.g., CM 9 ADC), connect sensor VIO wire to SPODM and ballast/driver VIO wire. Lowest output level always takes precedence. If no sensor is used, connect the SPODM white wire to the red wires.

### 3-WAY MANUAL ON SOLUTION w/ OCCUPANCY SENSOR



**Note 1:** SPODM (SA) 3X D units should only be used in multi-way applications with SPODM (SA) 3X units (non-dimming) as dimming levels are not communicated between devices.

**Note 2:** For multi-way configurations greater than two units, connect additional unit(s) in same manner as bottom right SPODM SA 3X unit in diagram above.

**Note 3:** If no sensor is used, connect the SPODM white wire to the red wires.

## PROGRAMMING INSTRUCTIONS

(Please read all 7 steps before programming)

1. Enter programming mode by pressing & holding upper most button until LED flashes rapidly. Release button.
2. Enter the On Mode function by pressing button twice.
3. The current On Mode setting will then be fed out in a sequence of LED flashes as indicated in the table below (e.g., one flash for Auto-On). To change the setting, proceed to step 4 before sequence repeats 10 times.
4. At any time while the switch is flashing back the current On Mode setting, interrupt it by pressing button the number of times for the new desired On Mode setting as indicated in the table below (e.g., press twice for Manual On). Switch will begin to flash back new setting as confirmation.
5. Next, while the switch is flashing back new setting, interrupt it by pressing and holding button until LED flashes rapidly. Release button.
6. As final confirmation and activation of the new setting, press button two times.
7. LED will flash twice indicating acceptance of new setting. If two flashes are not seen, repeat 7 step process.

**Note:** To exit programming mode without saving, wait for blink back sequence to repeat 10 times then return to step 1.

Function Number	Function Name	Settings (see ordering block for defaults)		
		Setting Number	Pole 1	Pole 2 (2P devices only)
2	On Mode	1	Auto-On	Manual On
		2	Manual On	Auto-On
		3 (2P devices only)	Manual On	Manual On
		4 (2P devices only)	Auto-On	Auto-On

## SPECIFICATIONS

### Electrical

- Input Ratings 12-24VAC/VDC, 5mA
- Output Ratings Sinks <20mA

### Mechanical

- Dimensions 2.74"H x 1.68"W x 1.63"D (70mm x 43mm x 41mm) – does not include ground strap
- Mounting Single-Gang Box or Low Voltage Ring
- Connection Type Low Voltage Leads

### Environmental

- Warrantied Operating Temperature -22°F to 185°F (-30°C to 85°C)
- Relative Humidity Up to 90%, Non-Condensing
- Standards/ Ratings RoHS

### General

- Standards/ Ratings CEC Title 20

Acuity Brands | One Lithonia Way Conyers, GA 30012

**Phone:** 800.535.2465 [www.acuitybrands.com/sensorswitch](http://www.acuitybrands.com/sensorswitch)

© 2014-2022 Acuity Brands Lighting, Inc.

All rights reserved. Rev. 03/08/22

## Documents / Resources



[sensorswitch Push-Button SwitchPod](#) [pdf] Instruction Manual  
Push-Button SwitchPod, Push-Button, SwitchPod

References

- [SensorSwitch | Lighting Controls](#)
- [Terms and Conditions and Warranties | Acuity Brands](#)