

Sonoff Technologies S26R2TPF Wi-Fi Smart Plug User Manual

Home » Sonoff Technologies » Sonoff Technologies S26R2TPF Wi-Fi Smart Plug User Manual

Contents

- 1 Sonoff S26R2TPF Wi-Fi Smart Plug
- **2 Product Information**
- 3 Product Usage
- **4 Operating Instruction**
- **5 Compatible Pairing Mode**
- **6 Specifications**
- **7 Product Introduction**
- 8 Wi-Fi LED indicator status
- instruction
- 9 Features
- 10 Switch Network
- 11 Factory Reset
- 12 Common Problems
- 13 Documents / Resources



Sonoff S26R2TPF Wi-Fi Smart Plug




Product Information

The Wi-Fi Smart Plug is a device manufactured by Shenzhen Sonoff Technologies Co., Ltd. It is available in different variants for different countries, including TPG(UK), TPF(DE), TPE(FR), TPB(US), TPI(AU), TPAI(CN), TPH(IL), TPN(BR), TPJ(CH), and TPL(IT). The device supports AndroidTM & iOS operating systems and has IEEE 802.11 b/g/n 2.4GHz Wi-Fi connectivity. It has a temperature range of -10~40 degrees Celsius and has a PC V0 rating. The dimensions of the device are 97.5x56x35mm.

The Wi-Fi Smart Plug has the following specifications

- Input: S26R2TPF: 250V~, 50/60Hz; S26R2TPG: 250V~, 50/60Hz; S26R2TPI: 250V~, 50Hz; S26R2TPN: 250V~, 50/60Hz; S26R2TPH: 250V~, 50/60Hz; S26R2TPE: 250V~, 50/60Hz; S26R2TPE: 250V~, 50/60Hz; S26R2TPB: 120V~, 60Hz; S26R2TPAI: 250V~, 50/60Hz; S26R2TPJ: 250V~, 50/60Hz; S26R2TPL: 250V~, 50/60Hz
- Max. load: S26R2TPF: 4000W/16A; S26R2TPG: 3250W/13A; S26R2TPI: 3750W/15A; S26R2TPN: 4000W/16A; S26R2TPH: 4000W/16A; S26R2TPL-H: 4000W/16A; S26R2TPE: 3680W/16A; S26R2TPB: 1800W/15A; S26R2TPAI: 2500W/10A; S26R2TPJ: 4000W/16A; S26R2TPL: 2500W/10A



Product Usage

To use the Wi-Fi Smart Plug, follow the steps given below:

- 1. Download the eWeLink app on your Android or iOS device.
- 2. Power on the device. During the first use, the device will enter the quick pairing mode (Touch) automatically. The Wi-Fi LED indicator will change in a cycle of two short and one long flash and release. If you want to enter this mode again, long press the manual button for about 5s until the Wi-Fi LED indicator changes in a cycle of two short and one long flash and release.
- 3. Add the device to the app by tapping on the + icon and selecting Quick Pairing. Follow the prompts on the app to complete the pairing process. If the device fails to enter the Quick Pairing Mode (Touch), try Compatible Pairing Mode. Long press the pairing button for 5s until the Wi-Fi LED indicator changes in a cycle of two short flashes and one long flash and release. Long press pairing button for 5s again until the Wi-Fi LED indicator flashes quickly. Then, select Compatible Pairing Mode on the app and enter the Wi-Fi SSID with ITEAD-****** and password 12345678. Wait until pairing completes.
- 4. Once the device is added to the app, you can control it remotely using the app. You can turn on/off the device, set schedules, and monitor power consumption, among other things.

Operating Instruction


Download APP





Android™ & iOS


Power on



After powering on, the device will enter the quick pairing mode (Touch) during the first use. The Wi-Fi LED indicator changes in a cycle of two short and one long flash and release.

The device will exit the quick pairing mode (Touch) if not paired within 3mins. If you want to enter this mode, please long press the manual button for about 5s until the Wi-Fi LED indicator changes in a cycle of two short and one long flash and release.

Add the device



Tap "+" and select "Quick Pairing", then operate following the prompt on the APP.

Compatible Pairing Mode


If you fail to enter Quick Pairing Mode (Touch), please try "Compatible Pairing Mode" to pair.

- Long press pairing button for 5s until the Wi-Fi LED indicator changes in a cycle of two short flashes and one long flash and release. Long press pairing button for 5s again until the Wi-Fi LED indicator flashes quickly.
 Then, the device enters Compatible Pairing Mode.
- 2. Tap "+" and select " Compatible Pairing Mode " on APP.
 - Select Wi-Fi SSID with ITEAD-***** and enter the password 12345678, and then go back to eWeLink APP and tap "Next". Be patient until pairing completes.

Specifications

	S26R2TPF, S26R2TPG, S26R2TPI, S26R2TPN, S26R2TPH		
Model	S26R2TPE, S26R2TPB, S26R2TPAI, S26R2TPJ, S26R2TPL, S26R2TPL-H		
	S26R2TPF: 250V~, 50/60Hz	S26R2TPE: 250V~, 50/60Hz	
	S26R2TPG: 250V~, 50/60Hz	S26R2TPB: 120V~, 60Hz	
	S26R2TPI: 250V~, 50Hz	S26R2TPAI: 250V~, 50/60Hz	
Input	S26R2TPN: 250V~, 50/60Hz	S26R2TPJ: 250V~, 50/60Hz	
	S26R2TPH: 250V~, 50/60Hz L-H: 250V~, 50/60Hz	S26R2TPL: 250V~, 50/60Hz S26R2TP	
	S26R2TPF: 4000W/16A	S26R2TPE: 3680W/16A	
Max. load	S26R2TPG: 3250W/13A	S26R2TPB: 1800W/15A	
	S26R2TPI: 3750W/15A	S26R2TPAI: 2500W/10A	
	S26R2TPN: 4000W/16A	S26R2TPJ: 4000W/16A	
	S26R2TPH: 4000W/16A 4000W/16A	S26R2TPL: 2500W/10A S26R2TPL-H:	
Operating systems	Android & iOS		
Wi-Fi	IEEE 802.11 b/g/n 2.4GHz		
Working temperature	-10°C~40°C		
Material	PC V0		
Dimension	97.5x56x35mm		

Product Introduction



Wi-Fi LED indicator status instruction

Wi-Fi LED indicator status	Status instruction	
Flashes (one long and two short)	Quick Pairing Mode	
Keeps on	Device is connected successfully	
Flashes quickly	Compatible Pairing Mode	
Flashes quickly once	Unable to discover the router	
Flashes quickly twice	Connect to the router but fail to connect to Wi-Fi	
Flashes quickly three times	Upgrading	


Features

Remotely turn on/off the device, schedule it on/off or share it with your family to control together.



Switch Network

If you need to change the network, long press the pairing button for 5s until the Wi-Fi LED indicator changes in a cycle of two short and one long flash and release, then the device enters quick pairing mode and you can pair again.



Factory Reset

Deleting the device on the eWeLink app indicates you restore it to factory setting.

Common Problems

Q: Why my device stays "Offline"?

A: The newly added device needs 1 – 2mins to connect Wi-Fi and network. If it stays offline for a long time, please judge these problems by the blue Wi-Fi indicator status:

- 1. The blue Wi-Fi indicator quickly flashes once per 2 seconds , which means that the device failed to connect your Wi-Fi:
 - 1. Maybe you have entered a wrong Wi-Fi password.
 - 2. Maybe there's too much distance between the switch your router or the environment causes interference, consider getting close to the router. If failed, please add it again.
 - 3. The 5G Wi-Fi network is not supported and only supports the 2.4GHz wireless network.
 - 4. Maybe the MAC address filtering is open. Please turn it off.
 If none of the above methods solved the problem, you can open the mobile data network on your phone to create a Wi-Fi hotspot, then add the device again.
- 2. Blue indicator quickly flashes twice per 2 seconds, which means the device has connected to Wi-Fi but failed to connect to the server.
 - Ensure steady enough network. If double flash occurs frequently, which means you access an unsteady network, not a product problem. If the network is normal, try to turn off the power and restart the device.

Shenzhen Sonoff Technologies Co., Ltd.

Documents / Resources



<u>Sonoff Technologies S26R2TPF Wi-Fi Smart Plug</u> [pdf] User Manual S26R2TPF Wi-Fi Smart Plug, S26R2TPF, Wi-Fi Smart Plug, Smart Plug, Plug

Manuals+,