


spaceti BASE-5 Sensor Gateway



spaceti BASE-5 Sensor Gateway User Manual

[Home](#) » [spaceti](#) » spaceti BASE-5 Sensor Gateway User Manual 

Contents

- [1 spaceti BASE-5 Sensor Gateway](#)
- [2 Technical parameters](#)
- [3 General safety instructions](#)
- [4 Installation and operation](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)



spaceti BASE-5 Sensor Gateway



Information about the product

Manufacturer

spaceti s.r.o. Přemyslovská 2845/43, 130 00, Prague, Czech Republic ID: 05137659, VAT: CZ05137659
support@spaceti.com www.spaceti.com

Introduction

Thank you for choosing Spaceti to help you build the office of the future. Our mission is to digitalize spaces and positively influence human interaction within buildings. We aim to increase comfort, productivity, and security while also providing an effective facility management tool. The Sensor Gateway is one of three components that make up Spaceti's technology. It is primarily used to collect data from all types of Spaceti sensors.

Package Contents

- Spaceti Sensor Gateway
- Power adaptor

Note: If any of the items are damaged or missing, please contact the retailer where you purchased the product or an authorized service agent.

Copyright and trademarks

The technical specification and all other information in this product manual (referred to just as "Manual" from here on) can change without prior announcements. Spaceti Sensor Gateway is trademarked by Spaceti s.r.o. No portion of this Manual can be reproduced in any way, nor can it be used in a paraphrased or translated form without the expressed consent of Spaceti s.r.o. All rights reserved.

Basic product information

The Spaceti Sensor Gateway ("Device") is a component of Spaceti's technology. It is a necessary component both for measuring the occupancy of workplaces and meeting rooms, as well as for measuring the environmental parameters of the environment. Spaceti's system is made up of the hardware device, a mobile application, and a web-based interface. The system requires all the parts to work correctly.

WARNING! Carefully read this Manual and save it for future use!

The manufacturer is not responsible for defects, accidents, damage, or other risks caused by not adhering to the procedures in this Manual! The Manufacturer does not guarantee the Device will work properly if it is used or handled in any way that is contrary to the recommended procedures listed in this Manual!

Technical parameters

- Power USB type C power adaptor DC 5V / 3A Output Max. 15 W
- Communication frequency 918.5 MHz Radiation output 918.5 MHz max. +14 dBm, LTE max. 23 dBm
- Operation temperature range (+5; +40) °C Relative humidity range (5; 90) %
- Weight 180 g Dimensions (105 x 75 x 66) mm
- Other PC-ABS fire retardant box (UL94V0)




Figure 1

General safety instructions

WARNING! Carefully read these instructions, memorize them, and save the instructions for future use!

Installation

- Installation can only be performed by a trained technician authorized by the Manufacturer (“Technician”).
- The Device cannot be installed in direct sunlight, close to a heat source, or a warm air duct.
- The Device requires at least 5 cm of space on all sides in order to operate correctly.

Environment

- The Device must not be used in spaces with extreme temperatures. The appropriate range is listed in the technical specifications.
- The space where the Device is located must be well ventilated, especially if the Device is installed in an enclosed or small space.
- Do not install the Device in rooms with extreme humidity or close to water, such as a damp cellar, in an aquarium, or a pool area.

Electric safety

- Use only accessories approved by the equipment manufacturer for use with the model.
- All connected accessories, especially the power adaptor, must meet the requirements of the FCC part 15 compliance for electromagnetic compatibility.

Personal safety

- Do not break the Device.
- Do not hit the Device or allow it to be struck.
- Do not clean with water or any other liquid.
- Do not place the Device into a microwave or any other tool that will warm it up.
- Do not place the Device into open flames, smoke, or other fumes.
- Do not allow the Device or the batteries to be subject to outside pressure
- Prevent contact between the Device and the batteries and mouths, ears, and eyes. Specifically, do not bite or lick the Device.

- Do not squeeze or stab the Device and prevent it from being deformed.
- Do not expose animals to the Device.

Maintenance

- Only the Technician installs, maintains, or removes the Device.
- Use dry tissues, a rag, or a duster to clean the exterior of the Device.
- Unplug before cleaning.

WARNING! Do not use any detergents, water, solvents, or other liquids or moist cleaning supplies. Be sure to prevent any liquid from leaking into the Device when cleaning the mounting! The Device must be kept out of the reach of children under the age of 12 or those with limited cognitive functions!

Use of power adaptor

- The power connector serves as “turn off” device.
- When disconnecting the device from the mains adapter, also disconnect it from the power socket.
- Do not use any damaged power adaptor.
- Make sure that AC adaptor meets the requirements of IEC60950-1/EN60950-1/UL60950-1 and approved according to the standards of the country in which it is operated.

WARNING! The Manufacturer is not responsible for any damage to the Device caused by the installation, opening, removal, or any other manipulation of the Device or its accessories by an unqualified individual! If the Device is to be transported, it must be protected in a similar way, especially protection from coming into contact with liquids. It should be mounted on the supplied covers.

FCC warning

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

ISED warning

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

Installation and operation

Installing the Device

Only an authorized Technician installs and removes the Device.

WARNING! The user is obligated to ensure the installation of the Device is permitted (especially the wireless technologies and Sub-GHz communication channels) before installation and operation or to procure permission from the authorized individual (most often the property owner or manager) to ensure that no limitations on using such technologies in the planned Device installation area are violated. The Manufacturer is not responsible for any damage caused by installing or using the Device in areas without permission or if the Device was not installed by an authorized Technician!

Operating the Device for the first time

Upon installation, the technician connects the adapter to the mains and to the device. When using the device in another place other than the initial installation location, just unplug the adapter from the outlet and from the device and just connect the device in the new location.

WARNING! If the user installs the Device without the Technician, or uses the Device at a new location, the Manufacturer is not responsible for any damages that could be caused, neither to the Device, nor in the unauthorized installation location, nor any possible health damages to individuals!

Malfunctions

If the Device ceases to work or displays any malfunctions, immediately contact the Technician or the Manufacturer.

Handling of electrical or electronic waste

WARNING! NEVER dispose of the Device or the battery in the trash!

- The Manufacturer states that mixing with normal trash can cause negative effects on the environment and human health.
- Never burn the Device or the battery.
- Never place the Device or the battery into heating equipment.
- Adhere to all general regulations in the given location when removing the used device or battery and place the battery in a designated receptacle.
- The Device will be removed by the Technician and then its parts and materials will be recycled.
- Dispose of the packaging in designated receptacles.

WARNING! Recycle! If the device will be disposed of outside the European Union, the user is obligated to ensure the Device and battery are disposed of according to the laws and regulations of the given country and to acquire information about the correct method of disposal from the authorities.

Contacts and maintenance

Contacting the Manufacturer:


EU: (+420) 800 661 133

US: (+420) 800 997 755



UK: (+420) 800 996 644

Please send any general questions to: support@spaceti.com General information and details can be found at: www.spaceti.com

Documents / Resources

 <small>Spaceti</small> <small>Spaceti sensor gateway</small> <small>User Manual</small>	spaceti BASE-5 Sensor Gateway [pdf] User Manual SHU1M1A200, 2APJ3SHU1M1A200, BASE-5 Sensor Gateway, BASE-5, BASE-5 Gateway, Sensor Gateway, Gateway, Sensor
--	--

References

-  [Spaceti | Space & Time Efficiency](#)
-  [Spaceti | Space & Time Efficiency](#)
-  [Spaceti | Space & Time Efficiency](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.