



TOSHIBA CANVIO BASICS USB-C User Manual

[Home](#) » [Toshiba](#) » TOSHIBA CANVIO BASICS USB-C User Manual 

Contents

- [1 TOSHIBA CANVIO BASICS USB-C](#)
- [2 Check the components](#)
- [3 System requirements](#)
- [4 Connecting the drive to your computer](#)
- [5 Dismount and disconnect the drive](#)
- [6 Further advise](#)
- [7 Frequently asked questions](#)
- [8 Troubleshooting](#)
- [9 TOSHIBA Support](#)
- [10 Regulatory statements](#)
- [11 Disposal of products](#)
- [12 Documents / Resources](#)
 - [12.1 References](#)
- [13 Related Posts](#)

TOSHIBA

TOSHIBA CANVIO BASICS USB-C



Introduction

Thank you for choosing our Portable Hard Drive. Please read this User's Manual carefully, as it contains all relevant information for installation, usage and maintenance of the drive, as well as security and safety advice. In case it does not behave as expected, please refer to the "Frequently Asked Questions" section at the end of this manual.

Check the components



- Canvio Basics USB-C®
- USB 3.2 Gen 1 Cable (Type-C to Micro-B)
- Support document

This User's Manual is also available for download: www.toshiba-storage.com/downloads/

Please also refer to the "Instruction Manual for Safety and Comfort" that is preloaded on this external hard drive.

System requirements

- Formatted NTFS for Windows 11 / Windows 10 / Windows 8.1
- Requires reformatting for macOS v12.0 / v11.5 / v10.15
- One free port of USB Type-C®

Installing the drive

Some information about bus-powered operation and the supplied USB cable:

- Your drive is bus-powered. Therefore, there is no need to connect an external power supply as all needed current will be supplied by the connected USB port(s).
- Passive USB hubs or USB connectors like keyboards, mice or similar products cannot be used or connected to

the drive.

- Make sure that the connectors will be inserted correctly.
- Never use pressure for connecting the cables. Check the polarity before connecting!

Connecting the drive to your computer



1. Plug the USB 3.2 Gen 1 micro-B connector into the corresponding port of the drive itself.

NOTE Requires USB Type-C® port.

2. With your computer powered on and fully booted up, plug the USB Type-C® connector into a USB Type-C® port of your computer.

Dismount and disconnect the drive

It is strongly recommended not to unplug the drive by just unplugging the cable connection as it may be that data is written to the drive at that time. Such data will be lost and the drive may be damaged physically!

Please follow the steps below for a safe dismount of the drive.

< Windows PC >

1. Click the “Hardware and Eject Media” icon.
A pop-up message box will appear listing the external devices connected to your computer.
2. Select the TOSHIBA drive to eject.
After a few seconds, you will get the notification that it is now safe to remove the device.
3. Click “OK” and you can unplug the drive now.

< Mac >

- Ctrl-click on the hard disk icon and choose “Eject”.
- OR
- Drag the hard disk icon to the trashcan. You can unplug the drive now.

Cleaning the drive case / enclosure

Before cleaning the drive, make sure that it's physically disconnected from the computer. We suggest to use standard products for cleaning it and to make sure that possible remaining liquid on the surface will be wiped off.

Further advise

For any further action of normal operation such as renaming the drive, backup data, or file management, we suggest to read your operation system user's manual.

Also for maintenance tasks such as defragmenting and optimisation we suggest to refer to the operating system user's manual.

We also strongly suggest having anti-virus software installed to protect your data against intended damage

caused by virus or trojan programs.

Frequently asked questions

1. Q: Do I need USB drivers for Windows?

A: No, they are already available with your operating system.

2. Q: Can I boot my system from the drive?

A: No, because Windows does not support booting from external hard drives.

3. Q: Why doesn't the drive need a fan?

A: The drives are designed to have optimal heat dissipation, and therefore no fan is required. This results in a near silent operation.

4. Q: Why is the capacity of my drive (as shown in Windows) lower than the drives actual stated capacity?

A: This difference can be explained because of the different methods of calculating the capacity.

Hard drive manufacturers calculate on the decimal system, while the operating system calculates in the binary system.

Example decimal:

1TB = 1000GB

1GB = 1000MB = 1 000 000KB = 1 000 000 000 bytes

Example binary:

1GB = 1024MB = 1 048 576KB = 1 073 741 824 bytes

As a result, a 1TB (decimal) hard disk appears in Windows to have just 931GB (binary).

5. Q: Can I use my drive to copy an operating system from one computer to another?

A: No, you must follow the operating system supplier instructions for installation. A simple copy does not work.

Troubleshooting

My computer does not recognize the disk drive at all.

- Make sure all of your connections are secure.
- If your drive is connected via a USB hub, make sure that it has its own power supply.
- If using an add-on card, make sure it is working properly and update the software/firmware.

Is it dangerous if the drive feels warm whilst in operation?

A: This is normal, and therefore not dangerous.

The drive gives me a "Device cannot start."

A: Two possible reasons. It is either a power problem and you should check the connections, or the drive has a malfunction and requires service.

I cannot see my drive in "My Computer/This PC", but it does appear in the Device Manager.

A: Follow these instructions:

1. Right-click "My Computer/This PC".
2. Select "Manage" in the pop-up menu.
3. Select "Disk Management".

You should see a list of available storage devices.

4. Check whether your drive is listed.
5. Right-click the right hand box and select "Delete Partition" in the pop-up menu.
6. Right-click the box and select "Create New Partition" in the pop-up menu.
7. Then select "Primary Partition" in the partition wizard window. Click next.
8. A drive letter will be displayed, which you can change. Click next.

NOTE When you format the drive all the data on your drive will be deleted.

9. Confirm to format the drive.

As I try to format the drive, I receive the message "Could not complete format".

A: This can be caused by formatting the drive with FAT file system. Try the "NTFS" file system. This should solve the problem.

TOSHIBA Support

Need help?

Please contact TOSHIBA's hard drive and storage products support page: www.toshiba-storage.com/support
For warranty claims, please check: www.toshiba-storage.com/warranty-claims

Regulatory statements

CE Compliance

This product is CE marked in accordance with the requirements of the applicable EU Directives. Responsible for CE marking is Toshiba Electronics Europe GmbH, Hansaallee 181, 40549 Düsseldorf, Germany.

UKCA compliance

This product is UKCA marked in accordance with the requirements of the applicable UK Standards. Responsible for UKCA marking is Toshiba Electronics Europe GmbH-UK branch, 1 Princes Road, KT13 9TU Weybridge Surrey, UK.

Working Environment

The Electromagnetic Compliance (EMC) of this product has been verified typically for this product category for a so-called Residential, Commercial & Light Industry Environment. Any other working environment has not been verified by Toshiba and the use of this product in these working environments is maybe restricted or cannot be recommended. Possible consequences of the use of this product in non-verified working environments can be: Disturbances of other products or of this product in the nearby surrounding area with temporary malfunction or data loss/ corruption as result. Example of non-verified working environments and related advices:

- Industrial environment (e. g. where 3-phase 380V mains is being used mainly): Danger of disturbances of this product due to possible strong electromagnetic fields especially near to big machinery or power units.
- Medical environment: The compliance to the Medical Product Directive has not been verified by Toshiba, therefore this product cannot be used as a medical product without further verification. The use in usual office environments e.g. in hospitals should be no problem if there is no restriction by the responsible administration.
- Automotive environment: Please search the owner instructions of the related vehicle for advice regarding the use of this product (category).
- Aviation environment: Please follow the instructions of the flight personnel regarding restrictions of use.

Additional Environments not Related to EMC

- Outdoor use: As a typical home/office equipment this product has no special resistance against ingress of moisture and is not strong shock proofed.

- Explosive atmosphere: The use of this product in such a special working environment (Ex) is not allowed.

The following information is only valid for the EU-member States:

REACH – Compliance Statement

Toshiba will meet all REACH (Registration, Evaluation, Authorization and Restriction of Chemicals) requirements and is committed to providing customers with information about the chemical substances in our products according to REACH regulations.

Disposal of products

The use of the symbol indicates that this product may not be treated as household waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

The following information is valid only for Turkey:

Compliant with AEEE Regulation.

Notices

©2022 TOSHIBA Electronics Europe GmbH. All rights reserved.

TOSHIBA reserves the right to make technical changes. TOSHIBA assumes no liability for damages incurred directly or indirectly from errors, omissions or discrepancies between this product and the documentation. The Toshiba name and its logos are registered trademarks of Toshiba.

macOS is a trademark of Apple Inc.

USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.

Other company names, product names, and service names may be trademarks of their respective companies.



Product specifications, configurations, colors, components and services are subject to change without notice.

One Terabyte (TB) means one trillion bytes. Total available capacity will vary based on the operating environment, and your results and storage capacity will vary accordingly. A computer operating system, however, reports storage capacity using powers of 2 for the definition of 1TB = 2⁴⁰ = 1 099 511 627 776 bytes and therefore shows less storage capacity.

NOTE

- When using this product, use the provided USB cable to connect it directly to the USB port.
- If sufficient power is not supplied via the USB port, the product will not function.
- Depending on the specifications of the device you are connecting to, the transfer speed may be that of USB 2.0. For details, refer to the manual of the device you are connecting to.
- As a precaution against losing data stored on this product, be sure to regularly back up as much of your data as possible on another storage device.

Documents / Resources

 <p>User's Manual CANVIO BASICS USB-C*</p> <p>EN HR RU CS HU SV DE IT SK DA NL SL ES NO TR FI PL AR FR PT UK EL</p> 	<p>TOSHIBA CANVIO BASICS USB-C [pdf] User Manual CANVIO BASICS USB-C, BASICS USB-C</p>
--	--

References

- [**T** EMEA Region – Toshiba Storage Solutions](#)
- [**T** Downloads & Product Archive - EMEA Region – Toshiba Storage Solutions](#)
- [**T** Support - EMEA Region – Toshiba Storage Solutions](#)
- [**T** Warranty - EMEA Region – Toshiba Storage Solutions](#)

Manuals+.