Home » Support » A3002RU FTP instal

A3002RU FTP instal

Contents

- 1 A3002RU FTP instal
- 2 DOWNLOAD
- **3 Related Posts**

A3002RU FTP instal

It is suitable for: A3002RU

Application introduction: File server can be build quickly and easily via the USB port applications so that file upload and download can be more flexible. This guide introduces how to configure FTP service via the router.

STEP-1:

Stores the resource you want to share with others into the USB flash disk or hard drive before you plug it into the USB port of the router.

STEP-2:

2-1. Connect your computer to the router by cable or wireless, then login the router by entering http://192.168.0.1 into the address bar of your browser.



Note: The default access address varies depending on the actual situation. Please find it on the bottom label of the product.


2-2. User Name and Password are required, by default both are admin in lowercase letter. Click LOGIN.

USER LOGIN

LOGIN


STEP-3:

Set the FTP server account password




STEP-4: Access the FTP server by local network


4-1. Please open the web browser and type in address **ftp://LAN IP**, press enter. Here the IP address of the router is **192.168.0.1**.



4-2. Enter the User name and password that you have set before, and then click Log On.




4-3. You can visit the data in the USB device now.




STEP-5: Access the FTP server by external network.


5-1. You can also access the FTP server by external network. Please type in address **ftp://wan IP** to access to it. Here the WAN IP of the router is **10.8.0.19.**



5-2. Enter the User name and password that you have set before, and then click Log On.



5-3. You can visit the data in the USB device now.



Notes:

If the FTP server can't take effect immediately, please wait a few minutes.

Or restart the service by clicking stop/start button.

DOWNLOAD

A3002RU FTP instal – [Download PDF]

Manuals+,