

How to use Reboot schedule?

Contents

- [1 How to use Reboot schedule?](#)
- [2 DOWNLOAD](#)
- [3 Related Posts](#)


How to use Reboot schedule?

It is suitable for: N100RE, **N150RH, N150RT, N151RT, N200RE, N210RE, N300RT, N301RT , N300RH, N302R Plus, A702R, A850R, A3002RU**

Application introduction: The schedule function allows you to setup the time that the router will reboot automatically. What's more, it allows you to setup the time WiFi on and off while by the other times beyond this period WiFi will be off. It is very convenient for users who often access the Internet very regularly.

STEP-1:


Connect your computer to the router by cable or wireless, then login the router by entering http://192.168.0.1 into the address bar of your browser.



Note:The default access address varies depending on the actual situation. Please find it on the bottom label of the product.

STEP-2:


User Name and Password are required, by default both are **admin** in lowercase letter. Click **LOGIN**.



STEP-3: Check Time Zone Setting

Before you configure the schedule, you should make sure that the NTP Server is enabled.

3-1. Click **System->Time Zone Setting** in the sidebar.



3-2. Choose Enable NTP and click Apply.

5bd972d12e1fa.png

STEP-4: Reboot Schedule Setup

4-1. Click **System->Reboot Schedule** in the navigation menu.

5bd973fd1ec1e.png

4-2. In the schedule interface, you can setup the time when the router will reboot time.

For Example:

5bd9742a15388.png

DOWNLOAD

How to use Reboot schedule – [[Download PDF](#)]
