



wallbox Open Charge Point Protocol for Communication User Manual

[Home](#) » [wallbox](#) » wallbox Open Charge Point Protocol for Communication User Manual 

Contents

- 1 wallbox Open Charge Point Protocol for Communication
- 2 Overview
- 3 Terms and Conventions
- 4 Part Number Activation
- 5 Charge Point Setup
- 6 myWallbox Account
- 7 Network Connection
- 8 OCPP Parameters Setup
 - 8.1 Wallbox App
- 9 myWallbox Portal
- 10 OCPP Connection Status
- 11 myWallbox App
 - 11.1 Chargers' List
 - 11.2 Chargers' Details
- 12 OCPP Functionalities
- 13 How to Use the Charger
- 14 OCPP and myWallbox
- 15 OCPP and myWallbox functionalities Compatibility
 - 15.1 myWallbox Portal
- 16 Connection to myWallbox in a VPN scenario
- 17 Troubleshooting
- 18 Service
- 19 Documents / Resources
 - 19.1 References
- 20 Related Posts




wallbox Open Charge Point Protocol for Communication



Overview

The OCPP is a standard and open protocol for communication between Charge Points and a Central System where a Charge Point Operator can, among others, monitor the status of the Charge Points, authorize who is allowed to charge or perform remote actions like to stop an ongoing transaction.



Terms and Conventions

- **CP:** The Charge Point is the physical system where an electric vehicle can be charged.
- **CPO:** The Charge Point Operator manages a set of CPs using a Central System
- **CS:** The Central System that manages Charge Points and has the information for authorizing users for using its Charge Points
- **OCPP:** Open Charge Point Protocol
- **VPN:** “Virtual Private Network”

Part Number Activation

OCPP is only available in:

- Chargers with OCPP selected in the “version” section of the part number.

Charger	Model	Cable	EVC	Power	Version	Custom	Revision
Pulsar Plus NA	PUP1	U – 25 ft	1 – Type 1	5 – 9.6 kW 6 – 11.5 kW	C- Hardwired + OCPP G – NEMA 14-50P +OCPP	002-Matte Black	–

You can know more about OCPP at:

<https://support.wallbox.com/na/knowledge-base/datasheets-pulsar-plus/>

Charge Point Setup

To achieve the OCPP connection between the Charge Point and the Central System, the Charge Point administrator shall set up the network connection and the OCPP parameters using myWallbox App or Portal. Wallbox is NOT responsible for any unexpected performance of the Central System if it has failed to successfully pass the Factory Acceptance Test between both parties.

If the Central System has failed to pass the Factory Acceptance Test, please contact: sales@wallbox.com

myWallbox Account

You can find all the instructions to use myWallbox App or Portal at: <https://support.wallbox.com/na/knowledge-base/mywallbox-overview-na/>

Network Connection

To establish a connection between the Charge Point and the Central System it is necessary to connect the Charge Point to the network using the Wi-Fi connection.

You can find all the instructions at: <https://support.wallbox.com/na/knowledge-base/connecting-your-charger-to-your-wi-fi-network/>

OCPP Parameters Setup

Wallbox App

To complete the OCPP setup using myWallbox App perform the following steps:




1. Log in to the myWallbox App.


The Wallbox app is available on PlayStore and AppStore.




2. Add the charger to your account.




3. Access to the charger's screen.



4. Select the required charger. Review the manuals, if required.



5. Enter the charger status screen and click the configuration button.




6. Go into the OCPP configuration menu.

Note: If the charger is not compatible with OCPP, the OCPP button will not be displayed.



7. Set the OCPP parameters and press the “SAVE” button.

- Enable: On / Off switch
- URL: Central System connection endpoint (required field)
- Charge Point Identity: Charge point ID (required field)
- Accept the terms and conditions (required field)




Note: The charger will automatically reboot and new configuration will be applied.


myWallbox Portal

To complete the OCPP setup using myWallbox portal perform the following steps:

1. Log in to the myWallbox portal and access the charger's page
2. Select the required charger and ensure it's connected to the network.



3. Enter the charger status page and click the OCPP tab.



Note: If the charger is not compatible with OCPP, the OCPP tab will not be displayed.

4. Set the OCPP parameters and press the "SAVE" button.

The screenshot shows the 'myWallbox Portal' interface. On the left is a green sidebar with navigation links: Family, Chargers, Statistics, Users, Payment, and Support. The main content area is titled 'PULSAR PLUS' and has tabs for DEVICE DETAIL, USERS, SESSIONS, LOCATION, PROTECTION, PAYMENTS, and OCPP. The OCPP tab is active, showing a toggle switch labeled 'ENABLED'. Below this is a 'websocket connection' section with two input fields: 'URL' containing 'ws://test' and 'CHARGE POINT IDENTITY' containing 'TEST'. A green 'SAVE' button is at the bottom of the form. The footer includes the Wallbox logo, copyright information, and social media links.

- Enable: On / Off
- URL: Central System connection endpoint (required field)
- Charge Point Identity: Charge point ID (required field)
- Accept the terms and conditions (required field)

Note: The charger will automatically reboot and new configuration will be applied.

OCPP Connection Status

The status of the OCPP connection between the charger and the Central System is shown in myWallbox App and Portal as:



The OCPP is activated and the charger is connecting to the Central System




The charger is connected through OCPP to the Central System




The Charge Point can not establish the connection with the Central System


myWallbox App



OCPP Connecting




OCPP Connected



OCPP Connection Error

Chargers' List




1. OCPP Connecting




2. OCPP Connected




3. OCPP Connected




Chargers' Details




1. OCPP Connected



2. OCPP Connecting



3. OCPP Connection Error





OCPP Functionalities





Pulsar Plus NA implements the beneath OCPP 1.6j Core profile functions as described in the “OCPP 1.6 Edition 2” specification:

- Core profile
- Local Authorization management
- Remote firmware update
- Remote trigger
- Smart charging

How to Use the Charger



Action	Pulsar Plus
Charge point will be locked while available	
Show your authorized RFID card to the RFID reader or unlock the charger with the CP O App	App
Once authorized, the charger will unlock	
Connect your EV charging cable to the Charge Point	N/A

Connect your EV cable to the EV	
Charge process will start	
Use the same RFID card, or the CPO App, to stop the charging process	
Disconnect your EV cable from the Charge Point and from the EV	

Notes:

- Other procedures could be defined by your Charge Point Operator.
- Mifare UID shall be introduced in Central System's authorization whitelist as little-endian and no separators.

OCPP and myWallbox

To keep aligned with the OCPP specification, some Wallbox functionalities are not available when OCPP is enabled. Non-conflicting functionalities will always remain available at myWallbox App and Portal. myWallbox cloud will continue gathering all the information regarding the Charge Point status and usage for a faster and better after sales service as well as managing the remote updates of the Charge Point.

Wallbox functionalities not available when OCPP is enabled:

Some of the myWallbox functionalities will still be available when OCPP is activated. They can be performed by the Charge Point Operator (CPO) though the myWallbox App or Portal:

- Charger status monitoring
- Anonymous charging sessions
- Set Power Sharing
- Set the current limit
- Update the charger software

- Restart (charger reboot)
- Restore (factory conditions)
- Set charging schedules
- Set TN/TT Ground system


Note: These features will not be available if the network connection is in a VPN.

Note: Wallbox functionalities will remain available according to your myWallbox plan: “Basic”, “Standard” and “Business”.

1. The charger status screens for OCPP not activated and activated




2. Advanced options setup




OCPP and myWallbox functionalities Compatibility

myWallbox Portal

1. The charger status screens for OCPP not activated and activated.





Find frequently asked questions at: <https://support.wallbox.com/article-tags/faqs/>

Connection to myWallbox in a VPN scenario

In order to keep all myWallbox features available in a VPN scenario, including among others remote diagnostics and remote software updates, the CPO SHALL allow charger connection to myWallbox Cloud by opening:

- Domains: *.wall-box.com
- Ports: 443 and 80
- Access: Outbound

Troubleshooting

OCPP connection status remains in “Connecting”

Check network connection status and OCPP parameters setup

Service

Need more assistance? Contact Wallbox customer service:

(888) 787-5780

support.wallbox.com/na

www.wallbox.com

service.na@wallbox.com

Documents / Resources

	<p>wallbox Open Charge Point Protocol for Communication [pdf] User Manual Open Charge Point Protocol, Communication, Open Charge Point Protocol for Communication</p>
---	---

References

- [🏠 Home - Wallbox Academy](#)
- [🌐 Wallbox | Smart, electric car charging stations](#)
- [📄 articles Archives - Wallbox Academy DropDown_small DropDown_small DropDown_small DropDown_small Icon_twitter Icon_linkedIn](#)
- [🔌 Connecting to your charger via Bluetooth - Wallbox Academy Icon_twitter Icon_linkedIn](#)
- [📄 Datasheet: Pulsar Plus - Wallbox Academy Icon_twitter Icon_linkedIn](#)
- [🔌 myWallbox Overview - Wallbox Academy Icon_twitter Icon_linkedIn](#)