

Yealink MVC940-C5-008 Microsoft Teams Rooms System



# Yealink MVC940-C5-008 Microsoft Teams Rooms System User Guide

[Home](#) » [Yealink](#) » Yealink MVC940-C5-008 Microsoft Teams Rooms System User Guide 

## Contents

- [1 Yealink MVC940-C5-008 Microsoft Teams Rooms System](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Package Contents](#)
- [5 Install MVC940-C5-008](#)
- [6 Connect MVC940-C5-008](#)
- [7 Initial Setup](#)
- [8 Features](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)

# Yealink

Yealink MVC940-C5-008 Microsoft Teams Rooms System



## Product Information

### Specifications

- Model: MVC940-C5-008
- Operating System: Microsoft Windows 10 IoT Enterprise Edition
- Features: Wireless Sharing, Camera Position Control, RoomSensor Pairing
- Compatibility: Teams Room Accessories
- Maximum RoomSensor Pairing Distance: 20m

### Product Usage Instructions

#### Installation

Follow the steps provided in the user manual to install the MVC940-C5-008.

#### Connection

Connect the necessary components as described in the manual.

#### Initial Setup

Press the power button on the MCore Pro to load the operating system. Follow on-screen instructions for setup.

#### Wireless Sharing

1. Connect the WPP30 to the USB port of the MTouch E2.
2. Pair the devices, indicated by LED colors.
3. Connect the paired WPP30 to your PC's USB-A/USB-C port.
4. Press the presentation button on WPP30 to share the full screen.

#### Camera Position Control

Access the Camera Control page by tapping More. Follow the instructions to control the UVC84 camera position.

#### RoomSensor Pairing

1. Switch account to Admin and open Yealink RoomConnect Software.
2. Go to MTouch Plus > Sensor and add a sensor.
3. Select the right sensor to pair, following on-screen prompts.
4. Ensure the distance between MTouch Plus and RoomSensor is within 20m for successful pairing.

## **Frequently Asked Questions (FAQ)**

- **Q: How do I find more information about compatible devices?**

A: Please refer to the Teams Room Accessories Compatibility Lists for information on compatible devices and their maximum numbers.

For the operation video, please refer to [MVC940-C5-008 Unboxing](#).


## **Minimum Requirements**

- An audio (speaker & microphone) system (purchase separately).
- A display connected to MCore Pro (not included).
- A Microsoft Teams Rooms or Skype® for Business account (not included).
- Wired network environment (not included).

## **Package Contents**




UVC84




(7.5m, 24.60ft)

CAT5e UTP (RJ45 - RJ45) Cable




(2.5m, 8.20ft)

USB 2.0 (A - B) Cable



(3.5m, 11.48ft)

Power Adapter (48V/0.7A)



Mounting Bracket



× 4

Φ 6 \* 30 mm, white, Polyamide



× 4

4\*30 FAHOZN3+ (+)




× 5

1/4" -20 UNC



× 2

M3\*5.8KM0ZN3+



VCR20 Remote Control



× 5

(20 \* 200 mm)

Cable Ties




Quick Start Guide

## UVC84 Package\*2




MCore Pro



× 3

(1.8 m, 5.91 ft)

HDMI Cable




(2.1m, 6.89ft)

Power Adapter (19V/4.74A)



(WH-85\*3.0mm)

Screwdriver



(150\*117\*15mm)

Mounting Bracket



× 4

Φ 6 \* 30 mm, white, Polyamide



× 4

4\*30 FAHOZN3+ (+)



× 2

3\*6PMOZN3+



× 2

(W25.4\*L50mm,3M)  
Velcro



Quick Start Guide

## MCore Pro Package



MTouch Plus



(7.5m, 24.6ft)

CAT5e UTP (RJ45 - RJ45) Cable




(1.2m, 3.94ft)

USB 3.1 (C - C, HDMI) Cable



(WH-85\*3.0mm)

Screwdriver



(207.44 mm \* 126.99 mm)

Mounting Bracket



× 4

Φ 6 \* 30 mm, white, Polyamide



× 4

4\*30 FAHOZN3+ (+)



× 4

2.5\*9.0FMHZN(+)



× 2

M8\*60mm,SUS304



(M8, Φ 30\*T2mm, SUS304)

Washer



× 2



× 2

(M8,SUS304)

Wing Nuts



(L200\*W62.5\*T1.2mm)

Double-Coating Tape



Lock cable buckle



× 4

2.5\*8.0PAHOZN3+ (+)




Quick Start Guide

## MTouch Plus Package




AVHub




(7.5m, 24.60ft)

CAT5e UTP (RJ45 - RJ45) Cable




(2.5m, 8.20ft)

USB 3.0 (A - B) Cable



(3.8m, 12.47ft)

Power Adapter (48V/2A)



(150\*117\*15mm)

Mounting Bracket



× 4

Φ 6 \* 30 mm, white, Polyamide



× 4

4\*30 FAHOZN3+ (+)



× 8

3\*8PMOZN3+



× 2

Mounting Ears



× 2

(W25.4\*L50mm,3M)


Velcro



× 5

(20\*200mm)

Cable Ties



Quick Start Guide

## AVHub Package



RoomSensor



× 2

Φ 6 \* 30 mm, white, Polyamide



× 2

4\*30 FAHOZN3+ (+)



× 5


PIR Blocking Sticker



3M Adhesive Tape



CR123A,3V




Quick Start Guide

## RoomSensor Package



USB 3.1 Type-C (with USB2.0  
AM to TYPE-CF adapter)




Quick Start Guide

## WPP30 Package

### Install MVC940-C5-008

- MCore Pro supports: mount on the wall, mount on the TV, stick to the table.
- MTouch Plus supports: put on a table, paste on a table, fixed on a table, mount on the wall.
- UVC84 supports: put on a flat surface, mount on top of a display, mount on the wall, mount on the ceiling, mount on the TV mount.
- AVHub supports: mount on the wall, stick under the table, put on the desk, mount on the rack.
- RoomSensor supports: mount on the ceiling, mount on the wall.
- Install and deploy the accessories in the system according to the environment and actual needs. For how to install and deploy, please refer to the quick start guide of each product.

### Connect MVC940-C5-008



## NOTE

- When starting up the system for the first time, you need to connect a mouse to complete the initial configuration. We recommend using the wireless mouse and keyboard kit.
- When you connect the UVC84/UVC86/MSpeaker II directly to the AVHub, the total number of connections must be no more than 4 devices. If the total number of connections exceeds 4 devices, you need to connect a PoE switch (the PoE switch must meet the 802.3 AT (PoE+) standard). We recommend using Yealink RCH40.
- Not included accessories requirements:
  - **Display:** Resolution of 1080p or higher and with an HDMI port.
  - **PC:** Equipped with HDMI or USB-C (support DP protocol) Port.
  - **Ethernet cable:** CAT5e or higher ethernet cable.
  - **HDMI:** Standard HDMI cable.

## Initial Setup

1. Press the power button on the bottom left of MCore Pro, and the Microsoft Windows 10 IoT Enterprise Edition operating system will be automatically loaded after starting MCore Pro.

**NOTE:** When starting up the system for the first time, you need to connect a mouse to complete the initial configuration. We recommend using the wireless mouse and keyboard kit. After the system is initialized, you can use MTouch E2 to complete the system login and settings, and the device will automatically start the Microsoft Teams conference system application and enter the setting page.



2. Select the check box on the EULA page, and then tap Next.
3. Enter the account, the password on the Account page, and then tap Next. Supports Microsoft Teams Rooms or Skype® for Business accounts.
4. On the Advanced page, configure the domain and tap Next.
5. Tap Finish to complete the setup wizard.


## Features

### Wireless Sharing



1. Connect the WPP30 to the USB port of the MTouch E2.  
When pairing, the LED indicator of WPP30 is orange. When the pairing is successful, the LED indicator turns green breathing light.
2. Connect the paired WPP30 to the USB-A/USB-C port on your PC.
3. On the WPP30, press the presentation button to share the full screen.

### Control UVC84 Camera Position

1. Tap More >  to enter the Camera Control page.

### Pair with a RoomSensor

1. Switch the account from Skype to Admin.
2. Open Yealink RoomConnect Software from the Desktop.
3. Go to MTouch Plus > Sensor.
4. Add sensor. Select the right sensor to pair.

Remove the back cover of RoomSensor, and you will see its name on the top. Then select accordingly.


## NOTE

- A MTouch Plus can be paired with one RoomSensor at most.
- The distance between MTouch Plus and RoomSensor needs to be within 20m.

Supported Accessories

For the compatible devices and the maximum number of compatible devices, please refer to [Teams Room Accessories Compatibility Lists](#).

Documents / Resources

	<p><a href="#">Yealink MVC940-C5-008 Microsoft Teams Rooms System</a> [pdf] User Guide</p> <p>MVC940-C5-008, MCore Pro, MTouch Plus, UVC84, AVHub, RoomSensor, MVC940-C5-008 Microsoft Teams Rooms System, MVC940-C5-008, Microsoft Teams Rooms System, Teams Rooms System, Rooms System, System</p>
---	--

References

- [Yealink Support](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.