



ZYXEL EX5512-T0 AX6000 WiFi6 Multi Gigabit Ethernet Gateway User Guide

[Home](#) » [ZYXEL](#) » ZYXEL EX5512-T0 AX6000 WiFi6 Multi Gigabit Ethernet Gateway User Guide 

Contents

- [1 ZYXEL EX5512-T0 AX6000 WiFi6 Multi Gigabit Ethernet Gateway](#)
- [2 Package Contents](#)
- [3 Hardware Installation](#)
- [4 App Management](#)
- [5 FCC STATEMENT](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)



ZYXEL EX5512-T0 AX6000 WiFi6 Multi Gigabit Ethernet Gateway



A member of the Zyxel MPro Mesh solution family.

- MPro Mesh Solution:
- EX5512-TO
- WX5512-TO
- MPro Mesh App
- Visit www.zyxel.com/us/en for updated information.

Package Contents



EX5512-TO



Power Adapter



Ethernet Cable




Quick Start Guide

US Importer


- Zyxel Communications, Inc
- 1130 North Miller Street Anaheim, CA 92806-2001 <https://www.zyxel.com/us/en/>
- Copyright ©2022 Zyxel and/or its affiliates. All Rights Reserved.

Hardware Installation

1. Use the included blue cable to connect the xDSL/cable/fiber modem's LAN port to the EX5512-T0's WAN port as illustrated.




2. Connect the power adapter to the EX5512-T0 and wait for 2 minutes. Check the EX5512-T0 front panel.



3. The Power  /Internet  /WAN  /2.4G  /5G  LEDs will light up green as below when the setup is complete.

Note: If the lights do not turn on green, please retry O 20 or contact your service provider for assistance.



POWER	Green On - Power is on. Blinking - Starting up. Red On - System failure. Blinking - Upgrading firmware.
INTERNET	Green On - Internet is ready. Blinking - Transmitting/receiving internet data. Red On - Attempt to get an IP address failed.
WAN	Green On - Link up. Off - Link down.
LAN	Green On - Link up. Off - Link down.
USB	Green On - Link up. Off - Link down.
2.4G	Green On - 2.4GHz WiFi is ready. Blinking - Transmitting/receiving data.
5G	Green On - 5GHz WiFi is ready. Blinking - Transmitting/receiving data.

WiFi Connection A or B

- The label on the side of the EX5512-TO provides 2 ways to connect your wireless device to WiFi:
- Method A: Scan QR code or Method B: Using SSID


Method A: SCAN QR code to connect WiFi

1. Check the QR code on the EX5512-TO'S Side label, and use your wireless device to scan this QR code.
2. After scanning the QR code, join this SSID and you can surf the internet.



Using the SSID method to connect WiFi

1. The WiFi SSID is on the EX5512-TO's side label
2. On your wireless device, find this SSID and enter the WiFi Password on your wireless clients and you can surf the internet.




App Management

1. After successfully surfing the internet, please download the MPro Mesh app to your wireless device to manage your MPro Mesh.



2. Open this app and enter the EX5512-TO's serial number. The serial number is on the bottom label as below.




3. Use this app to enjoy the following features:

- Remote Management
- View Home Devices
- Guest Wi-Fi
- Manage Home Wi-Fi Name
- Internet Instant Block
- Add Mesh Extender
- Push Notification

Adding a Wireless Extender

WPS button: If you have a wireless extender you want to add to your EX5512-T0's WiFi network, press the EX5512-T0 button once, and press the WPs button on your extender within 120 seconds to start the WPS process.



Safety Warnings

- DO NOT use this product near water, for example, in a wet basement or near a swimming pool
- DO NOT expose your device to dampness, dust or corrosive liquids.
- DO NOT store things on the device.
- DO NOT install, use, or service this device during a thunderstorm. There is a remote risk of electric shock from lightning
- Connect ONLY Suitable accessories to the device.
- DO NOT open the device or unit. Opening or removing covers can expose you to dangerous high voltage high temperature points or Other risks.
- ONLY qualified service personnel should service or disassemble this device. Please contact your vendor for further information.
- Make sure to connect the cables to the correct ports.
- Place connecting cables carefully so that no one will step on them or stumble over them.
- Always disconnect all cables from this device before servicing or disassembling.
- Please use the provided or designated connection cables/power cables/ adaptors. Connect it to the right

supply voltage (for example, 110V AC in North America or 230V

- AC in Europe). If the power adaptor or cord is damaged, it might cause electrocution. Remove it from the device and the power source, repairing the power adapter or cord is prohibited. Contact your local vendor to order a new one.
- DO NOT remove the plug and connect it to a power outlet by itself; always attach the plug to the power adaptor first before connecting it to a power outlet
- DO NOT allow anything to rest on the power adaptor or cord and do NOT place the product where anyone can walk on the power adaptor or cord.
- DO NOT use the device outside, and make sure all the connections are indoors. There is a remote risk of electric shock from lightning
- **CAUTION:** Risk of explosion if battery (on the motherboard) is replaced by an incorrect type. Dispose of used batteries according to the instructions. Dispose of them at the applicable collection point for the recycling of electrical and electronic equipment. For detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the store where you purchased the product
- DO NOT obstruct the device ventilation slots, as insufficient airflow may harm your device.
- For example, do not place the device in an enclosed space such as a box or on a very soft surface such as a bed or sofa. The following warning statements apply, where the disconnect device is not incorporated in the equipment or where the plug on the power supply cord is intended to serve as the disconnect device,
- For permanently connected devices, a readily accessible disconnect device shall be incorporated external to the equipment for pluggable devices, the socket-outlet shall be installed near the equipment and shall be easily accessible.
- **Caution!** The RJ-45 jacks are not used for telephone line connection.

FCC STATEMENT

The following information applies if you use the product within the USA

The device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device. This device has been tested and complies with the specifications for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which is found by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the measures following: reorient or relocate the receiving antenna, increase the separation between the devices, connect the equipment to an outlet other than the receiver's, consult a dealer or an experienced radio/TV technician for assistance. This device meets all the other requirements specified in Part 15E, Section 15.407 of the FCC Rules. The following information applies if you use the product with RF function within the USA.

FCC Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must be at least 20 cm from the user and must not be co-located or operating in conjunction with any other antenna or transmitter. FCC regulations restrict the operation of this device to indoor use only.

CANADA

The following information applies if you use the product within Canada area

Innovation, Science and Economic Development Canada ICES statement

CAN ICES-003(6)/ NME-003(6)

Innovation, Science and Economic Development Canada RSS-GEN & RSS-247 statement

- This device contains licence-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).
- Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device
- This radio transmitter (2468C-EX5512T0) has been approved by Innovation, Science and Economic Development Canada to operate with the antenna types listed below, with the maximum permissible gain indicated. Antenna types not included in this list that have a gain greater than the maximum gain indicated for any type listed are strictly prohibited for use with this device

Antenna information

MODEL NAME	TYPE	MANUFACTURER	GAIN	CONNECTOR
56-001-000240Z	Dipole	M.gear	2.6 dBi (2.4~2.4835 GHz)	ipex (MHF)
56-001-000241Z	Dipole	M.gear	3.3 dBi (2.4~2.4835 GHz)	ipex (MHF)
56-001-000247Z	Dipole	M.gear	3.1 dBi (2.4~2.4835 GHz)	ipex (MHF)
56-001-000242Z	Dipole	M.gear	3.2 dBi (2.4~2.4835 GHz)	ipex (MHF)
56-001-000243Z	Dipole	M.gear	4.0 dBi (5.15~5.895 GHz)	ipex (MHF)
56-001-000244Z	Dipole	M.gear	3.2 dBi (5.15~5.895 GHz)	ipex (MHF)
56-001-000245Z	Dipole	M.gear	4.2 dBi (5.15~5.895 GHz)	ipex (MHF)
56-001-000246Z	Dipole	M.gear	3.4 dBi (5.15~5.895 GHz)	ipex (MHF)

For indoor use only.

- If the product with 5G wireless function operating in 5150-5250 MHz and 5725-5850 MHz, the following attention must be paid,
- The device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.
- For devices with detachable antenna(s), the maximum antenna gain permitted for devices in the band 5725-5850 MHz shall be such that the equipment still complies with the e.i.r.p. limits as appropriate; and
- Where applicable, antenna type(s), antenna models(s), and the worst-case tilt angle(s) necessary to remain compliant with the e.i.r.p. elevation mask requirement set forth in
- Section 6.22.3 of RSS 247 shall be clearly indicated.
- If the produce with 5G wireless function operating in 5250-5350 MHz and 5470-5725 MHz, the following attention must be paid.
- For devices with le ar na(s), the kimum antenna gain nitted for devices in the bands 5250-535 MHz and 5470-5725 MHz shall be such that the equipment still complies with the e.i.r.p. limit

Informations antenne


MODEL NAME	TYPE	MANUFACTURER	GAIN	CONNECTOR
56-001-000240Z	Dipole	M.gear	2.6 dBi (2.4~2.4835 GHz)	ipex (MHF)
56-001-000241Z	Dipole	M.gear	3.3 dBi (2.4~2.4835 GHz)	ipex (MHF)
56-001-000247Z	Dipole	M.gear	3.1 dBi (2.4~2.4835 GHz)	ipex (MHF)
56-001-000242Z	Dipole	M.gear	3.2 dBi (2.4~2.4835 GHz)	ipex (MHF)
56-001-000243Z	Dipole	M.gear	4.0 dBi (5.15~5.895 GHz)	ipex (MHF)
56-001-000244Z	Dipole	M.gear	3.2 dBi (5.15~5.895 GHz)	ipex (MHF)
56-001-000245Z	Dipole	M.gear	4.2 dBi (5.15~5.895 GHz)	ipex (MHF)
56-001-000246Z	Dipole	M.gear	3.4 dBi (5.15~5.895 GHz)	ipex (MHF)

Industry Canada radiation exposure statement

This equipment complies with ISSED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 29 cm between the radiator and your body.

See the User's Guide at www.zyxel.com for more information, including customer support.

Documents / Resources

	<p>ZYXEL EX5512-T0 AX6000 WiFi6 Multi Gigabit Ethernet Gateway [pdf] User Guide I88EX5512-T0, I88EX5512T0, EX5512-T0, EX5512-T0 AX6000 WiFi6 Multi Gigabit Ethernet Gateway, AX6000 WiFi6 Multi Gigabit Ethernet Gateway, WiFi6 Multi Gigabit Ethernet Gateway, Multi Gigabit Ethernet Gateway, Ethernet Gateway</p>
---	--