Danfoss Redia RTD Thermostatic Sensors Installation Guide

Danfoss Redia RTD Thermostatic Sensors Installation Guide

Contents

## Installation

2.

3.

15Nm

32

Temperature Limitation

1.

2.

MAX

5

3 | 4 5

3.

MAX

3 | 4 5

4.

e.g.
MAX = 4

4

2 | 3 | 4 5

5.

e.g.
MAX = 4

Temperature Limitation

1.

2.

MIN

3.

MIN

4.
e.g.
MIN = 2

5.
e.g.
MIN = 2

Shut off

1.

2.

3.

Theft protection

1.

2.

	Code no.
	013G5287

Blind mark

Danfoss AS

Climate Solutions • **danfoss.com** • +45 7488 2222

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material.

Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product. All

Documents / Resources

Danfoss Redia RTD Thermostatic Sensors [pdf] Installation Guide
Redia RTD, Thermostatic Sensors, Redia RTD Thermostatic Sensors, 015G3350, Sensors

Manuals+,