Kzzi I75Pro Mechanical Keyboard User Guide

Contents

Kzzi I75Pro Mechanical Keyboard

PRODUCT BASIC INFORMATION


Manual   Switch and Keycaps Puller   Keyboard   Type-C Cable   2.4G Receiver

KNOB FUNCTION

Long press knob for 3 seconds to switch knob mode

Volume Mode (default): Clockwise Volume Up, Counterclockwise Volume Down, Press to Mute

Backlight mode: clockwise backlight brightness plus, counterclockwise backlight brightness minus, press to switch the light effect

- Long press the knob for 3 seconds to switch knob mode
- Volume Mode (default): Clockwise Volume Up, Counterclockwise Volume Down, Press to Mute
- Backlight mode: clockwise backlight brightness plus, counterclockwise backlight brightness minus, press to switch the light effect

尺寸/Size	Layout	版本/Version	背光/Backlit	轴体/Key Switches
327.5(L)×150.71(W)×30.03(H)±2	80 keys	有线/2.4G/BT USB-C wired/2.4G wireless/BT	RGB	矮轴 low profile switch

WIERD MODE

USB Type-c ⚡

Wired Mode: Connect USB to the device and pull the power switch to the middle position for wired mode.

BT CONNECTION

- BT Pairing Method
- Switch to B

FN+Q / W / E, any group of long-press pairing code, for example, long-press Fn+Q, at this time, the Q key flashes quickly, indicating that it has entered the pairing state, and the slow flash indicates that the keyboard is back-connecting. Open PC/Mobile BT, search and connect the device, the search shows the name: Kzzi-+75 3.0 (connect to PC with Windows 7 or below), Kzzi-75 5.0 (connect to Windows 8 or above system version, mobile devices, etc.)

Completing the connection
And so on: Repeat the above steps, Q/W/E/can store 3 groups of BT devices, when using the switch Short press Fn+Q/W/E, you can switch between different BT devices
(Warm tips: before using the switch, please pair up the 3 groups of BT)

2.4G RECEIVER CONNECTION

1 Switch to 2.4G

**2** 2.4G pairing method FN + P

3

Switch to 2.4G

24GE 51E
2.4G pairing method

Switch to 2.4G and long press FN+P to pair the code. The The p key blinks to insert the receiver, P key stops blinking which means code pairing is successful.

(Tips: The receiver is set to be paired at the factory You just need to set it only once when pairing not working properly.)

INDICATOR LIGHT

Tap this key: Quick desktop view switch

(The factory default is to display the desktop, if you want to change other functions, you can use the driver to customize the function of the key)

Caps

Caps

1.Win Lock
  Win Lock (white light)

2.Charging indicator (red light): Charging (solid), Fully charged (off),Low battery (flashing)

BATTERY LEVEL CHECK

The keyboard's lighting can display the current battery level status.

View in wireless mode
Pressing FN +ENTER allows you to view the battery level status. Each key from "1' to "0" represents a specific battery level range.

For example

 The backlink of the rise lumina battery level is at 109%.

 The "1" and "2' keys are both illuminated, indicating that the keyboard's current battery level is at 20%.

Similarly

 When the backlighting illuminates from 1 to 0 simultaneously, it indicates that the keyboard battery is at 100% charge.

BACKLIGHT CONTROL

Fn + **\ |** ⟨•••⟩ Multiple backlight effects switch

Fn + **△** Backlight brightness +

Fn + **▽** Backlight brightness -

Fn + **WIN** 🔒 Windows lock

Fn + **, <** ⟨•⟩ Backlight monochrome switching

Fn + **◁** Backlight speed -

Fn + **▷** Backlight speed +

Fn + **space bar** Long-press for three seconds to restore factory settings

FN KEY COMBINATION FUNCTION

Fn + Del		Prtsc
Fn + PgUp		Home
Fn + PgDn		End
Fn +] }		Ins
Fn + [{		ScrLk
Fn + ' ''		Pause

BACKLIGHT RECORDING

Step1: Press Fn + 1! to customize backlight

第一步：按 Fn + 1! 选择将要自定义的背光

Step2: Press Fn + Back Enter backlit recording mode

第二步：按 Fn + Back 进入背光录制模式，

第四步：完成后，再次按 Fn + Back，将保存并退出背光录制模式

Step4: When done, press Fn + Back again, will save and exit backlit recording mode

第三步：按下想要录制背光的按键，重复此步骤，录制自己想要的背光

Step3: Press the keys which you want to record the backlight , and repeat this step

WINDOWS MULTIMEDIA KEYS

Fn + F1	Screen Brightness-	Fn + F4	Calculator	Fn + F7	Previous Song	Fn + F10	Mute
Fn + F2	Screen brightness +	Fn + F5	Media Player	Fn + F8	Play/Pause	Fn + F11	Volume -
Fn + F3	Email	Fn + F6	Stop	Fn + F9	Next Song	Fn + F12	Volume +

WindowstsELF (FN+A: t]f=Windows.zt)
In Windows mode (FN+A: Switch to Windows system)

MAC MULTIMEDIA KEYS
In macOS mode (FN+S: Switch to macOS system)

F1	Screen Brightness -	F4	Search	F7	Previous Song	F10	Mute
F2	Screen Brightness +	F5	siri	F8	Play/Pause	F11	Volume -
F3	Multiscreen Display	F6	Do Not Disturb (only supported in wired mode)	F9	Next Song	F12	Volume +

Thank you for choosing KZZI products! If you have any questions or need assistance, please feel free to contact us. Our team is dedicated to providing support and addressing your inquiries. We highly value your feedback and suggestions as they help us continuously improve and enhance product quality. Once again, we appreciate your support for KZZI!

FCC WARNING

This device complies with part 15 of the FCC Rules, Operation is subiect to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device. pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications, However, there is no guarantee that interference wil not occur in
a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WHEN USING A KEYBOARD

1. Maintain proper posture and avoid excessive force on the keys.
2. Take regular breaks to prevent hand fatigue.
3. Clean the keyboard regularly to remove dust and dirt.
4. Avoid exposing the keyboard to liquids.
5. Keep the keyboard in a suitable environment, free from extreme temperatures or humidity.
6. Remember these tips for a comfortable and durable keyboard experience.

Hot-line:400-0221-288
Email:**kzzi@kzzi.com**
Official Website: **www.kzzi.com**
Brand: Kezhi(huizhou)Electronic Technology Co., Ltd
Executive standard: GB / T 14081-2010 166-66101-02

Documents / Resources

Kzzi I75Pro Mechanical Keyboard [pdf] User Guide
I75Pro, I75Pro Mechanical Keyboard, Mechanical Keyboard, Keyboard

References

- **User Manual**