Manuals+ — User Manuals Simplified.

NYLAVEE SK600 Computer Speaker User Manual

Contents

NYLAVEE SK600 Computer Speaker

PACKAGE INCLUDE

- 2x Computer speaker
- 1 x 3.5mm Audio
- Cable 1 x User Manual

SPECIFICATION

- **Model:** SK600
- **Two Connection:** Options Bluetooth & 3.5mm Aux-in
- **Power Supply:** USB plug (no built-in battery)
- **Power Input:** DC 5V2A Max
- **3 RGB Lighting Modes:** Rhythm, Flow, Breathing

PRODUCT DIAGRAM

- **1** LED Strip
- **2** Volume Knob
- **3** Power Button
- **4** Mode Button
- **5** EQ Button
- **6** 3.5mm Aux-in Jack
- **7** LED Touch Point

BUTTON CONTROL

Function	Operation	Voice Prompt	LED Indicator
Plug in	Insert the USB plug into any USB charging adapter or active computer USB port	/	Green light on for 1 second
Power on	Hold the Power Button for 2 seconds	Beep	LED flashing red and blue alternately (It defaults to Bluetooth mode when it's turned on for the first time)
Power off	Hold the Power Button for 5 seconds	Beep	Red light on for 1 second
Play/Pause	Press the Power Button once	/	/
Switch to Bluetooth/ Aux-in mode	Press the Mode Button once	Beep	/
Bluetooth pairing	/	Beep	LED flashing red and blue alternately
Bluetooth connected	/	Beep	/
Disconnect Bluetooth	Hold the Mode Button for 5 seconds	Beep	LED flashing red and blue alternately
Toggle music effect	Press the EQ Button once	Bass, Balance	/
Volume +	Turn the Volume Knob clockwise	/	/
Volume -	Turn the Volume Knob counter clockwise	/	/
Change lighting modes	Tap the LED Touch Point once	/	① rhythm ② flow ③ breathing
Turn off/on the Light	Hold the LED Touch Point for 2 seconds	/	Light off/on
Reset	Hold the EQ Button for 10 seconds	/	/

The computer speaker does not have a built-in battery, please insert the USB plug into the USB port of the desktop

## Wireless Connection via Bluetooth

1. Switch to Bluetooth mode

1. The speaker defaults to Bluetooth mode when it is turned on for the first time.

2. To switch to Bluetooth mode from wired mode, press the Mode button once.

3. When the LED flashes blue/red, the Bluetooth mode is on.

Pair with your device

1. Tum on the Bluetooth of your audio source device and search for nearby devices Find "SK600" in the search results and tap to connect.
2. Once connected, a beep will be heard.

Wired Connection via 3.5mm Plug

RIGHT SPEAKER

AUX IN

1. Press the Mode button once to switch to the wired mode from Bluetooth mode.
2. Plug the 3.5mm Audio Cable into the AUX IN port of the right speaker.
3. Connect to your audio source device via the 3.5mm Audio Cable.

Attention

Troubleshooting of Sound

If there is no sound comes out from the speaker, please try the following operations:

- Rotate the volume knob clockwise to raise the volume of the speaker.
- Adjust the volume on your audio source device.
- Press the volume knob to resume in case the speaker pauses.
- Re-insert the USB plug and restart.

Troubleshooting of Bluetooth

- Connection Makes sure the Bluetooth of the speaker is not connected by other devices.
- Unplug the 3.5mm Audio Cable from your device.
- Delete "SK600" memorized on your device, then search for "SK600" and connect again.

Worry-free Service Guarantee

- 30 days free return and exchange.
- 18 months warranty.
- Lifetime friendly customer service.

Please contact us for more details and further instructions via

Support

- **Extend 2-years warranty:** **www.nylavee.net**
- **FCC Compliance** This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
    1. this device may not cause harmful interference, and
    2. this device must withstand any interference received, including Linterference that may cause undesired operation.
    3. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
        - this device may not cause harmful interference, and
        - this device must accept any interference received, including interference that may cause undesired operation.

          Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

          NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter.

Radiation Exposure Statement
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 5mm between the radiator and your body.

Documents / Resources

	NYLAVEE SK600 Computer Speaker [pdf] User Manual NV-SK600, NVSK600, 2A2QG-NV-SK600, 2A2QGNVSK600, SK600 Computer Speaker, SK600, Computer Speaker