A3002RU QOS settings

Contents

1 A3002RU QOS settings
2 DOWNLOAD
3 Related Posts

A3002RU QOS settings

It is suitable for: **N100RE, N150RT, N200RE, N210RE, N300RT, N302R Plus, A3002RU**

Application introduction: Solution about how to configure QoS on TOTOLINK products.

STEP-1:

Connect your computer to the router by cable or wireless, then login the router by entering http://192.168.0.1 into the address bar of your browser.

Note:The default access address varies depending on the actual situation. Please find it on the bottom label of the product.

STEP-2:

User Name and Password are required, by default both are **admin** in lowercase letter. Click **LOGIN**.



STEP-3: IPV4 QOS setting

Please go to **QoS** page, and check which you have selected. Select **Enable** and fill in **Manual Uplink/Downlink Speed**, then click **IPv4** bottom

You can fill in **IP Address and Total Uplink Bandwidth** and **Total Downlink Bandwidth** you want to restrain, then Click **Apply**.



STEP-4: IPV6 QOS setting

Please go to **QoS** page, and check which you have selected. Select **Enable** and fill in **Manual Uplink/Downlink Speed**, then click **IPv6** bottom

You can fill in **IP Address** and **Total Uplink Bandwidth** and **Total Downlink Bandwidth** you want to restrain, then Click **Apply**.



DOWNLOAD

A3002RU QOS settings – [Download PDF]

Manuals+,