Manuals+
Q & A | Deep Search | Upload

Phomemo M08F

Phomemo M08F Wireless Thermal Tattoo Stencil Printer User Manual

Model: M08F-WS

1. Introduction

The Phomemo M08F Wireless Thermal Tattoo Stencil Printer is a portable, inkless device designed for creating high-quality tattoo stencils. It offers wireless connectivity to various devices, simplifying the stencil creation process for both professional tattoo artists and beginners. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance.

Image: The Phomemo M08F printer actively producing a tattoo stencil, demonstrating its compact size and wireless capability with a smartphone displaying the design.

2. Product Overview

The M08F printer utilizes advanced thermal technology for inkless printing, eliminating the need for ink cartridges and reducing maintenance. Its lightweight and compact design makes it highly portable, ideal for various work environments. The device supports multiple operating systems and offers versatile connectivity options.

Image: An overview of the Phomemo M08F printer, emphasizing its core features such as high-quality output, inkless operation, ease of use, Bluetooth connectivity, rechargeable battery, portability, and specialization for monochrome tattoo printing.

Key Features:

- **Portable and Lightweight:** Weighs only 2 pounds, 60% smaller than traditional stencil makers.
- **Strong Compatibility:** Compatible with smartphones, tablets, laptops, and desktop computers (Android, iOS, Windows, MacOS, ChromeOS).
- **Powerful Phomemo APP:** Allows easy image and document printing, with regular updates of tattoo patterns.
- **High-Quality Inkless Printing:** Advanced thermal technology for precise designs and lines. Designed for simple monochrome patterns.
- **Conveniently Rechargeable:** 1200mAh battery, capable of printing up to 140 pages on a single

charge.

Image: A detailed view of the Phomemo M08F printer with its physical dimensions (length, width, height) clearly indicated, showcasing its compact form factor.

3. What's in the Box

- 1 x M08F Wireless Tattoo Transfer Stencil Printer (Grey)
- 10 Sheets x Tattoo Transfer Paper
- 1 x Soft Storage Pouch
- 1 x USB-A to USB-C charging cable (80cm)
- 1 x Instruction Manual

4. Setup

4.1 Powering On

To turn on the printer, press and hold the power button for 3 seconds. The indicator light will illuminate.

Video: A short preview demonstrating how to power on the Phomemo M08F printer by pressing and holding the power

button.

4.2 Loading Transfer Paper

1. Remove the transparent paper from the transfer sheet.
2. Peel off the yellow backing paper.
3. Lay the transfer paper flat in the printer with the carbon side facing down. Ensure it is centered.

Image: Visual instructions detailing the process of preparing and loading tattoo transfer paper into the printer, including removing the transparent and yellow backing sheets, and correctly inserting the paper.

4.3 Connecting to Mobile Device (Phone/Tablet)

1. Turn on your phone's Bluetooth.
2. Download the "Phomemo" App from your device's app store.
3. Open the Phomemo App.
4. Tap the printer icon in the upper left corner.
5. Find your printer (M08F) and connect.**Note: Connect within the app, not in your phone's Bluetooth settings.**

Image: The Phomemo M08F printer connected wirelessly via Bluetooth to a tablet, illustrating the app-based connection process for mobile devices.

Video: A detailed demonstration of how to connect and operate the Phomemo M08F printer using a mobile phone and the Phomemo app.

4.4 Connecting to PC (Windows/MacOS)

1. Visit tattoo.phomemo.com to download the appropriate driver for your operating system (Windows, MacOS, ChromeOS, Linux).
2. Connect the printer to your computer using the provided USB-A to USB-C charging cable.
3. Follow the on-screen instructions to install the driver.
4. Once installed, you can select the printer from your computer's print dialogue.

Image: The Phomemo M08F printer connected to a laptop via USB, with the laptop screen displaying the Phomemo driver download page for various operating systems.

Video: An operational guide demonstrating how to connect and use the Phomemo M08F printer with a Windows computer.

Video: A step-by-step tutorial on how to connect and operate the Phomemo M08F printer with a MacOS device.

5. Operating

5.1 Printing Guidelines

The M08F printer is specifically designed for printing simple monochrome patterns. For best results, use

high-resolution images and avoid overly shaded or excessively colored designs, as these may not transfer clearly.



Image: A visual guide differentiating between optimal and suboptimal designs for thermal tattoo stencil printing, advising on image selection for clear results.

5.2 Achieving Clearer Prints

For optimal print clarity, ensure the carbon paper is on top and remove the transfer paper first. Incorrect paper orientation (carbon paper on the bottom, removing transfer paper first) can lead to unclear results.

Image: A comparison illustrating the correct paper setup for clearer tattoo templates versus an incorrect setup that yields poor results.

Video: A brief tutorial providing tips on how to achieve clearer printing results with the Phomemo M08F tattoo stencil printer.

5.3 Applying Stencils

1. Wipe off the skin with wet wipes or alcohol to clean the area.
2. Apply tattoo transfer cream or gel evenly to the skin.
3. Carefully stick the printed stencil onto the prepared skin.
4. Let it dry for a few minutes to ensure proper transfer.

Image: Visual instructions demonstrating the correct procedure for transferring a tattoo stencil onto the skin, from preparation to final application.

6. Maintenance

To ensure the longevity and optimal performance of your Phomemo M08F printer, keep it clean and free from dust. Store it in the provided soft storage pouch when not in use. Avoid exposing the printer to extreme temperatures or direct sunlight.

7. Troubleshooting

If you encounter any issues with your printer, please refer to the troubleshooting section in the full instruction manual or contact Phomemo customer support. Common issues may include connectivity

problems, paper feeding errors, or print quality concerns.

8. Specifications

Specification	Detail
Model Name	M08F-WS
Brand	Phomemo
Connectivity Technology	USB, Wi-Fi
Printing Technology	Thermal
Printer Output	Monochrome
Max Printspeed Monochrome	12 ppm
Maximum Black and White Print Resolution	300 dpi
Max Input Sheet Capacity	140
Sheet Size	8.27x11.69 Inches
Item Weight	2.17 pounds (985.7 Grams)
Product Dimensions	13.78 x 2.56 x 1.38 inches (2.3"D x 10.4"W x 1.2"H)
Batteries	1 Lithium Polymer batteries required (included)
Wattage	1200 milliamp_hours
Memory Storage Capacity	64 MB
Compatible Devices	Laptops, PC, Smartphones, Tablets
Control Method	App

9. Warranty & Support

The Phomemo M08F printer comes with a Limited Warranty. For detailed warranty information or technical support, please visit the official Phomemo website or contact their customer service.

© 2023 Phomemo. All rights reserved.

Related Documents - M08F


Quick Start Guide
M08F Portable Printer
Notes before use:
01. Package Contents
02. Printer Components
03. Indicator Light Guide
04. Button Function
05. Precautions
06. Instruction Guide
07. How to Download and Install Driver
08. Official Printing Paper Type
09. FCC Warning
10. IC Warning
11. Warranty Card

[Phomemo M08F Portable Printer: Quick Start Guide & Setup Instructions]

A comprehensive quick start guide for the Phomemo M08F portable printer. Learn about package contents, printer components, indicator lights, button functions, setup, app connection, driver installation, paper types, and important precautions. Includes FCC and IC warnings.


Quick Start Guide
M08F
Tattoo Printer


English

1. Product Introduction

1.1 Packing List

Printer ×1 | Quick Start Guide ×1 | Type-C Cable ×1 | Velvet Pouch ×1

USB to Type-C Adapter ×1 | Tattoo Transfer Paper - 10 Sheets ×1

Type-C data cable and USB adapter have been placed in the velvet bag.

1.2 Printer Parts Instruction

Reset Hole
Type-C Charger Port
Power Button
Indicator Light
Cover Open Buttons ×2
Top Cover
Transducers
Paper Output Slot
Print Head
Paper Entry Slot

2. Getting Started

2.1 Downloading the App

Method 1: Search for the "Phomemo" app on App Store or Google Play™ for download and installation.

Phomemo

Download on the App Store
GET IT ON Google Play
Phomemo

Method 2: Scan the QR code to download the app. You can scan the code using your cell phone's camera, the built-in QR code scanning feature of your browser, or a dedicated QR code scanning app.

In the Safari browser on Apple devices does not support direct QR code scanning, please use your device's built-in QR code scanner instead.

2.2 Tattoo Transfer Paper Introduction

White Tracing Sheet
Removable Protective Sheet
Blue Carbon Sheet
Yellow Backing Sheet

This area is the adhesive seam at the top of the paper, please do not tear it!

2.3 Preparation Before Use

Take out a piece of tattoo transfer paper, and remove its Protective Sheet.

Removable Protective Sheet

Trim the Yellow Backing Sheet along the top adhesive seam with a ruler or scissors.

Method 1 | Method 2

Yellow Backing Sheet | Yellow Backing Sheet

When cutting, please make sure that the adhesive was remains intact.

2.4 Paper Installation Guide

Long press the Power Button for 1 seconds until the indicator Light is green to power up the printer.

Simultaneously press the Cover Open Buttons with both hands.

Open the Top Cover.

Remove the protective paper.

If your printer version does not include the disposable protective paper, please skip this step.

Place the white tracing paper face up and flat into the printer in the direction of the paper outlet. Make sure the tattoo paper covers the sensor.

Transducers

Place the tattoo transfer paper with the White Tracing Sheet facing up.

Put the Top Cover back down, and press down on both of its ends at the same time until you hear a click, indicating the cover is securely closed.

2.5 User Guide: Printing via Mobile App

Open the "Phomemo" app.

Grant permissions.

Wait for the printer to be searched.

Tap [Connect Now].

The printer is connected. Tap [Paper loaded, starting printing].

Edit your first image, and tap [ ] after you finish editing.

Confirm the preview of the image, and tap [Print].

Printing is completed.

Retrieve the printout.

Tear off the White Tracing Sheet for use.

The software interface is for illustration purposes only. Please refer to the actual operation page for accurate information.

2.6 User Guide: Printing via computer

Please make sure the printer is powered on and connect it to the computer using the original Type-C cable.

USB Type-A End (Wide End)

USB Type-C End (Flat End)

If your computer is Type-C interface, you can use the supplied adapter to convert the interface, the Type-C end of the adapter needs to be plugged into the computer side. The adapter is unidirectional, and the Type-A end of the adapter plugged into the printer and will not be charge or fail to transfer data when only.

Visit tattoo.phomemo.com to download and install the driver.

Select and open the file you need to print.

The file formats supported by the printer include JPG, PNG, etc.

Tap [ ].

Select the M08F Printer, and click [Print] to start printing.

Retrieve the printout.Tear off the White Tracing Sheet for use.

3. Cleaning and Maintenance

Disconnect the printer from the power supply before starting any cleaning or maintenance.

If you encounter issues such as blank lines, blurry print, or missing words, it may be caused by dirt on the Print Head. Please follow these steps:

If you have just finished printing, wait for at least 30 minutes for the Print Head to cool down completely.

Use a cotton swab dipped in alcohol or a dry alcohol-soaked cotton ball to gently wipe the Rubber Roller and the Print Head left and right 5 times each, removing dust and stains from the surfaces.

Wait 5-10 minutes for the alcohol to evaporate completely before closing the Top Cover and completing the cleaning process. You may now continue using the printer.

Rubber Roller
Print Head

Print Head Warning: HOT component! Touching it when it is hot can cause burns to your fingers. Please wait for at least 30 minutes after turning off the power before touching it.

4. Charging Instructions

1. Please prepare your own power adapter (DC 5V/2A) with a Type-A port.
2. Insert the Type-C end (flat end) of the USB cable into M08F's Type-C Charger Port and plug the Type-A end (wide end) into the Type-A port of the power adapter.
3. After connecting the printer to an outlet using the power adapter, please check the status of the Indicator Light: a light flashing alternately between red and green indicates that the printer is off, while a flashing green light signals that the

[Phomemo M08F Tattoo Printer Quick Start Guide]

Get started quickly with the Phomemo M08F Tattoo Printer. This guide provides essential information for setup and initial use, including mobile app connectivity and printing instructions.



	[Phomemo M08F Portable Thermal Tattoo Printer Quick Start Guide](#) This quick start guide provides essential instructions for setting up and operating the Phomemo M08F portable thermal tattoo printer, including component identification, indicator light meanings, mobile app and computer connectivity, paper installation, and compliance information.

	[Phomemo M08F Quick Start Guide: Computer and Smartphone Printing] A concise guide to setting up and using the Phomemo M08F portable printer for printing from computers (Windows, Mac, Linux) via USB and from smartphones via Bluetooth, including setup instructions and regulatory information.
	[M08F Printer Troubleshooting Guide] A comprehensive troubleshooting guide for the M08F printer, covering power indicator issues, connectivity problems, printing effects, charging issues, and other settings.
	[M08F Plus Portable Printer User Guide] User guide for the M08F Plus portable printer, covering product introduction, getting started, app download, paper installation, printing via mobile app, additional instructions, cleaning and maintenance, charging, and connection methods.