# Wake-up Light
User Manual


Thank you for choosing our product.
Please read this manual carefully before using it.

Front

Back

Bottom

①Patting turn on the light setting ②Alarm 1/Alarm 2 ③Fall Asleep ④Snooze

⑤FM Radio ⑥FM Tuning ⑦Display Brightness/Time Setting

⑧/⑨Down/Up Button ⑩Light Switch ⑪TYPE-C Input ⑫USB Output

⑬Loudspeaker ⑭FM antenna ⑮Button Batery (Remove insulation sheet first) ⑯LED Display

Alarm

①Press : turn on/off the alarm;
②Press and hold: set the alarm with pressing ⊖/⊕ to adjust.

Fall Asleep

①Press : turn on/off the fall asleep function;
②Press and hold : set the fall asleep mode, with pressing ⊖/⊕ to adjust.

Display Brightness & Time Setting

①Press : adjust the time display brightness;
②Press and hold : set the time with pressing ⊖/⊕ to adjust.

Light

①Press and hold 60, the 60 icon will illuminate, Press 60 to select the time of turn on the light.Pat the product and the light will turn on/off. Press and hold 60 again to switch off patting light function
②Press ☀ to turn on/off sunrise light; Press — / + to adjust the brightness.
③Press ☀ twice to turn on/off the colored light;

   Press — / + to adjust the light color.

FM Radio

①Press 📻 to turn on/off the FM; Press and hold 📻 to scan radio frequencies auto matically
②Press to adjust the volume

   Press and hold to adjust the channel.

Catalog

1.Press and hold ⊛ for 2s, the ⊛ icon will illuminate and the hour indication will start to flash; press ⊖/⊕ to adjust the hour.

2.Press ⊛ to confirm the setting, the minute indication will start to flash;press ⊖/⊕ to adjust the minute.


3.Press ⊛ to confirm the setting, the 12H indication will start to flash; press ⊖/⊕ to choose between a 12-hour and a 24-hour clock Press ⊛ to complete the time setting.

2

2 Display Brightness

Press ⚙ to adjust the display brightness. 4 Levels: High-light—Mid-light—Low-light—OFF


High-light   Mid-light   Low-light   OFF

3 Alarm Function

3.1 Alarm Groups

Allow users to program 4 alarms based on individual needs.For example, set Alarm 1 for weekdays and Alarm 4 for weekend.Note: the setting of 2 alarms is the same.

3.2 Alarm Switch (Alarm 1 as the example)

Press 🕐 to turn on/off the alarm; When Alarm 1 is turned on, the ⏰ icon will illuminate on the display.


Alarm1 ON

3.3 Alarm Setting

1.Press and hold 🕐 for 2s, the icon will illuminate and the hour indication will start to flash; press ⊖/⊕ to adjust the hour;

2.Press 🕐 to confirm the setting, the minute indication will start to flash; press ⊖/⊕ to adjust the minute.

3.Press 🔘 to confirm the setting, the sound indication will start to flash; press ⊖/⊕ to choose the sound; (S-00～S-09, XX MHz)

Indications: S-00: the sound is turned off.S01～S09: built-in natural sounds.XX MHz: the last FM radio frequency you listened to.


4.Press 🔘 to confirm the setting, the volume indication will start to flash; press ⊖/⊕ to adjust the alarm volume (V-01～V-16).

5.Press 🔘 to confirm the setting, the wake-up light brightness indication will start to flash; press ⊖/⊕ to adjust the wake-up light brightness (L-00, L-01 to L-20).

Note: when the set alarm time arrives，the light will slowly turn from dark to the preset brightness level. L-00: the light is turned off.


6.Press 🔘 to confirm the setting, the "light up prior to alarm" indication will start to flash; press ⊖/⊕ to adjust the duration (10~60 min).

Press 🔘 to confirm and complete the alarm setting.

The wake-up light can simulate sunrise to gradually increase the brightness. The alarm will go off at set time as the wake-up light reaches the set brightness. When the alarm goes off, you can tap to snooze, adjust the alarm sound or stop the alarm.


1.Press ⏺⏺⏺😴⏺⏺⏺ to snooze. After 9 minutes, the light will automatically come on and the sound will play again (5 times at most).

2.Press 🔘 to stop the alarm.
Note: If the alarm is turned on, it will still go off next time.

NO
Respond

3.If the alarm is ignored for 30 minutes, it will stop automatically.
Note: If the alarm is turned on, it will still go off next time.

## 5.1 Pat light setting

1. Press and hold ⟨·60⟩ for 2S， the ⟨60⟩ icon will illuminate. Press ⟨·60⟩ to select the time of turn on the light (selection of four gears: 5 minutes, 15 minutes, 30 minutesand 60 minutes)

2. Pat the Product and the light will turn on/off，When the selected time is up, the light will automatically turn off

3. Press and hold ⟨·60⟩ for 2s again to switch off patting light function

5.2 Sunrise Light

1.Press ⊙ to tun on the sunrise light; the ⊛ icon will illuminate.

2.Press ⊖/⊕ to adjust the brightness. Press ⊙ again to turn it off.

5.3 Colored Light

Press twice to turn it on

1.Press ⊙ twice to tun on the colored light; the ⊛ icon will illuminate and the light will activate auto color-change mode.

2.Press ⊖/⊕ to manually adjust the light color.
Press and hold ⊖/⊕ to quickly adjust the light color
Press ⊙ to turn it off.

6.1 Radio Switch

1.Press 🔘 to turn on/off FM. The 📻 icon will illuminate on the display when the FM mode is turned on.

6.2 Auto Scan

2.Press and hold 🔘 for 2s to scan radio frequencies automatically; the 📻 icon will start to flash. It broadcasts the first channel after the search is complete.

6.3 FM Tuning/Volume

3.When the FM mode is turned on, Press ◄/► to adjust the volume; Press and hold ◄/► to adjust channels.

9

7.1 Fall Asleep Switch

Press to turn on/off the fall asleep mode.

The icon will illuminate on the display when the fall asleep mode is turned on.


Fall asleep mode: ON

7.2 Fall Asleep Setting

hold for 2s

1.Press and hold for 2s to start the setting, the icon will illuminate and the time indication will start to flash; press ⊖/⊕ to adjust the fall asleep time (10～120 min).

Press and hold for 2s

2.Press to confirm the setting, the fall asleep brightness indication will flash; press ⊖/⊕ to adjust the fall asleep brightness. (L-00, L-01~L-20);

Note: the fall asleep brightness is the initial brightness when fall asleep mode is turned on; the light will gradually dim in sleep mode L-00: the light is turned off.

10

3.Press ⊙ to confirm the setting, the fall

asleep sound indication will start to flash;

press ⊖/⊕ to adjust the fall asleep sound.

(S-00～S-08, XX MHz);Note: S-00: the sound is
turned off.S-01～S-08: natural sounds. XX MHz:
the last FM radio frequency you listened to.

4.Press ⊙ to confirm the setting, the fall

asleep volume indication will start to

flash.Press ⊖/⊕ to adjust the

volume(V-01～V-16).Press ⊙ to confirm

the completion and activation of fall

asleep mode.

7.3 Fall Asleep Adjustment

Sunset simulation for peaceful bedtime: when the fall asleep mode is turned
on, the light will dim until it goes out and the sound will gradually decrease
until there is no sound.

1.Press ⊖/⊕ to adjust the

brightness.

2.Press 🔊/🔊 to adjust the

volume.

8. Charge other electronics

The product has reverse charging function, and can charge electronic equipment such as mobile phone, handheld game player, etc.

1. Download Smart Life into your mobile device from App Store/ Google Play or by scanning QR code.

• Download APP

Android/IOS

2. Create an Account and Log in

3. Add Device & Connect WIFI

- Once your alarm clock is connected with power at your first time using,the hour on the display blinks and icon 🛜 blink rapidly.Follow the steps to add the device:
 **Note:**If the icon 🛜 on the device is NOT rapidly blinking,press and hold button snooze⊙(about 5 seconds) until it is rapidly blinking.
- Turn on the Bluetooth of the mobile phone. Bluetooth makes adding devices quickly. After adding the device, you can choose to turn off Bluetooth

1.Download Amazon Alexa and sign in your Amazon account.

2. ——Select **Skills & Games**, search **Smart Life**, and **ENABLE TO USE** it.

——Login your "Smart Life" account, then **Authorize** and close the **successfully linked** page after it is connected successfully to enter **Discover Devices** page.

3. Discover Devices

This wake-up light works with Alexa, through this skill, Amazon Alexa will find and list devices you originally added in Smart Life App.

Note:
If your Smart Life account has linked to Alexa, please add the devices by the following steps:

1.Download **Google Home** and sign in your google account.

2. Login your "Smart Life" account, then **Authorize** and close the **Accounts now linked** page after it is connected successfully to enter **Choose Device** page. Then you can control the wake-up light via Google Home after complete setting.

| Product Name	Wake-up Light
Brightness Adjustment	20 Levels
Light Color	7
Volume Adjustment	16 Levels
Display Brightness	4 Levels
Alarm Groups	4
Type of Alarm Sound	9 Natural Sounds & FM Radio
Sunrise Simulating Time	Adjustable 10-60 Minutes
Alarm Mode	Light & Sound; Sound Only; Light Only
Alarm Time	30MIN
Snooze Time	9MIN
Number of Snooze Times	5
Fall Asleep Sound	8 Natural Sounds & FM Radio
Sunset Simulating Time	10-120 Min
Fall Asleep Mode	Light & Sound, Sound Only, Light Only
Frequency	76.0-108MHz
Material	Light-proof ABS + PC
Operating Temperature	0°C~40°C (32°F~104°F)
Type of Battery	Button Cell CR2032
Input Voltage	100~240V
USB Output	5V/2A

Caution

Place the device on a stable, level and non-slippery surface.

The alarm stand is a fragile component, please be careful during installation and removal.

Do not use the device at room temperature lower than 0°C or higher than 40°C.

Do not use this device as a tool to reduce your time of sleep. Its purpose is to help you wake up more easily without reducing your need for sleep.

This device is intended for family use or hotel use.

Storage

Please clean the device with a soft cloth.

Do not use abrasive cleaners or pads, or cleaning agents such as alcohol or acetone to prevent damage to the device surface.

Store the device in a safe, dry place that will not crush, bang or damage it.

Do not wrap the power cord around the device during storage.