Samsung Controls Product Overview

1

Agenda

1. Local control
2. Centralized control
3. Integrated management system
4. Building management system
5. Ancillary controls & modules
6. DVM chiller controls

2

Before we begin…

SAMSUNG

Important Notices

Specification Changes	Use of Training Material	Handling of Equipment	Use of Information
Specifications are subject to change without prior notice.

Every effort has been made to insure that the information included in this presentation is as accurate as possible at the time of it's publication. | This training module is not intended to replace Samsung service manuals, technical data books, installation/operation manuals or other factory documents.

For technical support issues, always contact a Samsung equipment provider. www.samsunghvac.com/downloads | Only properly trained, HVAC professionals should attempt to install and start up any Samsung heating and air-conditioning system. | This presentation may only be used with authorization by Samsung HVAC. Unauthorized use, duplication or alteration of this presentation is prohibited. |

High Voltage Caution:
Extra care must be taken when working on or around the system equipment due to numerous high voltage components. Whether installing or servicing Samsung RLC equipment in the field or while attending Samsung HVAC training classes which include powered simulators and equipment, be aware of the potential dangers of high voltage **Use Caution**

3

Samsung Control System

4

Samsung N.A.S.A
Network Architecture for System Air Conditioners

F1 F2 communications

F3 F4 communications

R1 R2 communications

Integrated digital communications Samsung "NASA" Communication Protocol	Proprietary to all Samsung DVMS VRF systems
Basic 2-conductor control wire design simplifies installation	Reliable Daisy-chain communication wiring – 0.5vdc.

5

Control Wiring NASA Digital Control Layers

- F1 F2 – Set Layer:
  - ODU to IDU's & MCU'S
  - (incl. multiport EEV Kit)
  - Daisy chain connections
    - 0.5 VDC
- F3 F4 – Local Layer:
  - Wired Remote Controller to indoor unit
    - 12 VDC
- R1 R2 – Control Layer:
  - Outdoor Unit to upper-level controllers
    - 5 VDC
- Control Wire:
  - 16/2 AWG stranded with shield
  - Never use solid core thermostat wire

F1 F2 Set Layer

F3 F4 Local Layer

R1 R2 Control Layer

6

Local Control

7

Remote Controllers

- Indoor units are controlled by digital, Remote Controllers
    - Wireless
        - No internal room temperature sensor
    - Wired
        - All wired controllers have built-in room temp sensors
- Power Line Communication
    - (12 vdc)

8

Wireless Remote Controllers

Wirless controllers come with RAC systems, but must be purchased separately for CAC, FJM & DVM Systems

AR-EH04U	
Long reach function	Fan speed
Single event timer setting	Filter reminder setting
Temperature setting	Operation mode
Wind-Free™* Cooling mode, if applicable	Option code setting (Up to 4 indoor units)

AR-KH03U 360 Cassette	
Long reach function	Fan speed
Single event timer setting	Filter reminder setting
Temperature setting	Operation mode
360 Cassette directional airflow control	Option code setting (Up to 4 indoor units)

*The Wind-Free™ unit delivers an air current that is under 0.15 m/s while in Wind-Free™ mode. Air velocity that is below 0.15 m/s is considered "still air" as defined by ASHRAE 55-2013 (American Society of Heating, Refrigerating, and Air-Conditioning Engineers).

9

Wired Remote Controllers

Features include:
- Louver position setting
- Partial/ all button lock capability
- Outing function
- Wind-Free™* cooling
- Long reach function
- Built-in room temperature sensor

- Control up to 16 indoor units on a single system or across multiple systems
- Service mode for monitoring, setup, addressing, etc.

Touchscreen Wired Controller

Features include:
- Color screen
- Dual set-point**
- Built-in room sensor
- Advanced heat pump auto changeover settings
- 7-day programmable scheduling
- Occupied/unoccupied and setback settings
- Group control of up to 16 indoor units
- Energy monitoring
- IR receiver
- Service mode settings and error code display with description
- WindFree™* function

Advanced Wired Controller

**See specifications or manual for additional functions.**

*The Wind-Free™ unit delivers an air current that is under 0.15 m/s while in Wind-Free™ mode. Air velocity that is below 0.15 m/s is considered "still air" as defined by ASHRAE 55-2013 (American Society of Heating, Refrigerating, and Air-Conditioning Engineers).

10

Control Wiring Connections

Indoor unit PCB Terminal Block

| F1 | F2 | V1 | V2 | F3 | F4 |

Digital data transfer (F3 F4)

To Remote Controller
12 VDC

ODU to IDU
Communication 0.5vdc

**12 vdc
(e.g. wi-fi Kit)**

11

Wired Remote Controller – Built-in Sensor

- Room temperature control
- Default
  - Indoor unit return air sensor
- Options
  - Wired remote controller's built-in room sensor
  - Average room temperature between the indoor unit and remote controller

MWR-SH11UN   MWR-WG00UN

Room temperature sensor

12

MWR-SH11UN "Simple Touch" Wired Remote Controller

- Built-in room sensor
- Backlit LCD display
- Wind-Free™* Control
- Clean Function
- Long Reach
- Error display
- Built-in infrared receiver
  - allows control with wireless remotes

- Button lock feature: All buttons or selected buttons
- Temperature display option
  - "Set Temperature"
  - "Room Temperature"
- Address and option code setting
- For detailed functions and operations refer to IOM manual

*The Wind-Free™ unit delivers an air current that is under 0.15 m/s while in Wind-Free™ mode. Air velocity that is below 0.15 m/s is considered "still air" as defined by ASHRAE 55-2013 (American Society of Heating, Refrigerating, and Air-Conditioning Engineers).

13

MWR-WG00UN Wired Remote Controllers

- Built-in IR receiver and temperature room sensor
- Dual Set Point (DSP) Setting (for supported indoor units)
- **Wind-Free™*** function settings
- 360 cassette functions
- Backlit LCD display
- Advanced HP auto changeover
- Error display
- Weekly operating schedule
- Upper/lower temperature limit setting

- Child lock
- Button lockout options
- Wireless remote-control restriction
- MDS (motion detection sensor) Indirect/Direct setting
- Service mode support
- Address and option code setting
- For detailed functions and operations refer to IOM manual

*The Wind-Free™ unit delivers an air current that is under 0.15 m/s while in Wind-Free™ mode. Air velocity that is below 0.15 m/s is considered "still air" as defined by ASHRAE 55-2013 (American Society of Heating, Refrigerating, and Air-Conditioning Engineers).

14

AR-EH04U Wirless Remote Controller

- Compatible with all indoor units equipped with an IR receiver
  - (excl. 360 cassette)
- 4 channels for individual unit control
- No built-in room temp sensor
- Powered louver control
- WindFree* function
- Address and option setting
- Ducted units require Wireless Receiver Kit
- 4-Way Cassette each louver can be set individually
  - 32° to 65°
- For detailed functions and operations refer to IOM manual

15

AR-KH03U Wirless Remote Controller

360 Cassette

- Air flow direction control for 360 cassettes
  - Individual booster fan control
- No built-in room temp sensor
- 4 channels for individual unit control
- Buzzer sound mute
- Address and option setting

16

MRW-TA External Room Sensor

- Provides for more accurate room temperature control when indoor unit is installed in high ceiling, or has outside fresh air ducted into the return,
- 2-wire connection to indoor unit PCB

Thermistor Sensor

17

MRW-TA External Room Sensor

- Replaces input from return air sensor and provides temperature sensing for remote controllers without internal sensor
- Applies to all indoor units
- Includes a 39 ft. 2-conductor connection cable

Indoor Unit PCB

2 Pin Adaptor

Extension cable

Unplug the IDU return air sensor (CN412) and plug in the MRW-TA wire in it's place

18

9

Centralized Control

19

WIFI Adapter MIM-H04UN

- "Samsung Smart Things" app required
- Android and Apple devices
- Control up to 16 indoor units
- Scheduling / 7 day
- Grouping On/Off control
- Energy Monitoring
  - Daily
  - Weekly
  - monthly

20

WIFI Adapter MIM-H04UN

Remote Control

1 Way

4 Way

Ducted

Ceiling

21

WIFI Adapter MIM-H04UN

Schedule and Settings

22

WIFI Adapter MIM-H04UN

Energy Monitoring

- Display of power output
- Different than consumption found on utility bills
- View kWh by
  - Day
  - Week
  - Month

23

Touch Centralized Controller MCM- A300UN

- 7" Touchscreen Controller
- Maximum 128 indoor units
- Maximum of 16 systems on a single R1/R2 upper-level comm. Line
  - Control of multiple systems
- Can connect to one system on the set layer F1/F2
  - Control of one system

24

Touch Centralized Controller MCM- A300UN

- Creation of zones for indoor unit grouping
  - Max 12
- Digital output interlocked with indoor unit operation
  - Operation error
- SD card slot for data backup and future software updates
- 100 – 240vac power supply
  - Requires code compliant installation

25

Touch Centralized Controller MCM- A300UN

26

## Touch Centralized Controller MCM- A300UN

● **Front**

• On/Off button for LCD backlight
• LED indicator
  - Blue : Indoor unit's operation status.
  - Red : Indoor unit's error status.

SD card slot

● **Bottom**

Reset button

Power source

485 comm.
DO(Digital Output)
DI-1(Digital Input-1)
DI-2(Digital Input-2)
Indoor unit's on/off status : DC 12V, 10mA   : Dry contact(voltage free)

27

Touch Centralized Controller MCM- A300UN

▪ To connect to multiple systems the controller must be connected to the R1/R2 Connection

▪ Must be daisy chained

▪ Maximum 16 systems on R1/R2

   ▪ (single controller most common)

▪ 128 units maximum

Main system com line

R1/R2

Main system comm line

28

14

Touch Centralized Controller MCM- A300UN

- Can be used in conjunction with other upper-level controls
  - DMS 2.5
  - BACnet
- Multiple central controllers can be used in the network.

29

Touch Centralized Controller MCM- A300UN

- Connection can be made at indoor or outdoor unit
- Not polarity sensitive
- Max of 64 units on F1/F2

30

Touch Centralized Controller MCM- A300UN

External Device Interlock

- Simple operation control
- 2 Digital inputs
  - Stop signal (stops all equipment)
  - Signal to lock/unlock local controllers
- Interlock with external contact

31

Touch Centralized Controller MCM- A300UN

Three operation patterns

Pattern	Control	Contact Input
1	No function (Default setting)	Not applied
2	DI 1. Emergency stop operation. (Short : Stop / Open : standby) All indoor units stop operating and any command is ignored	Short / open **contact**
	DI 2. no function	
3	DI 1. All indoor unit ON/OFF control (Short : off / Open: on) ※ It is different from DMS 2.5 (Short : on / Open : off)	Short / open **contact**
	DI 2. Permitted/Prohibited remote controller use (Short : Permitted / Open : Prohibited)	
4	DI 1. All indoor unit ON control	Short **pulse**
	DI 2. All indoor unit OFF control	

32

16

Touch Centralized Controller MCM- A300UN

Operation Mode Restriction

Only cooling mode

Remote Controller Restriction

33

Integrated Management System

34

Data Management Server 2.5

- Directly compatible with
  - All NASA Systems
  - DVM, Current CAC & FJM,
- Fresh Access™ Split DOAS

35

Data Management Server 2.5

- Compatible with use of adaptors
  - Non-NASA Systems
    - With adaptor MIM-N01
  - Fresh Access™ ERV'S
    - With adaptors
      - MIN-N10
      - MXD-K200VN
  - RAC
    - With adaptor

MIM-N01   MIM-N10   MXD-K200V

Accessory are physically the same, but the software is different. Take care when installing to make sure the correct part number is with the correct components

MIM-R10UN

36

Interface Requirements

- Windows PC or mobile device utilizing any of the following internet browsers
  - Edge
  - Internet Explorer
  - Chrome
  - Safari
    - Firmware 2.9.0.15 or greater is required

37

DMS 2.5 Control & Monitoring

- Individual/Zone management up to 256 indoor units
- Remote control via LAN/Internet

Example

| A zone | Cooling only / No remote controller / Minimum cooling setpoint: 68°F |
| B zone | Cooling only / Remote controller use |

38

39

DMS 2.5 Recorded History Management

- Indoor unit operation history
- Schedule history
- Control logic operation history
- System environment setting history
- Error history
- SD card allows data storage when the DMS memory fills.

40

DMS 2.5 Connections

No	Name	Description
1	Digital Input	All indoor unit operation and wired/wireless remote controller use are controlled according to the option switch setting. (10Channel) Have fixed addresses.
2	Digital Output	DC signal voltage to output in case of error in more than one indoor unit and outdoor unit. Output voltage : 12VDC, 200mA (8Channel have fixed addresses)
3	Reserved	Not use
4	Power	Power supply to DMS. 12VDC/3.0A (adapter)
5	Reset button	Press the reset button to restart DMS.
6		Only use for R&D
7	SD card slot	SD card slot for data storage and updating software
8	LAN port	LAN connection with upper-layer devices.
9	RS485	Connect for RS485 communication with devices (5 Channel)

41

DMS 2.5 Connections: DI/DO

- 2 dedicated DI
  - Emergency control,
 - Voltage free

- 8 dry contact inputs
  - open/short contact
  - Voltage free

42

DMS 2.5 Connections: DI/DO

- 2 dedicated DO
  - Operation/Error
  - 12vdc max. 200mA
- 6, Non dedicated 12vdc outputs
  - External interlocking systems

43

DMS 2.5 Connections: DI/DO

- 2 reserved outputs for future use

44

22

DMS 2.5 Wiring Detail

- 5 Channels
- Max 16 systems per channel
  - 16 Systems X 5 channels
  - Max 80 systems
- Any channel configuration
- Max 128 indoor units and MCU's per channel
- Max 256 indoor units Per DMS 2.5

45

DMS 2.5 Connections

- Dedicated computer or integrated with a building network

46

23

DMS 2.5 Connection Example

- Local or Remote Access available
- IP address of remote computers must be registered in the DMS
- VPN maybe required if using a computer in multiple locations

47

DMS 2.5 Power Distribution

- Maximum 8 MIM-B16UN per DMS 2.5
- Maximum 8 pulse type watt hour meters
- 1-year power distribution data storage
- Data query for
  - watt-hour, use time and use ratio
  - Current power consumption monitoring
- Current-type electricity meter support
  - (CT ratio input)
- Pulse Input Module required
- (PIM) MIM-B16UN
- Export data to Microsoft Excel

48

DMS 2.5 Wiring Detail

- Max 8 Power Interface Modules (PIM)
  - MIM-B16UN
- Max 8 Watt Hour Meters per PIM

Max. 16 / 1Ch.

Max. 8 WHM per PIM

Max. 8 MIM-B16

49

DMS 2.5 Configurable Control Logic

User can edit control logic with different variable parameters

50

DMS 2.5 Configurable Control Logic

Sequence of Control Logic Setting

1. Definition

1. Control logic name
2. Period
3. Day
4. Time

2. Input condition setting

1. Select a factor (Single, Arithmetic, Function)
2. Select comparison operator & value
3. Select duration (optional)

3. Output command setting

1. Select a factor
2. Select operation command

51

DMS 2.5 Configurable Control Logic

- Example 1 – Cool Mode
- Changing mode based on average room temperature vs. set temperature

IF
The average room temperature is greater than the average set temperature
AND
Outdoor temperature is greater than 51°F
For 30 minutes

THEN
Change the indoor units to COOL mode

52

26

DMS 2.5 Configurable Control Logic

- Example 4
- Activate an outside air device based on OA and indoor temperature

IF
Outdoor temperature is between 40 ~ 90°F

THEN
Activate Digital Output (renamed as "AUX FAN")

DMS 2.5 Configurable Control Logic

Basic logic tips

- If input conditions are true and output commands are being executed, the output command type cannot be changed for that unit
- Additional control logic programs must be created to undo what your logic programs may have done
  - Example 1: If you activated an ERV in bypass mode for "free cooling", make sure that there is also a program to turn it off later if room temperature is below set temperature.
  - Example 2: If you activated a valve for backup radiant heating with a DO, make another program to turn it off once set temperature is reached.

Building Management System

55

BMS Gateway

SAC

- An integrated control and management system with third party control systems

DMS BACnet Gateway

- Converts Samsung NASA protocol to a common language
  - BACnet
  - Lonworks

DMS LonWorks Gateway

56

BMS Gateway

- Open protocol gateways for Building Management Systems (BMS)
- Same interface as DMS 2.5

| DMS BACnet Gateway | DMS LonWorks Gateway |
| (MIM-B17BUN) | (MIM-B18BUN) |

57

DMS BACnet Gateway MIM-B17BUN

- Interface for BACnet Building Management System
- Included DMS2.5 function
- Communication connection
  - Lower layer: RS485 to Samsung Systems
- Upper layer: Ethernet 10/100 Base-T to internet
- BACnet layer: Ethernet 10/100 Base-T to BMS

58

29

DMS BACnet Gateway MIM-B17BUN

3rd party BMS

※ One gateway can connect multiple outdoor units.

BMS (BACnet)

Samsung

DMS BACnet Gateway

Touch centralized controller

Control Layer (R1/R2)

Set Layer (F1/F2)

ODU   IDU   IDU   IDU   IDU   IDU

59

DMS BACnet Gateway MIM-B17BUN

BMS Control Function

- On/Off control
- Temperature setting
- Operation mode
- Fan speed/direction
- Filter alarm reset
- User control restriction
- Operation mode lock & set temp limit
- Emergency stop

Monitoring Function

- On/Off
- Set/Room temperature
- Operation mode
- Fan speed/direction
- Filter alarm
- User control restriction
- Operation mode lock & set temp limit
- Power distribution
- Error information

60

BACnet Control Points – Indoor Units

Instance Number	Object	Object Type	Object Name	Unit Inactive Text-1	Active Text-2
1	Indoor temperature	AI	AHU_RoomTemp_xx_xxxxxx	°C(°F)	
2	Set temperature	AV	AHU_Temp_Set_xx_xxxxxx	°C(°F)	
3	Setting lower temperature limit	AV	AHU_Cool_LimitTemp_xx_xxxxxx	°C(°F)	
4	Setting upper temperature limit	AV	AHU_Heat_LimitTemp_xx_xxxxxx	°C(°F)	
5	The power value of an indoor unit after the basic date	AI	AHU_Baseline_kWh_xx_xxxxxx	kWh	
6	The number of hours usage of an indoor unit after the basic date	AI	AHU_Baseline_Minute_xx_xxxxxx	Minute	
7	Power value within period	AI	AHU_Period_kWh_xx_xxxxxx	kWh	
8	The number of hours usage of an indoor unit within period	AI	AHU_Period_Minute_xx_xxxxxx	Minute	
9	Power On/Off	BV	AHU_Power_xx_xxxxxx	Off	On
10	Applying lower temperature limit setting	BV	AHU_Cool_Limit_set_xx_xxxxxx	False	True
11	Applying upper temperature limit setting	BV	AHU_Heat_Limit_set_xx_xxxxxx	False	True
12	Filter sign status	BI	AHU_FilterSign_xx_xxxxxx	False	True
13	Filter sign reset	BO	AHU_FilterSign_Reset_xx_xxxxxx	False	True

61

BACnet Control Points – Indoor Units

Instance Number	Object	Object Type	Object Name	Unit Inactive Text-1				Active Text-2
14	Operation mode status	MV	AHU_Operation_Mode_xx_xxxxxx	Auto	Cool	Heat	Fan	Dry
15	Operation mode limit status	MV	AHU_Mode_Limit_xx_xxxxxx	No Limit	Cool Only	Heat Only		
16	Remote controller limit status	MV	AHU_Remocon_Limit_xx_xxxxxx	Enable RC	Disable RC	Conditional RC		
17	Integrated error code of both indoor unit and outdoor unit	AI	AHU_Error_Code_xx_xxxxxx	Refer to Samsung integrated error code list				
18(*1)	Discharge cooling set temperature	AV	AHU_DisCoolSetTemp_xx_xxxxxx	°C(°F)				
19(*1)	Discharge heating set temperature	AV	AHU_DisHeatSetTemp_xx_xxxxxx	°C(°F)				
20(*1)	Discharge current temperature	AI	AHU_Dis_CurrentTemp_xx_xxxxxx	°C(°F)				
21(*1)	Humidification setting	BV	AHU_Humidification_xx_xxxxxx	Off	On			
22(*1)	Outdoor air intake setting	BV	AHU_OAIntake_xx_xxxxxx	Off	On			
23(*1)	Outdoor cooling setting	BV	AHU_OutdoorCool_xx_xxxxxx	Off	On			
24(*)	Fan speed status	MV	AHU_Fanspeed_xx_xxxxxx	Low	Mid	High		
25(*1)	Set humidity status	MV	AHU_SetHumidity_xx_xxxxxx	Low	Mid	High		
26(*1)	Current humidity status	MI	AHU_CurrentHumidity_xx_xxxxxx	Low	Mid	High		
27	AHU Notify	NC	AHU_Notify_xx_xxxxxx	When the error occurred, send event to list of destination in the recipient_list. (Max: 3)				

(*) Not supported as standard, additional sensors and unit configuration required

(**) Not supported for North American AHU models

62

31

BACnet Control Points – Outdoor Units

Instance Number	Object	Object Type	Object Name	EEV Readout Text 1	Status Value Access Text 2	Text 3	Text 4	Text 5
1	Outside temperature	AI	ODU_Outside_Temp_xx_xxxx	°C				
2	Cooling capacity requirement	AV	ODU_Cool_Comp_operation_xx_xxxx					
3	Heat capacity requirement	AV	ODU_Heat_Comp_operation_xx_xxxx					
4	Compressor status	DI	ODU_Comp_Status_xx_xxxx	False	True			
5	Interface module error code	AI	map/error_3_no3_Code_xx_xxxx					
6	Interface module error	MO	M_S_alby_xx_xxxx					

MIM-B17BUN Gateway

Instance Number	Control and Monitoring	Object Type	Object Name	Status Value
1	All on/All OFF	AO	ALL_OFF_xx	
2	DAM2 Status	AI	DAM2_Status_xx	0: Normal, 2: Emergency stop, 100: Tracking in progress, 101: Tracking failed 100, DAM2 — DA Com. Communication failed
3	error information code	AI	error information code_xx	error information code
4	Gateway Notify	VO	C/V_Notify_xx	

63

BACnet Control Points – Digital Inputs & Outputs

Instance Number	Object	Object Type	Object Name	Unit	Status Value
1	Digital Input 1 [1]	BI	DI_01_xx_xx	Off	On
2	Digital Input 2 [1]	BI	DI_02_xx_xx	Off	On
3	Digital Input 3	BI	DI_03_xx_xx	Off	On
4	Digital Input 4	BI	DI_04_xx_xx	Off	On
5	Digital Input 5	BI	DI_05_xx_xx	Off	On
6	Digital Input 6	BI	DI_06_xx_xx	Off	On
7	Digital Input 7	BI	DI_07_xx_xx	Off	On
8	Digital Input 8	BI	DI_08_xx_xx	Off	On
9	Digital Input 9	BI	DI_09_xx_xx	Off	On
10	Digital Input 10	BI	DI_10_xx_xx	Off	On
11	Digital Output 1 [2]	BO	DO_01_xx_xx	Off	On
12	Digital Output 2 [2]	BO	DO_02_xx_xx	Off	On
13	Digital Output 3	BO	DO_03_xx_xx	Off	On
14	Digital Output 4	BO	DO_04_xx_xx	Off	On
15	Digital Output 5	BO	DO_05_xx_xx	Off	On
16	Digital Output 6	BO	DO_06_xx_xx	Off	On
17	Digital Output 7	BO	DO_07_xx_xx	Off	On
18	Digital Output 8	BO	DO_08_xx_xx	Off	On

AI: Analog input (read only)
AO: Analog output (read/write)
AV: Analog value (read/write)
BI: Binary input (read only)
BO: Binary output (read/write)
BV: Binary value (read/write)
MI: Input (read only)
MO: Output (read/write)
MV: Value (read/write)

[1] Reserved for BACnet Gateway emergency input signal
[2] Reserved for BACnet Gateway operation and error output

64

32

DMS Lonworks Gateway MIM-B18BUN

- Interface for Lonworks Building Management System
- Included DMS2.5 function
- Maximum 128 indoor units per gateway
- Number of objects monitored/controlled varies based on quantity of indoor unit
- Communication connection
  - Lower layer: RS485 Samsung Systems
  - Upper layer: Ethernet 10/100 Base-T To internet
- Lonworks layer: TP/FT-10A to BMS
- Lonworks limited to a max 600 points
 - Example 30 indoor units 20 points each

65

DMS Lonworks Gateway

66

33

DMS Lonworks Gateway   MIM-B18BUN

BMS Control Function
- On/Off control
- Temperature setting
- Operation mode
- Fan speed/direction
- Filter alarm reset
- User control restriction
- Operation mode lock & set temp limit
- Emergency stop

Monitoring Function
- On/Off
- Set/Room temperature
- Operation mode
- Fan speed/direction
- Filter alarm
- User control restriction
- Operation mode lock & set temp limit
- Power distribution
- Error information

67

Intesis™ BACnet IP-MSTP Interfaces

- Features
  - Direct access to outdoor unit's communication bus.
  - Automatic identification of the units present in the VRF system.
  - Supports BACnet/IP and BACnet MSTP physical layers.
  - Datalogging through external USB port.
  - Configuration through IP or USB (Console) port.
  - Front cover LED indicators to provide easy to check communication status on both the Ethernet and serial ports.
  - Automatic updates for both Intesis MAPS and interface's firmware.
 - Power supply not included. 24 vdc (>=140ma) recommended;

68

34

Intesis™ BACnet IP-MSTP Interfaces

Use Case

Integration of Samsung NASA VRF Air Conditioner Units into a BACnet installation.

69

Intesis™ Modbus RTU Interface

- Allows fully bi-directional communication between NASA units and Modbus RTU networks.

- Features

  - Configuration from both onboard DIP-switches and Modbus RTU.

  - Quick and easy installation

  - External power not required.

  - Simultaneous control of the AC unit by wired/wireless controllers and Modbus RTU.

  - Window contact function allows energy savings.

 - Included components: Intesis Gateway, Installation Manual

70

Intesis™ Modbus RTU Interface

Use Case

Integration of Samsung NASA AC units into a Modbus RTU installation.

71

Ancillary Controls & Modules

72

Ancillary Controls & Modules

Optional devices to provide various control solutions

Wireless signal receiver
(MRK-A10N)

Operation mode selection switch
(MCM-C200U)

External room sensor
(MRW-TA)

Compatible interface module
(MIM-N01)

Interface Module
Communication Adapter
MIM-R10UN

ERV interface module
(MIM-N10)

External contact interface module
(MIM-B14)

Multi Tenant Function Controller
(MCM-C210N)

Motion Detection Sensors

73

Wireless Signal Receiver – MRK-A10N

- To allow indoor units without an infrared reciver to use a wireless controller
  - Ducted/Console
  - On/Off control
  - Operation indication
  - Filter maintenance indication
  - 32' connector cable included
- If the unit is using a wired controllers this receiver will not be needed as both our wireless controllers can receive an infrared signal

74

37

Operation Mode Selector Switch – MCM-C200U

- Manual system mode select
- Heat Pump systems only
  - Cool – Heat – Auto setting options
- Installed in outdoor unit or in building
- Allows manual operation mode change preventing mixed operation
- Max. 328ft of wire between outdoor unit and MCM-C200U
- 3 conductor cable require

75

External Temperature Sensor – MRW-TA

- 2-wire connection to indoor unit PCB
- Replaces unit return air sensor
- Applies to all indoor units
- Includes a 39 ft. 2-conductor cable
- Provides for more accurate room temperature control when
  - Indoor unit is installed in a high ceiling
  - Fresh air is ducted into the return
 - When using a remote controller with no built-in space sensor

76

Interface Module Communication Adapter MIM-N01

- Allows connection of DVM S series systems to previous generation central control models
- Allow connection of non-NASA products to NASA communication upper-level controllers
- Installs in the outdoor unit
- Includes wire harness for
  - F1/F2
  - 12 VDC

77

Interface Module Communication Adapter MIM-N01

- Gives older equipment a R1/R2 connection
- Converts eveything to NASA
- Address will be set with a dial,
- Each unit will need a unique address

78

Interface Module Communication Adapter MIM-N01

NASA
Upper-Level Control

R1/R2

MIM-N01

MIM-N01

F1/F2

F1/F2

Non-NASA
Equipment

Non-NASA
Equipment

79

Interface Module Communication Adapter MIM-N10

- Used in conjunction with ERV Kit (MXD-K200VN)
- Control Fresh Access ERV'S
- Communication between upper-level controllers and the ERV units, DMS2.5, Touch centralized controller

MIM-N10 takes F1/F2 and converts it to R1/R2

MXD K200VN
converts Modbus to F1/F2

DMS 2.5

80

MIM-N10 & MXD-K200VN ERV Interface

81

Interface Module Communication Adapter MIM-R10UN

- Allows connection of Samsung 2020 RAC single zone systems to NASA

- Installs in the RAC outdoor unit with included harnesses

- One per outdoor unit is required

- Must manually set a central control channel address

82

Interface Module Communication Adapter MIM-R10UN

NASA
Upper-Level Control

R1/R2

MIM-N01

MIM-N01

MIM-R10UN

F1/F2

F1/F2

F1/F2

Non-NASA
Equipment

Non-NASA
Equipment

83

External Contact Controller – MIM-B14

- Direct indoor unit control by external contact signal
- Function examples:
  - Hotel key card switch
  - Door/window switch
  - Occupancy sensor
  - On/Off ventilation control with indoor unit thermo-on/ thermo-off
- Indoor unit operation/error state output through relay contacts
- Emergency control with simple contact input
- Compatible with all DVM S indoor fan coil units

84

External Contact Controller – MIM-B14

85

External Contact Controller – MIM-B14

86

External Contact Controller – MIM-B14

Indoor unit operation/error state output through relay contacts

87

External Contact Controller – MIM-B14

- To control other devices based on indoor unit operation
- Output terminals are open/close contacts 0 volts
- Indoor unit option setting required
    - 02 installation option setting, segment 15
- Max load rating on the Operation & Error terminals
    - 250vac, 3A

88

External Contact Controller – MIM-B14

- MIM-B14 Controller operation output can be modified to one of the following at a time
- Operation On/Off
  - Output based on power status of connected indoor unit (On or Off including fan)
- Thermo On/Off
  - Output based on connected indoor unit's current operation
    - Heating/Cooling trying to condition the space
    - Satisfied set point and in a "Thermo-Off" state
    - Fan mode – contact open
- External Heat control

89

External Contact Controller – MIM-B14

Operation Output Cooling

Temperature

Room temperature

Set temperature + 1°F
Set temperature
Set temperature - 1°F

time

Remote control Cooling On

Operation output = THERMO ON/OFF

Operation output = Operation ON/OFF

Thermal ON   Thermal OFF   Thermal ON

90

External Contact Controller – MIM-B14

Operation Output Heating

91

External Contact Controller – MIM-B14

- Thermo-On/Off Operation
  - Output terminals are dry contacts Open/Close with 0 volts
  - Maximum 250vac, 3A can be applied to the operation and error output terminals

Indoor unit operation	Operation state
Cooling (Thermo **ON**)	Close (20 second delay)
Cooling (Thermo **OFF**)	Open (20 second delay)
Heating (Thermo **ON**)	Close (120 second delay)
Heating (Thermo **OFF**)	Open (120 second delay)
FAN	Open

92

46

External Contact Controller – MIM-B14

Control fresh air intake damper

93

External Contact Controller – MIM-B14

- RAC & FJM wall mount units
    - All units require wired controller sub-PCB and wire harness when using the MIM-B14
    - Change installation option setting code to enable the External Contact Controller

94

Multi-Tenant Function Controller – MCM-C210N

- Used in applications where an indoor unit will not have power for long periods to allow full system operation.
  - If an indoor unit loses power the DVM S system will lock out on an E201 error code after 2 minutes
  - Timing can be changed to 12 or 24 hours
  - MTFC can keep the system online
- One MTFC per DVM S indoor unit
  - Monitors supply voltage to the indoor unit
  - Supplies auxiliary power to maintain communication during power loss
  - Powers the EEV closed during power loss to avoid water damage
    - Condensation
    - Drain pump not powered causing water overflow
    - 5 VDC to maintain communication
    - 12 VDC to power EEV closed for safety

95

Multi-Tenant Function Controller – MCM-C210N

- Controller power supply:
  - 24vac 50/60Hz transformer (not provided)
- Transformer must be powered from a separate circuit
- Indoor unit connection cable
  - Max length 118"
- One Wired Remote controller cannot be connected to multiple indoor units when using the MTFC
- The MTFC must be installed in an NEC approved enclosure (field provided)

For ceiling type: 1 WAY CASSETTE, 4 WAY CASSETTE and DUCT

For wall-mounted type

96

Multi-tenant Function Controller – MCM-C210N

97

Multi-Tenant Function Controller – MCM-C210N

98

49

Motion Detect Sensors

- MCR-SMA Motion Sensor
  - Standard Mini 4-Way Cassette
- MCR-SMC Motion Sensor
  - Wind-Free™* 4 Way Cassette
- MCR-SMD Motion Sensor
  - Wind-Free™* Mini 4 Way
- MCR-SME Motion Sensor
  - 360 Cassette

99

MCR-SMA Motion Sensor – Mini 4-Way Cassette

- Samsung Comfort Logics (activated in "Premium" mode)
- Comfort Flow:
  - MDS prevents cassette from blowing directly on occupants by changing air flow direction
- Comfort Temperature:
 - When the temperature difference between the upper and lower parts of the room is large, the supply air louvers will lower to direct air downward
- Comfort Saving:
  - When no motion is detected, MDS will adjust set temperature to reduce energy consumption (maximum +3.6º F in cooling, and -3.6º F in heating)

Mode	Soft Off (minutes)	Hard Off (minutes)	Function Description
Standard	20	30	SOFT OFF: turns off indoor unit but can restart with motion detection before HARD OFF.
	40	60	
	80	120	HARD OFF: Turns unit off but will not turn back on after motion is sensed. Unit will need to be power ON with a unit controller.
	120	180	
Premium	20	30	SOFT OFF and HARD OFF are the same as Standard Mode.
	40	60	
	80	120	Samsung comfort functions are activated.
	120	180	

100

MCR-SMC,D,E Motion Sensor – Mini 4-Way Cassette

- Samsung Comfort Logics (activated in "Premium" mode)

- Comfort Flow:
  - MDS prevents cassette from blowing directly on occupants by changing air flow direction

- Comfort Temperature:
  - When the temperature difference between the upper and lower parts of the room is large, the supply air louvers will lower to direct air downward

- Comfort Saving:
  - When no motion is detected, MDS will adjust set temperature to reduce energy consumption (maximum +3.6º F in cooling, and -3.6º F in heating)

Mode	Soft Off (minutes)	Hard Off (minutes)	Function Description
Standard	20	30	SOFT OFF: turns off indoor unit but can restart with motion detection before HARD OFF.
	40	60	
	80	120	HARD OFF: Turns unit off but will not turn back on after motion is sensed. Unit will need to be power ON with a unit controller.
Premium	20	30	SOFT OFF and HARD OFF are the same as Standard Mode.
	40	60	
	80	120	Samsung comfort functions are activated.

101

Motion Detect Sensors

Power On/Off

102

Motion Detect Sensors

Pattern Learning Function Details

- Pattern Learning Function is implemented with ON/OFF function baseline (default OFF times)
- Pattern Learning Function is 3rd step
- If there is a pattern of leaving and not returning, the MDS will slowly decrease the amount of time for Soft OFF and Hard OFF saving energy with shortened operation times.

3763 Wh
2177 Wh
758 Wh

31%
65%

Non MDS (Conventional)   Power On/Off   Power On/Off + Pattern learning

*ON/OFF Function 120min

*Cooling set point 64.4° F, 18,000 btu/h Mini 4way 1 set

103

Motion Detect Sensors

Indirect Air Flow

- People sensing O → avoid direct air flow
- People sensing X → direct air flow
  ⇒ Feeling comfortable

Floor Temperature Sensing

Ceiling Temperatures sensing - Temperature difference of Floor-Ceiling

Floor – Ceiling Temperatures sensing Feeling comfortable

104

24VAC Thermostat Adapter MIM-A60UN

Features
- Allow control of indoor units with a standard 24VAC thermostat
- One adapter per indoor unit connected to F3-F4

Basic control of:
- Power: ON/OFF
- Mode: Heat, Cool, Fan
- Supports 1 or 2 stages cooling inputs, 1 or 2 stages heating inputs

Can be configured to operate the indoor unit as
- Primary heating source
- Secondary heating source
- Cooling only with heat from an external source only

External contact input to disable the unit when contact is opened

105

24VAC Thermostat Adapter MIM-A60UN

External NTC (MRW-TA)

Dip Switch (Setting Option Mode)

Reset Switch

No	Name	Description
1	Y1	Stage 1 cooling
2	Y2	Stage 2 cooling
3	G	Fan
4	G1	Low Fan
5	G2	Mid Fan
6	G3	High Fan
7	W1	Stage 1 heating
8	W2	Stage 2 heating
9	R	24VAC (out) to Thermostat
10	C	Common (out) to Thermostat

No	Name	Description
1	TR	24VAC (In) from Transformer
2	TC	Common (In) from Transformer

No	Name	Description
1	DI1	Dry contact input
2	DI2	Not USE
3	DI-Com	Input common
4	DO1	Error Feedback output
5	DO1	Error Feedback output
6	DO2	E. external heat output
7	DO2	E. external heat output

No	Name	Description
1	F3	RS485 PLC communication
2	F4	(Connected Indoor Unit)

Rotary Switch (Setting Set Temp.)
RSW1 : Cooling, RSW2 : Heating

106

53

24VAC Thermostat Adapter MIM-A60UN

- Basic priority :
 - Central control and wireless remote control will operate normally. If the indoor unit is controlled by central control or wireless remote control, the displayed indoor status on the thermostat and the actual status of the indoor unit may be different.
- Thermostat priority :
  - The thermostat control will be applied first and will control the indoor unit based on the thermostat demand. Indoor units with this option set to ON will ignore wireless remote control and central control commands including central controller schedule, logic control, etc. Central controllers will only monitor indoor unit status.


SW1	Operation priority setting
ON	Thermostat priority
OFF	Basic priority (default)

107

24VAC Thermostat Adapter MIM-A60UN

SW2	Use External DI Function
ON	DI Function enable (dry contact)
OFF	DI Function disable (default)

SW3	Use External DO Function
ON	DO Function enable
OFF	DO Function disable (default)

SW4	Select Error Feedback Function
ON	Enable Error Feedback
OFF	Disable Error Feedback (default)

| SW5	Select External Heater Function
ON	Enable support for external heat
OFF	Disable support for external heat (default)

108

24VAC Thermostat Adapter MIM-A60UN

For the external thermistor, use the
external room sensor (MRW-TA) supplied
by Samsung Electronics.

SW6	External Thermistor(NTC) setting
ON	Use External Thermistor
OFF	Do not use External Thermistor (default)

SW7	SW8	Stage 1, 2 Heat sources option
ON	ON	W1 (Stage 1 heat) energized : SAMSUNG AC OFF
		W2 (Stage 2 heat) energized : SAMSUNG AC OFF
ON	OFF	W1 (Stage 1 heat) energized : SAMSUNG AC OFF
		W2 (Stage 2 heat) energized : Turn on SAMSUNG AC with Heat Mode
OFF	ON	W1 (Stage 1 heat) energized : Turn on SAMSUNG AC with Fan Mode
		W2 (Stage 2 heat) energized : Turn on SAMSUNG AC with Heat Mode
OFF	OFF	W1 (Stage 1 heat) energized : Turn on SAMSUNG AC with Heat Mode (default)
		W2 (Stage 2 heat) energized : Turn on SAMSUNG AC with Heat Mode (default)

109

24VAC Thermostat Adapter MIM-A60UN

SW9	SW10	In case of using 'G' Input
ON	ON	FAN Speed (LOW)
ON	OFF	FAN Speed (MID)
OFF	ON	FAN Speed (HIGH)
OFF	OFF	FAN Speed : Auto (default)

SW11	SW12	If using 'G' Input under thermal off condition
ON	ON	FAN Speed (HIGH)
ON	OFF	FAN Speed (LOW)
OFF	ON	FAN Speed (MID)
OFF	OFF	FAN Speed (HIGH) (default)

110

# 24VAC Thermostat Adapter MIM-A60UN

RSW1   RSW2

► RSW1 : Cool mode set temperature (Y1/Y2), (Cooling: 64.4°F ~ 82.4°F)

RSW1	0(Default)		1		2		3		4		5		6		7	
Input	Y1	Y2	Y1	Y2	Y1	Y2	Y1	Y2	Y1	Y2	Y1	Y2	Y1	Y2	Y1	Y2
°F	73.4	68	68	64.4	69.8	66.2	71.6	68	75.2	71.6	77	73.4	78.8	75.2	80.6	77

	8		9		A		B		C		D		E		F	
	Y1	Y2	Y1	Y2	Y1	Y2	Y1	Y2	Y1	Y2	Y1	Y2	Y1	Y2	Y1	Y2
°F	69.8	64.4	71.6	64.4	73.4	64.4	75.2	64.4	77	64.4	78.8	64.4	80.6	64.4	82.4	64.4

► RSW2 : Heat mode set temperature (W1/W2), (Heating: 68°F ~ 86°F)

RSW2	0(Default)		1		2		3		4		5		6		7	
Input	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2
°F	71.6	77	69.8	75.2	73.4	78.8	77	82.4	78.8	84.2	80.6	86	68	86	69.8	86

	8		9		A		B		C		D		E		F	
	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2
°F	71.6	86	73.4	86	75.2	86	77	86	78.8	86	82.4	86	71.6	77	71.6	77

Warning The indoor unit may not operate properly if it is set to "discharge air temperature" control.

If this situation is encountered, change the setting to "indoor temperature" control (default indoor unit setting).

111

24VAC Thermostat Adapter MIM-A60UN

112

DVM Chiller Control

113

Samsung's DVM Chiller
Capacities and Specifications

DVM Chiller~

Available capacities - 10 | 15 ton modules
(Heat pump only)

- Connect up to 16 units for system capacities up to 240 tons
- 208-230V / 60Hz / 3 Ø or 460V / 60Hz / 3 Ø
- Outdoor unit static pressure up to 0.32" WC
- • Water temperature ranges
  - Cooling: 41°F - 77°F (5°C – 25°C) as standard, 14°F – 77°F (-10°C – 25°C)*
  - Heating: 77°F - 131°F (25°C - 55°C)**

~Requires FCU Interface Module

114

Samsung's DVM Chiller
Key Features

SAMSUNG

MIM-F00N

16 single 10 or 15-ton modular chillers can be combined to achieve 240-tons from a single system.

Capacity Modulation
Its compatibility and high space efficiency makes it perfect for replacing existing chillers as it cuts down maintenance costs and frees-up valuable space while expanding overall capacity.

Advanced Performance and Efficiency
Boasts a highly efficient BLDC inverter compressor with flash injection technology.

Flash Injection
Uses Samsung BLDC scroll compressors with flash injection technology for increased low ambient heating performance.

Control Options*
Optional Fan Coil Unit Control Kits and Fan Coil Interface Modules are available to control and integrate third-party fan coil units to Samsung central and local controls.

*Used with MIM-F00N FCU Control Kits, requires MIM-F10N Interface Module

115

Samsung's DVM Chiller
Controls and Accessories

MIM-F10N

Module Controller
- Required to operate the DVM Chiller
- DVM Chiller ON/OFF control (module/group)
- Operation mode, water outlet temperature setting
- Optional operation setting, module/group setting
- Weekly operation schedule setting

MCM-A00N

FCU (Fan Coil Unit) Interface Module
- Communication interface module between FCU Control Kit and upper-level controller
- Used with MIM-F00N FCU Control Kits
- Supports FCU Control Kit Only
- Maximum connection of 1A FCU Control Kits

FCU (Fan Coil Unit) Control Kit
- Communication and control interfacing kit between 3rd party fan coil unit and Samsung control system
- Requires MIM-F10N Interface Module
- Compatible with MWR-SH1SUN, MWR-WE1SUN, MWR-WG00UN wired controllers
- Provides external contact input
- Outputs control signal for fan coil unit fan/water valve

MIM-F00N

116

Samsung's DVM Chiller

Integrated System Diagram

Control and monitor Samsung standard indoor units along with third party fan coil units using a FCU control kit with the DMS 2.5 web interface.

117

DVM Chiller Design Guide

118

119

Thank you for listening!

120