**Manuals+** — User Manuals Simplified.

# RayBit POD 7 Wireless Speakerphone Kit User Manual

# RayBit

**Wireless Speakerphone Kit**

**User Manual**

**Contents**

## What's in the box

**Wireless Speakerphone X 1**

**Wireless Microphone X 2**

**USB Cable X 1**

**Wireless Receiver X 1
(Optional)**

**User Manual X 1**

## Overview



Indicator light

Answer
End call

ON/OFF

Volume +
Mute/unmute
Volume –
Wireless pairing

Wireless Microphone
Charging Port

3.5 Audio Port (IN)

3.5 Audio Port (OUT)

Type-C Port

Mute/unmute

Charging Port

## Easy Set-Up

**• About main sperkerphone**

1. **Power On/Off**

   Long press ON/OFF ⏻ for 3s, the speakerphone will be turn on/off with hint tone.

2. **Connect and disconnect**

   2.1 Wireless connection

   A. After power on, long press wireless pairing button for about 2s to start pairing mode.

   You will hear "pairing" (white and blue flashing light).

   B. Turn on your device and choose to connect with the speakerphone. Wait for 3s until you hear hint tone.

C. To cancel pairing: a short click on pairing button.(flashing light turn white).

D. To disconnect: a long press on pairing button for about 2s, you will hear hint tone.
(Blue light turn white).



2.2 Connect by USB cable

Connect with computer by USB cable.



2.3 Connect by Wireless Receiver

Connect the USB wireless receiver to your computer, and start pairing mode on speakerphone. Wait for about 15 seconds until the pairing is completed, then the speakerphone is connected and ready to go.



3. **Charging**



Main speakerphone: connect the speakerphone by USB to an AC adapter or USB charging port, it will start to charge.

4. **Answer /end calls**

Press ⌕ button to answer calls, press ⌕ button to end calls.

5. **Speaker volume up/down**

$+$ Speaker volume up, $=$ Speaker volume down

6. **Mute**

   Press mute button 🎤 among any of the main speakerphone and wireless microphones, all microphones will be muted at the same time. Press again to unmute.

   When microphone is working, light will be white. When muted, light will be red.

7. **Automatic shut off**

   When device is not connected for lSmins, it will shut off automatically.

8. **Battery level**

   When charging or short press power key, the green light is the charging/power level indicator. During charging it will be green flash light, and full green light when charging is completed.

## About wireless microphone

1. **Power On/Off**

   Long press mute button for 3s, it will be turned on/off.

2. **Connect and Disconnect**

   A. Long press mute button on the extension mies for about 6s, the white light will flash quickly to enter pairing mode.Then long press on the call key and power key of main speaker for about 65+ to start pairing.

   (Note: Usually the wireless microphones should have been paired with main speakerphone already before delivery. n special cases, refer to this method to pair again if they were disconnected).

   B. When wireless mic is disconnected with main speakerphone, it will be white flash light and shut down automatically after 18mins.

   C. When main speakerphone is shut down, the connected wireless mies will be shut down at the same time.

3. **Charging**

   Wireless microphone: While the main speakerphone is charging, put the wireless microphone magnetic charging connector near the speakerphone charging port.

   Wireless microphone will be connected and start to charge.

   **(Note:** When battery under low level, it will be red flash light. During charging it will be green flash ight, and full green light when charging s completed.)

## Documents / Resources

| | |
|---|---|
| Wireless Speakerphone Kit<br><br>User Manual | **RayBit POD 7 Wireless Speakerphone Kit** [pdf] User Manual<br>POD 7 Wireless Speakerphone Kit, POD 7, Wireless Speakerphone Kit, Speakerphone Kit |

## References

- **User Manual**