UNITY M-LOK Mounting Kit Instruction Manual

UNITY M-LOK Mounting Kit

Contents

ⓘ PRODUCT OVERVIEW

The AXON™ SL M-LOK® Mounting Kit increases functionality of the AXON™ SL remote switch by expanding the mounting capabilities to the M-LOK® rail. It replaces the rail clamps with a frame that provides attachment to any M-LOK® rail surface.

One (1) AXON™ SL M-LOK® Mounting Kit Frame

Two (2) M-LOK® Screws

Two (2) M-LOK® Nuts

ENSURE FIREARM IS UNLOADED

⚠️ **WARNING**

◇ **CAUTION**

OVER-TORQUING FASTENERS CAN DAMAGE YOUR MOUNT AND WILL NOT BE COVERED BY WARRANTY.

1. Ensure the Rail Clamps on your AXON™ SL are uninstalled prior to installing the M-LOK® Mounting Kit. Set the Rail Clamps and associated screws aside for safe keeping.

2. Insert the M-LOK® Screws through the AXON™ SL M-LOK® Mounting Kit Frame and thread partially into the M-LOK® nuts.

3. Guide the AXON™ SL Control Module through open slot of M-LOK® Mounting Kit until fully seated.
4. Place the AXON™ SL with M-LOK® Mounting Kit in desired location on the rail. Guide the M-LOK® Screws with the M-LOK® Nuts installed through the desired M-LOK® slot. Lightly snug both Screws before applying torque. When torqueing, do not exceed 10 in-lbs (1.13 Nm). Ensure M-LOK® Nuts are fully perpendicular to M-LOK® slots in rail (fully seated).

CUSTOMER SUPPORT

Documents / Resources

 UNITY M-LOK Mounting Kit [pdf] Instruction Manual
M-LOK Mounting Kit, Mounting Kit, Kit

References

- ⊕ **UNITY Tactical Patents - UNITY Tactical**
- **User Manual**