



BH CORE MTB User Guide

[Home](#) » [BH](#) » BH CORE MTB User Guide 

BH CORE MTB User Guide



Contents

- [1 DISPLAY INFO](#)
- [2 SETTINGS](#)
- [3 BATTERY XPRO](#)
- [4 BATTERY](#)
- [5 DOWNLOAD COMPLETE MANUAL](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

DISPLAY INFO



ON /OFF



CHANGE INFO



LEVEL





LIGHTS



THROTTLE




SETTINGS




- Reset Trip




- Brightness




- Battery Status




- Display Info




- Units



- Motor Settings



- Wheel Size



- Language



- Connectivity





- Connectivity – Bluetooth



- Connectivity – Ant+



- Vibration notifications



- Errors



BATTERY XPRO


CORE DISPLAY INFO



BATTERY XPRO INFO



BATTERY




Only use the charger provided with the battery. Do not place any object on the charger.

Charging the BH battery at 70-80% is mandatory if not used or stored for a long time period.

Additionally, control the level of the battery charger every 3 months and keep it always above 20% charge.

If the battery is in deep sleep mode and in order to wake it up, please charge the battery to 100% capacity.

DOWNLOAD COMPLETE MANUAL



https://www.bhbikes.com/en_INT/about-bh/manuals-downloads

Documents / Resources



[BH CORE MTB](#) [pdf] User Guide
CORE, MTB, BH

References

- [BH Manuals & Downloads | Official Online store of BH bikes](#)