



AcuRite 75071T Intelli-Time Digital Clock Instruction Manual

[Home](#) » [Acurite](#) » AcuRite 75071T Intelli-Time Digital Clock Instruction Manual 

*AcuRite 75071T Intelli-Time
Digital Clock Instruction Manual*



Questions? Contact Customer Support at
(877) 221-1252 or visit www.AcuRite.com.

SAVE THIS MANUAL FOR FUTURE REFERENCE.



Congratulations on your new AcuRite product. To ensure the best possible product performance, please read this manual in its entirety and retain it for future reference.

Contents

- 1 Unpacking Instructions
- 2 Package Contents
- 3 Features & Benefits
- 4 SETUP
 - 4.1 Install or Replace Batteries
 - 4.2 Intelli-Time® Clock
 - 4.3 Set the Time & Date
- 5 OPERATION
 - 5.1 Using the Digital Clock
 - 5.2 Troubleshooting
 - 5.3 Care & Maintenance
 - 5.4 Replace Intelli-Time Clock Battery
 - 5.5 Specifications
- 6 FCC Information
- 7 Customer Support
- 8 Limited One Year Warranty
- 9 Documents / Resources
 - 9.1 References
- 10 Related Posts

Unpacking Instructions

Remove the protective film that is applied to the LCD screen prior to using this product. Locate the tab and peel off to remove.

Package Contents

1. Digital clock
2. Instruction Manual

IMPORTANT


PRODUCT MUST BE REGISTERED TO RECEIVE WARRANTY SERVICE


PRODUCT REGISTRATION

Register online to receive 1 year warranty protection


www.AcuRite.com

Features & Benefits






1. Intelli-Time® Clock
2. AM/PM Indicator
3. Time Zone Indicator
4. Daylight Saving Time Indicator
5. Integrated Hang Hole
For easy wall mounting.
6. SET Button
7. UP Button
8. DOWN Button
9. TIME ZONE Button
10. RESET Button
Full reset to factory defaults
11. DST OLD/NEW/OFF Switch
for DST setup preferences.
12. Battery Compartment
13. Intelli-Time® Battery Compartment
14. Fold-Out Stands



SETUP

Install or Replace Batteries

1. Remove the battery compartment cover.
2. Insert 4 x AA alkaline batteries into the battery compartment, as shown.
Follow the polarity (+/-) diagram in the battery compartment.
3. Replace the battery cover.



PLEASE DISPOSE OF OLD OR DEFECTIVE BATTERIES IN AN ENVIRONMENTALLY SAFE WAY AND IN ACCORDANCE WITH YOUR LOCAL LAWS AND REGULATIONS.

BATTERY SAFETY: Clean the battery contacts and also those of the device prior to battery installation. Remove batteries from equipment which is not to be used for an extended period of time. Follow the polarity (+/-) diagram in the battery compartment. Promptly remove dead batteries from the device. Dispose of used batteries properly. Only batteries of the same or equivalent type as recommended are to be used. DO NOT incinerate used batteries. DO NOT dispose of batteries in fire, as batteries may explode or leak. DO NOT mix old and new batteries or types of batteries (alkaline/standard). DO NOT use rechargeable batteries. DO NOT recharge non-rechargeable batteries. DO NOT short-circuit the supply terminals.

Intelli-Time® Clock

Intelli-Time clock and calendar are pre-programmed to the correct time and date, and update automatically for Daylight Saving Time. All you need to do is select your time zone using the “TIME ZONE” button.

Set the Time & Date

Set the time zone (HAST, AKST, PST, MST, CST, EST, AST) by pressing the “TIME ZONE” button, located on the back of the clock. The Time Zone selected is indicated on the clock display.

Set the Daylight Saving Time preference (NEW, OLD, OFF) using the DST switch, located on the back of the clock. If you live in an area that observes Daylight Saving Time, DST should be set to “NEW”, even if it is not currently Daylight Saving Time. While DST is being observed, “Daylight ST” is indicated on the clock display.

Press and hold the “SET” button for 3 seconds to enter SET MODE. Once in SET MODE the preference you are currently setting will blink on the clock.

To adjust the currently selected (flashing) item, press and release the “UP” or “DOWN” buttons (press and HOLD to fast adjust).

To save your adjustments, press and release the “SET” button to adjust the next preference. The preference order is as follows:

CLOCK HOUR (Please note AM/PM indicator)

CLOCK MINUTE

CALENDAR MONTH

CALENDAR DATE

CALENDAR YEAR

You will automatically exit SET MODE if no buttons are pressed for 15 seconds. Enter SET MODE any time by pressing and holding “SET” button for 3 seconds.

OPERATION

Using the Digital Clock

To view the MONTH/DATE/YEAR, press and release the “SET” button. Press “SET” button again to display time. If no buttons are pressed after 15 seconds the display will automatically display time again.

Troubleshooting

Clock is too dark, hard to read or doesn't work

- Reset the unit by pressing the reset button located on the back of the clock. This will reset the clock to the original factory settings. Time and date will need to be entered after a reset.

If your AcuRite product does not operate properly after trying the troubleshooting steps, visit www.AcuRite.com or call (877) 221-1252 for assistance.

Care & Maintenance


Clock Care

Clean with a soft, damp cloth. Do not use caustic cleaners or abrasives. Keep away from dust, dirt and moisture. Clean ventilation ports regularly with a gentle puff of air.

Replace Intelli-Time Clock Battery

Intelli-Time technology is powered by a pre-installed coin-cell battery that stores the time and date settings. The battery has a shelf life of several years. Time and date will need to be entered after replacing Intelli-Time battery. To replace the Intelli-Time battery:

1. Locate the coin cell battery compartment door inside the battery compartment of the clock. Unscrew and remove the compartment cover.
2. Insert 1 x CR2032 coin cell battery into the battery compartment, as shown. Install battery with “+” positive terminal facing right.
3. Screw in the battery cover.





WARNING: THIS PRODUCT CONTAINS A BUTTON-CELL BATTERY. IF SWALLOWED, IT COULD CAUSE SEVERE INJURY OR DEATH IN JUST 2 HOURS. SEEK MEDICAL ATTENTION IMMEDIATELY IF INGESTED.



Specifications

POWER

4 X AA alkaline batteries

FCC Information

This device complies with part 15 of FCC rules. Operation is subject to the following two conditions:

1. This device may NOT cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. **NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

This device complies with Industry Canada licence-exempt RSS standard(s).

Customer Support

AcuRite customer support is committed to providing you with best-in-class service. For assistance, please have the model number of this product available and contact us in any of the following ways:



(877) 221-1252



info@chaney-inst.com

24/7 support at www.AcuRite.com

- Installation Videos
- Instruction Manuals
- Replacement Parts
- Register your Product
- Support User Forum
- Submit Feedback & Ideas


IMPORTANT

PRODUCT MUST BE REGISTERED TO RECEIVE WARRANTY SERVICE

PRODUCT REGISTRATION

Register online to receive 1 year warranty protection

www.AcuRite.com



Limited One Year Warranty

At AcuRite, we proudly uphold our commitment to quality technology. Chaney Instrument Co. warrants that all products it manufactures to be of good material and workmanship, and to be free of defects when properly installed and operated for a period of one year from the date of purchase.

We recommend that you visit us at www.AcuRite.com for the fastest way to register your product. However, product registration does not eliminate the need to retain your original proof of purchase in order to obtain warranty benefits.

Chaney Instrument Co. warrants that all products it manufactures to be of good material and workmanship, and to be free of defects when properly installed and operated for a period of one year from the date of purchase. Remedy for breach of this warranty is limited to repair or replacement of the defective item(s). Any product which, under normal use and service, is proven to breach the warranty contained herein within ONE YEAR from date of sale will, upon examination by Chaney, and at its sole option, be repaired or replaced by Chaney. Transportation costs and charges for returned goods shall be paid for by the purchaser. Chaney hereby disclaims all responsibility for such transportation costs and charges. This warranty will not be breached, and Chaney will give no credit for products it manufactures which have received normal wear and tear, been damaged (including by acts of nature), tampered, abused, improperly installed, damaged in shipping, or repaired or altered by others than authorized representatives of Chaney.

The above-described warranty is expressly in lieu of all other warranties, express or implied, and all other warranties are hereby expressly disclaimed, including without limitation the implied warranty of merchantability and the implied warranty of fitness for a particular purpose. Chaney expressly disclaims all liability for special, consequential or incidental damages, whether arising in tort or by contract from any breach of this warranty. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Chaney further disclaims all liability from personal injury relating to its products to the extent permitted by law. By acceptance of any of Chaney's products, the purchaser assumes all liability for the consequences arising from their use or misuse. No person, firm or corporation is authorized to assume for Chaney any other liability in connection with the sale of its products. Furthermore, no person, firm or corporation is authorized to modify or waive the terms of this paragraph, and the preceding paragraph, unless done in writing and signed by a duly authorized agent of Chaney. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

For in-warranty claims: Chaney Instrument Co. 965 Wells St., Lake Geneva, WI 53147

ACU RITE®



Weather
Stations



Temperature
& Humidity



Weather
Alert Radio



Kitchen
Thermometers
& Timers



Clocks

It's more than accurate, it's **ACURITE**.


AcuRite offers an extensive assortment of precision instruments, designed to provide you with information you can depend on to
Plan your day with confidence™.

www.AcuRite.com

Printed in China
75071T INST 040215

©Chaney Instrument Co. All rights reserved. AcuRite is a registered trademark of the Chaney Instrument Co., Lake Geneva, WI 53147. All other trademarks and copyrights are the property of their respective owners. AcuRite uses patented technology. Visit www.AcuRite.com/patents for details.

Documents / Resources

	<p>AcuRite 75071T Intelli-Time Digital Clock [pdf] Instruction Manual 75071T, Intelli-Time Digital Clock</p>
--	--

References

- [Home -](#)
- [AcuRite Weather Monitoring | #1 Weather Station Brand in North America](#)
- [Patented Technology | AcuRite](#)

[Manuals+](#).