

# Adtran 17600030F1 841-t6 Service Delivery Gateway Wi-Fi Mesh Access Point / Remote Gateway User Manual

Home » ADTRAN » Adtran 17600030F1 841-t6 Service Delivery Gateway Wi-Fi Mesh Access Point / Remote Gateway User Manual ™



## **Contents**

- 1 ADTRAN 841-t6 Service Delivery Gateway
- 2 Overview
  - 2.1 Features
- 3 Installing the 841-t6 Gateway
  - 3.1 Package Contents
  - 3.2 Prior to Installation
  - 3.3 Required Tools
  - **3.4 Mounting Options**
  - 3.5 Connecting the 841-t6 Gateway
  - 3.6 Connecting the Power Supply
  - 3.7 Resetting the Gateway
- 4 Understanding the Status LEDs
  - 4.1 2.4GHz / 5GHz Status LEDs
  - 4.2 WPS Status LED
- **5 Product Specifications** 
  - **5.1 Electrical**
- 6 Documents / Resources
  - **6.1 References**
- 7 Related Posts

ADTRAN 841-t6 Service Delivery Gateway

Wi-Fi Mesh Access Point / Remote Gateway

August 2021 617600030F1-13A

P/N: 17600030F1



Read all warning, cautions, notes and installation instructions before installing or servicing this equipment.

The ADTRAN® 841-t6 is a carrier-class Dual-Band Wi-Fi 5 Gigabit Ethernet router, built to deliver top-end Wi-Fi 5 performance, true gigabit routing throughput, and advanced service delivery capabilities. This quick start describes how to install ADTRAN's 841-t6 Service Delivery Gateway.

The 841-t6 WiFi Mesh Access Point / Remote Gateway is an indoor gateway delivering premium multi-Gigabit services.

- "Installing the 841-t6 Gateway"
- "Understanding the Status LEDs"
- "Resetting the Gateway"

Figure 1 illustrates the front and back of the 841-t6 gateway.



Figure 1. Front and Back of the 841-t6 Gateway



WARNING indicates a hazard which, if not avoided, could result in death, injury or serious property damage.



CAUTION indicates a hazard which, if not avoided, could result in service interruption, damage to the equipment,

or minor property damage.



NOTES inform the user of additional, but important, information or features.

#### Features

The features of the 841-t6 gateway include the following:

- 1x Gigabit Ethernet (RJ-45) 2.5G WAN interface
- Subscriber interfaces
  - 1x Gigabit Ethernet (RJ-45) LAN interface
  - 1x USB 3.0 (Type A) Host port

## Installing the 841-t6 Gateway

The following are guidelines for basic installation of the 841-t6.



Refer to the national, state and local electrical codes for the requirements for power, grounding, wiring, and installation methods.



The product is intended for indoor use only. Ethernet, POTS cables, and attached equipment are intended for use within the same building with equipotential bonding, and not intended to be placed in separate buildings or structures. Failure to deploy as described could result in permanent damage from lightning or other electrical events and voids the warranty. Furthermore, all connections from outside of the building, such as old POTS wiring, must be disconnected prior to use.

## **Package Contents**

- ADTRAN's 841-t6 WiFi 5 Gigabit Router
- 12V DC power adapter

#### Prior to Installation

Before installing the equipment, inspect the gateway. If damage has occurred during shipping, file a claim with the carrier, and then contact ADTRAN Customer Support. For more information, refer to the product warranty available online at <a href="https://adtran/wp\_support\_warranty">https://adtran/wp\_support\_warranty</a>.

#### **Required Tools**

No special tools are required for installing the 841-t6 gateway.

## **Mounting Options**

There are two options to install the 841-t6: desktop and wall mount. Be sure to route and secure the fiber and cables in a manner that will prevent damage. These options are described below.

## **Desktop Installation**

The 841-t6 can be placed on a desk or table. The following table shows the recommended minimum distance (in feet and meters) between the gateway and household appliances to reduce interference.

| Household Appliance      | Recommended Minimum Distance (in feet and meters) |  |
|--------------------------|---|--|
| Microwave ovens          | 30 feet / 9 meters                                |  |
| Baby monitor – analog    | 20 feet / 6 meters                                |  |
| Baby monitor – digital   | 40 feet / 12 meters                               |  |
| Cordless phone – analog  | 20 feet / 6 meters                                |  |
| Cordless phone – digital | 30 feet / 9 meters                                |  |
| Bluetooth devices        | 20 feet / 6 meters                                |  |
| ZigBee                   | 20 feet / 6 meters                                |  |



Ensure that the 841-t6 does not come in contact with water or other liquids.



Ensure that the 841-t6 is not located in direct sunlight or next to any thermal obstructions.

## Wall Mount Installation

The 841-t6 can be mounted on a wall. Wall Mount Kit (17600192F1) can be ordered for mounting the 841-t6. Instructions are provided in the related Quick Start Guide (617600192F1-13A).

# Connecting the 841-t6 Gateway

Figure 2 illustrates the installation (connection) options for the 841-t6 gateway.



Figure 2. 841-t6 Gateway Installation Options (placeholder)

The following subscriber connections are available on the rear of the 841-t6:

- 1x Gigabit Ethernet (RJ-45 Connectors) LAN port
- 1x Gigabit Ethernet port (RJ-45 Connector) 2.5G WAN port
- 1x USB 3.0 (Type A Connector) SSC port

To connect the subscriber Ethernet interfaces, refer to Figure 2 and insert a Category 5E (or better) RJ-45 cable into the LAN port (labeled **LAN**) or the Gigabit Ethernet port (**2.5G WAN**) until there is an audible "click".

## **Connecting the Power Supply**

- 1. Connect the end of the power adapter to the **Power** port on the rear panel of the gateway
- 2. Plug other end of the power adapter into the wall outlet.
- 3. Press the On/Off switch.
- 4. Confirm that the power is connected properly. The **Power** LED should be lit on the front of the gateway.

## Resetting the Gateway

A reset button is available if the 814-v6 needs to be rebooted. To reboot the 841-t6, press the **Reset** button on the rear panel of the gateway for **5 seconds** or less. To reset the device to custom defaults, press the **Reset** button for **5 seconds** or more.

## **Understanding the Status LEDs**

The LEDs on the back panel of the 814-v6 gateway enable you to monitor the device status. This section describes the four types of LEDs available on the 814-v6 gateway. See Figure 1 for details.



Figure 1. Status LEDs

2.4GHz / 5GHz Status LEDs

The 2.4GHz and 5GHz (1 & 2) status LEDs indicate the state of the wireless connections on the gateway.

| LED                          | Color      | State    | Description                       |
|------------------------------|------------|----------|-----------------------------------|
| 2.4GHz / 5GHz-1 / 5GHz-<br>2 | Green None | On       | Wi-Fi radio is UP.                |
|                              |            | Flashing | Wi-Fi radio is transferring data. |
|                              |            | Off      | Wi-Fi connection is DOWN.         |

## **WPS Status LED**

The **WPS** status LED indicates the status of WPS (Wi-Fi protected setup).

| LED | Color | State    | Description             |
|-----|-------|----------|-------------------------|
| WPS | Green | On       | WPS is enabled.         |
|     |       | Flashing | WPS is passing traffic. |
|     | None  | Off      | WPS is not active.      |

## **Product Specifications**

## Electrical

- Power is provided by a 12V DC Power Adapter that is included with the 841-t6. The power adapter operates from a power source of 100 to 240V AC, 50 60 Hz. The nominal output is 12V DC +5% with a minimum current rating of 2.5 Amps, Amb. 40°C. For US and Canadian applications, a UL Listed limited power source (LPS) is required. For deployment outside of North America, an LPS specifically approved for that country, such as a CE Mark, is required.
- If a Class I adapter or switch is used to provided power, be sure that the power cord is firmly plugged into the socket and confirm the main earth connection.

Documentation for ADTRAN Network Solutions products is available for viewing and download directly from the ADTRAN Support Community website.

Go to: https://supportcommunity.adtran.com

ADTRAN offers training courses on our products, including customized training and courses taught at our facilities or at customer sites.

For inquiries, go to: <a href="http://adtran.com/training">http://adtran.com/training</a>

**Warranty:** ADTRAN will replace or repair this product within the warranty period if it does not meet its published specifications or fails while in service. Warranty information can be found online at <a href="https://www.adtran.com/warranty">www.adtran.com/warranty</a>.

**Trademarks:** Brand names and product names included in this document are trademarks, registered trademarks, or trade names of their respective holders.

Access additional safety information and product documentation using the QR code or website.



https://supportcommunity.adtran.com

ADTRAN CUSTOMER CARE: From within the U.S. 1.888.423.8726 From outside the U.S. +1 256.963.8716 PRICING AND AVAILABILITY 1.800.827.0807



Copyright © 2021 ADTRAN, Inc. All Rights Reserved.

# **Documents / Resources**



Adtran 17600030F1 841-t6 Service Delivery Gateway Wi-Fi Mesh Access Point / Remote Gateway [pdf] User Manual

17600030F1, HDC-17600030F1, HDC17600030F1, 841-t6 Service Delivery Gateway, Wi-Fi M esh Access Point, Remote Gateway

## References

- A Training
- ▲ My Adtran Log In
- O Home Adtran Support Community

