



# Advanced Semiconductor Engineering Chung Li Branch SCLCT06M Bluetooth Headset User Manual

[Home](#) » [Advanced Semiconductor Engineering Chung Li Branch](#) » [Advanced Semiconductor Engineering Chung Li Branch SCLCT06M Bluetooth Headset User Manual](#) 

## Advanced Semiconductor Engineering Chung Li Branch SCLCT06M Bluetooth Headset User Manual

### Contents

- [1 SCLCT06M User's Manual](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

## SCLCT06M User's Manual

### Power ON/OFF

**Turn on:** press the button -> You will hear "POWER ON" when powering on (the left and right ears should be turned on separately)

**Turn Off:** You must disconnect the device or mobile phone before turning off -> Press and hold the button to hear "Beep~Beep Beep", then release to hear power off

### How to repair:

Our headset will remember the phone or device.

To connect with the new device -> Make sure you hear power on -> Press and hold the button and you will hear "Beep~BeepBeep~ BeepBeepBeep" and then release it to find it on the phone.


### Speaker

Driver unit:30mm, dome type(CCAW Voice Coil)

Impedance: 24ohm at 1kHz

Sensitivity:98dB/mW

Frequency response:10Hz-24000Hz



### **FCC Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **FCC Caution:**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

### **FCC Radiation Exposure Statement**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End-user must follow the specific operating instructions for satisfying RF exposure compliance.

### **Documents / Resources**

<div data-bbox="150 107 268 123" data-label="Section-Header"><p>SCLCT06M User's Manual</p></div> <div data-bbox="150 123 268 152" data-label="Text"><p><b>Important:</b> Read the "Important Notes" in the "Important Notes" section of the manual. Please do not use the headset for extended periods of time. Please do not use the headset for extended periods of time.</p></div> <div data-bbox="150 152 268 168" data-label="Text"><p><b>Key Features:</b> The headset features a high-quality microphone and a comfortable ear cup. It is designed for extended use and provides excellent sound quality.</p></div> <div data-bbox="150 168 268 183" data-label="Text"><p><b>Model:</b> SCLCT06M</p></div> <div data-bbox="164 219 252 297" data-label="Image"></div>	<div data-bbox="317 154 1469 293" data-label="Text"><p><a href="#">Advanced Semiconductor Engineering Chung Li Branch SCLCT06M Bluetooth Headset [pdf] User Manual</a> AIP6MA, 2AYS4-AIP6MA, 2AYS4AIP6MA, SCLCT06M Bluetooth Headset, SCLCT06M, Bluetooth Headset</p></div>
---	---