



## AKISENS W S-HTS 0 0 1 Temperature Sensor User Guide

[Home](#) » [AKISENS](#) » AKISENS W S-HTS 0 0 1 Temperature Sensor User Guide 

### Contents

- [1 AKISENS W S-HTS 0 0 1 Temperature Sensor](#)
- [2 Insert a battery in the sensor](#)
- [3 Programming the sensor with the controller](#)
- [4 Sensor Failure](#)
- [5 FCC 15.105](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)



### AKISENS W S-HTS 0 0 1 Temperature Sensor



The sensor will detect the water, humidity, freezer, temperature and works with Aki Central platform .

#### Insert a battery in the sensor

Unscrew the sensor screw and open the case with a small screw driver.



**Insert an AA Battery in the sensor and close the cover.**

**Note :** Insert first the black jack in the hole (cover) of the sensor.

### **Programming the sensor with the controller**

1. The technician will pair the sensor with the controller
2. The technician will put the right information risk area ( like the dishwasher in the kitchen) in the web platform .  
( [www.akicentral.com](http://www.akicentral.com) )

### **Sensor Failure**

When a sensor failure occurs, try the following :

1. Check if the sensor is located at where it should be .
2. Check if there is any physical damage to the sensor.
3. Move the sensor more closer to the controller.
4. Replace the battery of the sensor if the Controller does not respond when the sensor is activated within short range.

### **SAFETY INFORMATION**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received , including interferences that may cause undesired operation.

### **FCC 15.105**

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna Increase the separation between the equipment and receiver Connect the equipment into an outlet on a circuit different from that to which the receiver is connected Consult the dealer or an experienced radio/TV technician for help.

## RSS GEN Sect 8.4

This device contains silence exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation subject to the following two conditions :

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device

CAN-00a3(B)/NMB-003(B)

### THREE YEAR WARRANTY


This product is guaranteed to be free of defects in materials and workmanship for 3 year from the date of purchase. If this product is defective , call 1 8 4 4 -333-70 18 for repair or replacement parts. Guarantee does not include normal wear and tear or batteries.

If you have any questions, problems or missing parts, please call AkiSens Customer Support: 9:00am – 5:00pm EST, Monday-Friday. ( 1 844-333-7018 Or e -m ail us at [iot@akisens.com](mailto:iot@akisens.com) )

[www.AkiSen.com](http://www.AkiSen.com)

**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. (FCC 15.21)

## Documents / Resources

	<p><a href="#">AKISENS W S-HTS 0 0 1 Temperature Sensor</a> [pdf] User Guide WSHTS001, 2ASQRWSHTS001, W S-HTS 0 0 1 Temperature Sensor, W S-HTS 0 0 1, Temperature Sensor</p>
--	---