



---

[Home](#) » [Analog Devices](#) » **ANALOG DEVICES LTC9111, IEEE 802.3cg SPoE PD Controller  
Owner's Manual** 

## **ANALOG DEVICES LTC9111, IEEE 802.3cg SPoE PD Controller Owner's Manual**



User Guide | EVAL-LTC9111-AZ

**UG-2343**

---

Evaluating the LTC9111, IEEE 802.3cg SPoE PD Controller

## Contents [ [hide](#) ]

- 1 FEATURES
- 2 ONLINE RESOURCES
- 3 GENERAL DESCRIPTION
- 4 EVALUATION BOARD PHOTOGRAPH
- 5 EVALUATION BOARD QUICK START PROCEDURE
  - 5.1 EVAL-LTC9111-AZ OPERATION
- 6 EVALUATION BOARD QUICK START PROCEDURE
- 7 EVAL-LTC9111-AZ DEMONSTRATION CIRCUIT
  - 7.1 SHIELD INSTALLATION
  - 7.2 INPUT POLARITY CORRECTION
  - 7.3 SPOE PD CLASS
  - 7.4 OVERVOLTAGE PROTECTION FOR 24V PDS
  - 7.5 SENSE SNUBBER
- 8 EVAL-LTC9111-AZ DEMONSTRATION CIRCUIT
  - 8.1 STBY SUPPLY
  - 8.2 ON-BOARD MICROCONTROLLER FOR PHY
  - 8.3 ON-BOARD 3.3V BUCK REGULATOR
  - 8.4 EXTERNAL SCCP HEADER
  - 8.5 LAB\_OUT CIRCUIT
  - 8.6 OPTIONAL HOTSWAP MOSFET PACKAGE
- 9 Documents / Resources
  - 9.1 References

## FEATURES

- ▶ IEEE 802.3cg-compliant SPoE PD
- ▶ Supports serial communication classification protocol (SCCP)

## ONLINE RESOURCES

- ▶ [Schematic, PCB layout, and bill of materials](#)

## GENERAL DESCRIPTION


The EVAL-LTC9111-AZ is an evaluation motherboard featuring the LTC9111, an IEEE 802.3cg-compliant single pair power over Ethernet (SPoE) powered device (PD) controller.

With the LTC9111 wide operating range of 2.3V to 60V, the EVAL- LTC9111-AZ may be configured with class jumpers to IEEE 802.3cg 24V power classes (Class 10 to Class 12) or 52V power classes (Class 13 to Class 15).

The EVAL-LTC9111-AZ motherboard headers (J1, J2, and J3) connect to SPoE shields, the [EVAL-10BT1L-MCS-AZ](#) (Class 10 to Class 14) or the [EVAL-10BT1L-MCS-BZ](#) (Class 15). The EVAL- LTC9111-AZ motherboard with a shield connects via a single pair Ethernet (SPE) cable to an IEEE 802.3cg SPoE power sourcing equipment (PSE) for power.

The EVAL-LTC9111-AZ incorporates both IEEE 802.3cg-compliant wakeup signature and SCCP-based classification.

## EVALUATION BOARD PHOTOGRAPH



*Figure 1. EVAL-LTC9111-AZ Evaluation Board Photograph*

PLEASE SEE THE LAST PAGE FOR AN IMPORTANT WARNING AND LEGAL TERMS AND CONDITIONS.

## REVISION HISTORY

7/2025—Revision 0: Initial Version

# EVALUATION BOARD QUICK START PROCEDURE

## EVAL-LTC9111-AZ OPERATION

The EVAL-LTC9111-AZ is an IEEE 802.3cg SPoE PD motherboard. Refer to Figure 2 to Figure 5 and Table 1 for proper equipment setup.

Refer to Figure 2 for the EVAL-LTC9111-AZ evaluation with an EN enabled DC-DC converter and Figure 3 for evaluation with a resistive or active load.

Follow these steps on how to connect the PD:

1. Set PD class with the CLASSV and CLASSC jumpers according to Table 1.
2. Align the [EVAL-10BT1L-MCS-AZ SPoE](#) (Class 10 to Class 14) shield or the [EVAL-10BT1L-MCS-BZ](#) (Class 15) SPoE shield over the headers on the EVAL-LTC9111-AZ motherboard as shown in Figure 4. Push down firmly on the shield until all headers are flush. Verify no pins are sticking out.

Note that the last two female pins of P1 (the longer connector) must be left floating.

3. Set the P4 jumper to CONNECT when using the EVAL-10BT1L-MCS-AZ SPoE (Class 10 to Class 14) shield to connect the on-board sense snubber; set the P4 jumper to DISCONNECT when using the EVAL-10BT1L-MCS-BZ SPoE (Class 15) shield to disconnect the on-board sense snubber.
4. Connect the output of the IEEE 802.3cg-compliant PSE to the SPoE shield. A compliant PSE classifies the EVAL-LTC9111-AZ SPoE PD which responds with the class set in Table 1. After connection is established, verify LED1 is lit. This LED indicates a successful classification followed by power-up.

**Table 1. Class Jumper Selection, PD Class, PD On Range, and PD Power**

CLASSV Jumper	CLASSC Jumper	PD Class	V <sub>ON</sub> (typ)	V <sub>OFF</sub> (typ)	Overvoltage (V <sub>OV</sub> (typ))	Maximum PD Input Power (P <sub>PD(MAX)</sub> )
GND	GND	10	17.5V	12V	38.5V	1.23W
GND	FLOAT	11				3.2W
GND	STBY	12				8.4W
STBY	GND	13	46V	30V	N/A <sup>1</sup>	7.7W
STBY	FLOAT	14				20W
STBY	STBY	15				52W

<sup>1</sup>N/A means not applicable.




Figure 2. Setup Diagram for the EVAL-LTC9111-AZ with EN Pin Enabled DC-DC Converter and Load

## EVALUATION BOARD QUICK START PROCEDURE




Figure 3. Setup Diagram for the EVAL-LTC9111-AZ with Resistive or Active Load




Figure 4. Alignment of SPoE Shield with the EVAL-LTC9111-AZ





side rectifiers and relies on external Schottky diodes for the high-side rectifiers. Active low-side rectification minimizes power losses and overcomes circuit start-up challenges posed by the constraints in the standard. Footprints for both dual-MOSFET (single package, default option) at Q1, and discrete 3mm × 3mm DFN MOSFETs at Q2 and Q4 (optional), are available on the PCB for the active low-side rectifiers.

**SPOE PD CLASS**

The LTC9111 SPoE PD class is configured by the CLASSC and CLASSV pins. CLASSV is a binary input, either low by connecting to GND or high by connecting to STBY. CLASSV is tied low for the 24V classes (Class 10 to Class 12), and high for the 54V classes (Class 13 to Class 15). CLASSC is a trinary input, set either low by connecting to GND, high by connecting to STBY, or high impedance by floating the pin. Refer to Table 1 for configuration options and Figure 6 for jumper location.



*Figure 6. EVAL-LTC9111-AZ CLASSC and CLASSV Jumpers*


**OVERVOLTAGE PROTECTION FOR 24V PDS**

When the LTC9111 is configured for Class 10 to Class 12 (that is, CLASSV pin is tied low), an overvoltage protection feature is enabled to protect downstream elements in the application from exposure to excessive voltage. When the input voltage exceeds VOV (38.5, typ), the gate of the external hot swap MOSFET turns off, regardless of the port

state.

## SENSE SNUBBER

A snubber between the SNS pins prevents high-frequency ringing when the rectifying diodes are reverse biased during SCCP logic transitions. On the EVAL-LTC9111-AZ motherboard, the P4 jumper connects or disconnects the sense snubber. Set the P4 jumper to CONNECT when using the EVAL-10BT1L-MCS-AZ SPoE shield (Class 10 to Class 14) to connect the sense snubber. Set the P4 jumper to DISCONNECT when using the EVAL-10BT1L-MCS-BZ SPoE shield (Class 15) as the sense snubber is already present on this SPoE shield. Refer to Figure 7 for jumper location.



*Figure 7. EVAL-LTC9111-AZ RC Snubber Jumper*

## EVAL-LTC9111-AZ DEMONSTRATION CIRCUIT

### STBY SUPPLY

An internal linear regulator produces a nominal 3.5V supply at the STBY pin. It is used to power internal control circuitry. The STBY pin has a capacitance of 2.2 $\mu$ F placed near the pin.

Note that any external load on the STBY pin during classification may discharge the capacitor and cause brownout. There must be no load on the STBY pin during classification.

### ON-BOARD MICROCONTROLLER FOR PHY

The EVAL-LTC9111-AZ PD motherboard includes an on-board microcontroller for configuring an Ethernet PHY located on the SPoE shields via the MDIO interface.




Note that the microcontroller is not required for the [LTC9111](#) operation.

The microcontroller is powered from the on-board 3.3V buck regulator and the MDIO interface is isolated on the SPoE shield. Header J7 is used for programming the microcontroller. Switch S1 is used for resetting the microcontroller.

### ON-BOARD 3.3V BUCK REGULATOR

The EVAL-LTC9111-AZ PD motherboard has an on-board buck converter that steps the LTC9111 output down to a 3.3V logic rail. This supply powers the SPoE shield and on-board microcontroller. An additional 3.5A load may be connected to the 3.3V/3.5A turret. Refer to Figure 8 for on-board 3.3V buck regulator location.



*Figure 8. EVAL-LTC9111-AZ On-Board 3.3V Buck Regulator*

### EXTERNAL SCCP HEADER

An external SCCP circuit may optionally perform classification instead of the LTC9111. The EXT SCCP header (J6) brings out the IN1 and IN2 inputs, as well as the STBY supply and GND. The external SCCP classification circuit may pull IN1 and IN2 to GND. The LTC9111 SCCP pull-down FETs (Q11 and Q12) must be disabled or uninstalled to not interfere with the external SCCP circuit. Refer to the [LTC4296-1](#) SCCP Wiki for more information on the classification protocol.

### LAB\_OUT CIRCUIT

During inrush, there can be significant transient power dissipation in the external MOSFET. Any load present before inrush is complete increases MOSFET stresses. LAB\_OUT– turret is a return path for resistive or active loads that are only connected after inrush has completed. The EN pin is held low then rises to 3.4V (typ) after inrush has completed. When EN is high, the LAB\_OUT circuit applies 12V to a power MOSFET gate which connects LAB\_OUT– to GND. Connect a resistive or active load between OUT+ and LAB\_OUT–.

Note that the user must not capacitively load LAB\_OUT–.

### OPTIONAL HOTSWAP MOSFET PACKAGE

Q13 provides an optional SOT-223 package footprint for the Hotswap MOSFET.



#### ESD Caution

**ESD (electrostatic discharge) sensitive device.** Charged devices and circuit boards can discharge without detection. Although this product features patented or proprietary protection circuitry, damage may occur on devices subjected to high energy ESD. Therefore, proper ESD precautions should be taken to avoid performance degradation or loss of functionality.

### Legal Terms and Conditions

By using the evaluation board discussed herein (together with any tools, components documentation or support materials, the “Evaluation Board”), you are agreeing to be bound by the terms and conditions set forth below (“Agreement”) unless you have purchased the Evaluation Board, in which case the Analog Devices Standard Terms and Conditions of Sale shall govern. Do not use the Evaluation Board until you have read and agreed to the Agreement. Your use of the Evaluation Board shall signify your acceptance of the Agreement. This Agreement is made by and between you (“Customer”) and Analog Devices, Inc. (“ADI”), with its principal place of business at One Analog Way, Wilmington, MA 01887-2356, U.S.A. Subject to the terms and conditions of the Agreement, ADI hereby grants to Customer a free, limited, personal, temporary, non-exclusive, non-sublicensable, non-transferable license to use the Evaluation Board FOR EVALUATION PURPOSES ONLY. Customer understands and agrees that the Evaluation Board is provided for the sole and exclusive purpose referenced above, and agrees not

to use the Evaluation Board for any other purpose. Furthermore, the license granted is expressly made subject to the following additional limitations: Customer shall not (i) rent, lease, display, sell, transfer, assign, sublicense, or distribute the Evaluation Board; and (ii) permit any Third Party to access the Evaluation Board. As used herein, the term "Third Party" includes any entity other than ADI, Customer, their employees, affiliates and in-house consultants. The Evaluation Board is NOT sold to Customer; all rights not expressly granted herein, including ownership of the Evaluation Board, are reserved by ADI. CONFIDENTIALITY. This Agreement and the Evaluation Board shall all be considered the confidential and proprietary information of ADI. Customer may not disclose or transfer any portion of the Evaluation Board to any other party for any reason. Upon discontinuation of use of the Evaluation Board or termination of this Agreement, Customer agrees to promptly return the Evaluation Board to ADI.

ADDITIONAL RESTRICTIONS. Customer may not disassemble, decompile or reverse engineer chips on the Evaluation Board. Customer shall inform ADI of any occurred damages or any modifications or alterations it makes to the Evaluation Board, including but not limited to soldering or any other activity that affects the material content of the Evaluation Board. Modifications to the Evaluation Board must comply with applicable law, including but not limited to the RoHS Directive. TERMINATION. ADI may terminate this Agreement at any time upon giving written notice to Customer. Customer agrees to return to ADI the Evaluation Board at that time. LIMITATION OF LIABILITY. THE EVALUATION BOARD PROVIDED HEREUNDER IS PROVIDED "AS IS" AND ADI MAKES NO WARRANTIES OR REPRESENTATIONS OF ANY KIND WITH RESPECT TO IT. ADI SPECIFICALLY DISCLAIMS ANY REPRESENTATIONS, ENDORSEMENTS, GUARANTEES, OR WARRANTIES, EXPRESS OR IMPLIED, RELATED TO THE EVALUATION BOARD INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, TITLE, FITNESS FOR A PARTICULAR PURPOSE OR NONINFRINGEMENT OF INTELLECTUAL PROPERTY RIGHTS. IN NO EVENT WILL ADI AND ITS LICENSORS BE LIABLE FOR ANY INCIDENTAL, SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES RESULTING FROM CUSTOMER'S POSSESSION OR USE OF THE EVALUATION BOARD, INCLUDING BUT NOT LIMITED TO LOST PROFITS, DELAY COSTS, LABOR COSTS OR LOSS OF GOODWILL. ADI'S TOTAL LIABILITY FROM ANY AND ALL CAUSES SHALL BE LIMITED TO THE AMOUNT OF ONE HUNDRED US DOLLARS (\$100.00). EXPORT. Customer agrees that it will not directly or indirectly export the Evaluation Board to another country, and that it will


comply with all applicable United States federal laws and regulations relating to exports. GOVERNING LAW. This Agreement shall be governed by and construed in accordance with the substantive laws of the Commonwealth of Massachusetts (excluding conflict of law rules). Any legal action regarding this Agreement will be heard in the state or federal courts having jurisdiction in Suffolk County, Massachusetts, and Customer hereby submits to the personal jurisdiction and venue of such courts. The United Nations Convention on Contracts for the International Sale of Goods shall not apply to this Agreement and is expressly disclaimed. All Analog Devices products contained herein are subject to release and availability.



©2025 Analog Devices, Inc. All rights reserved. Trademarks and registered trademarks are the property of their respective owners.

One Analog Way, Wilmington, MA 01887-2356, U.S.A.

## Documents / Resources

	<a href="#">ANALOG DEVICES LTC9111, IEEE 802.3cg SPoE PD Controller [pdf]</a> Owner's Manual EVAL-LTC9111-AZ, LTC9111 IEEE 802.3cg SPoE PD Controller, LTC9111 IEEE, 802.3cg SPoE PD Controller, SPoE PD Controller, PD Controller, Controller
---	---

## References

- [User Manual](#)

■ Analog Devices  
💎 802.3cg SPoE PD Controller, Analog Devices, controller, EVAL-LTC9111-AZ, LTC9111 IEEE, LTC9111 IEEE 802.3cg SPoE PD Controller, PD Controller, SPoE PD Controller

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.