

ANALOG DEVICES LTP8800-1A 54V Input High Current DC Power Module with PMBus Interface Instruction Manual


Home » Analog Devices » ANALOG DEVICES LTP8800-1A 54V Input High Current DC Power Module with PMBus Interface Instruction Manual

Contents

- 1 ANALOG DEVICES LTP8800-1A 54V Input High Current DC Power Module with PMBus Interface
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 Measurement Equipment Setup
- 5 Connect PC to DC3190A-A
- **6 Typical Performance Characteristics**
- **7 DESCRIPTION**
 - 7.1 GUI Download
- **8 BOARD PHOTO**
- 9 PERFORMANCE SUMMARY
- **10 QUICK START PROCEDURE**
- 11 CONNECT PC TO DC3190A-A
- 12 TYPICAL PERFORMANCE CHARACTERISTICS
- **13 PARTS LIST**
- **14 SCHEMATIC DIAGRAM**
- **15 REVISION HISTORY**
- 16 Documents / Resources
 - 16.1 References



ANALOG DEVICES LTP8800-1A 54V Input High Current DC Power Module with PMBus Interface



Product Information


Product Name	DC3190A-A
Description	LTP8800-1A 54V Input, High Current DC/DC Power

Product Usage Instructions

- 1. Connect the input power supply to VIN (45V to 65V) and GND.
- 2. Connect the auxiliary power supply to BIAS (7V) and GND.
- 3. Connect the auxiliary power supply to 3V3 (3.3V) and GND.
- 4. Connect the load from VOUT to GND.
- 5. Connect the DMMs to the input and outputs.
- 6. Adjust the load current within the operating range of 0A to 150A.
- 7. Observe the output voltage regulation, output voltage ripples, load transient response, and other parameters.
- 8. Connect the dongle and control the output voltages from the GUI. Refer to LTpowerPlay GUI for the LTP8800-1A Quick Start Guide for details.


Measurement Equipment Setup

Refer to Figure 1 for the proper measurement equipment setup.




Connect PC to DC3190A-A

Use a PC to reconfigure the power management features of the LTP8800-1A. LTpowerPlay software can be downloaded from: <u>LTpowerPlay</u>. To access technical support documents for Analog Devices Digital Power Products, visit the LTpowerPlay Help menu. Online help is also available through LTpowerPlay.



Typical Performance Characteristics

Measured LTP8800-1A efficiency at VIN = 54V, fSW = 1MHz, Forced Air Cooled with 500LFM:



DESCRIPTION

Demonstration circuit 3190A-A is a high current, high density, high-efficiency open-frame µModule® regulator with

45V to 65V input range. The demo board has an LTP™8800-1A μModule regulator which provides a microprocessor 0.75V voltage from 54V power distribution architecture with digital power system management. The maximum output current for the demo board is 150A. Please see the LTP8800-1A data sheet for more detailed information. DC3190A-A powers up to default settings and produces power based on configuration resistors without the need for any serial bus communication. This allows easy evaluation of the DC/DC converter. To fully explore the extensive power system management features of the part, download the GUI software LTpowerPlay® onto your PC and use ADI's I2C/SMBus/PMBus dongle DC1613A to connect to the board. LTpowerPlay allows the user to reconfigure the part on-the-fly and store the configuration in EEPROM, view telemetry of voltage, current, temperature and fault status.

GUI Download

The software can be downloaded from:

LTpowerPlay For more details and instructions of LTpowerPlay, please refer to LTpowerPlay GUI for LTP8800-1A Quick Start Guide.

Design files for this circuit board are available.

All registered trademarks and trademarks are the property of their respective owners.

BOARD PHOTO

Part marking is either ink mark or laser mark

PERFORMANCE SUMMARY

Specifications are at TA = 25°C, Air cooling 400LFM

PARAMETER	CONDITIONS	MIN	TYP	MAX	UNITS
Input Voltage Range V _{IN}		45		65	V
Output Voltage		0.746	0.75	0.754	V
Default Switching Frequency		0.925	1.0	1.075	MHz
Maximum Output Current	Derating is Necessary for Certain V _{IN} and Thermal Conditions, I _{OUT} = 150A		150		A
Converter Efficiency	V _{IN} = 54V • f _{SW} = 1MHz, V _{OUT} = 0.75V, I _{OUT} = 150A		85.6		%

QUICK START PROCEDURE

Demonstration circuit 3190A-A is easy to set up to evalu-ate the performance of the LTP8800-1A.

Refer to Figure 1 for the proper measurement equipment setup and follow the procedure below:

- 1. With power off, connect the input power supply to VIN (45V to 65V) and GND.
- 2. With power off, connect the auxiliary power supply to BIAS (7V) and GND.
- 3. With power off, connect the auxiliary power supply to 3V3 (3.3V) and GND.
- 4. With power off, connect the load from VOUT to GND.
- 5. Connect the DMMs to the input and outputs.
- 6. Turn on the auxiliary power supply and the input power supply and check for the proper output voltage. VOUT should be 0.75V ±0.5%.
- 7. Once the input and output voltages are properly estab-lished, adjust the load current within the operating range of 0A to 150A. Observe the output voltage regulation, output voltage ripples, load transient response and other parameters.
- 8. Connect the dongle and control the output voltages from the GUI. See LTpowerPlay GUI for the LTP8800-1A

Note: When measuring the output or input voltage ripple, do not use the long ground lead on the oscil-loscope probe. See Figure 2 for the proper scope probe technique. Short, stiff leads need to be soldered to the (+) and (-) terminals of an output capacitor. The probe's ground ring needs to touch the (-) lead and the probe tip needs to touch the (+) lead.




Figure 1. Proper Measurement Equipment Setup




Figure 2. Measuring Output Voltage Ripple

CONNECT PC TO DC3190A-A

Use a PC to reconfigure the power management features of the LTP8800-1A such as: nominal VOUT, margin set points, OV/UV limits, temperature fault limits, sequenc-ing parameters, the fault log, fault responses, GPIOs and other functionalities. LTpowerPlay utilizes the DC1613A USB-to-SMBus controller to communicate with one of demo system, or a customer board. The software also provides an automatic update feature to keep the software

current with the latest set of device drivers and docu-mentation. The LTpowerPlay software can be downloaded from: LTpowerPlay. To access technical support documents for Analog Devices Digital Power Products, visit the LTpowerPlay Help menu. Online help also available through the LTpowerPlay.




Figure 3. LTpowerPlay Main Interface

TYPICAL PERFORMANCE CHARACTERISTICS




Figure 4. Measured LTP8800-1A Efficiency at VIN = 54V, fSW = 1MHz, Forced Air Cooled with 500LFM




Figure 5. LTP8800-1A Thermal Performance at VIN = 54V, ILOAD = 150A, TA = 25°C, 500LFM Forced Airflow




Figure 6. LTP8800-1A Thermal Performance at VIN = 54V, ILOAD = 150A, TA = 25°C, 900LFM Forced Airflow




Figure 7. LTP8800-1A Load Transient Responses with Load Steps 0A to 37.5A to 0A at $di/dt = 37.5A/\mu s$





Figure 8. LTP8800-1A DC3190A-A Output Voltage Ripple Measured Through J3 (54V Input, IOUT = 150A, 20MHz BW Limit)

PARTS LIST

ITEM	QTY	REFERENCE	PART DESCRIPTION	MANUFACTURER/PART NUMBER	
Requir	ed Circui	it Components			
1	18	C5-C22	CAP, 10µF, X7S, 6.3V, 20%, 0603	TDK, C1608X7S0J106M080AC	
2	5	C45, C46, C76-C78	CAP., 2.2µF, X7R, 100V, 10%, 1206	SAMSUNG, CL31B225KCHSNNE	
3	1	C47	CAP., 22µF, ALUM, 100V, 20%, 8mm × 10.2mm, SMD, RADIAL, AEC-Q200, CE-BS	SUN ELECTRONIC INDUSTRIES CORP, 100CE22BS	
4	1	C48	CAP., 10µF, X7S, 16V, 10%, 0805	MURATA, GRM21BC71C106KE11L	
5	1	C49	CAP., 2.2µF, X7R, 16V, 10%, 0805	KEMET, C0805C225K4RACTU	
6	4	C52-C55	CAP, 100µF, X5R, 6.3V, 20%, 1206	TDK, C3216X5R0J107M160AB	
7	4	C58-C61	CAP, 100µF, X6S, 6.3V, 20%, 1210	SAMSUNG, CL32X107MQVNNNE	
8	10	C66-C75	CAP, 560µF, ALUM POLY, SP-CAP, 2V, 20%, 7343	PANASONIC, EEFGX0D561R	
9	1	CVS	CAP, 100pF, X7R, 16V, 10%, 0603	AVX, 0603YC101KAT2A	
10	4	J6-J9	EVAL BOARD STUD HARDWARE SET, #10-32	ANALOG DEVICES, 720-0010	
11	1	LB1	LABEL SPEC, DEMO BOARD SERIAL NUMBER	BRADY, THT-96-717-10	
12	4	M1-M4	XSTR., MOSFET, N-CH, 25V, 70A, LFPAK55, POWER-S08	NEXPERIA, PSMN5R4-25YLDX	
13	4	R1-R4	RES., 24.9Ω, 1%, 1/10W, 0603, AEC-Q200	PANASONIC, ERJ3EKF24R9V	
14	8	R5-R8, R13-R16	RES., 200Ω, 1%, 1/10W, 0603	VISHAY, CRCW0603200RFKEA	
15	4	R9-R12	RES., 0.006Ω, 1%, 3W, 2512, LONG-SIDE TERM., METAL, SENSE, AEC-Q200	SUSUMU, KRL6432E-M-R006-F-T1	
16	1	R17	RES., 49.9Ω, 1%, 1/10W, 0603	PANASONIC, ERJ3EKF49R9V	
17	4	R18-R21	RES., 4.99k, 1%, 1/10W, 0603, AEC-Q200	PANASONIC, ERJ3EKF4991V	
18	1	R25	RES., 750Ω, 1%, 1/10W, 0603, AEC-Q200	STACKPOLE ELECTRONICS, INC., RMCF0603FT750R	
19	1	R26	RES., 10k, 1%, 1/10W, 0603, AEC-Q200	VISHAY, CRCW060310K0FKEA	
20	1	R27	RES., 10k, 1%, 1/16W, 0402, AEC-Q200	VISHAY, CRCW040210K0FKED	
21	1	R31	RES., 1k, 0.1%, 1/10W, 0603, THIN-FILM	YAGEO, RT0603BRD071KL	
22	1	R32	RES., 2k, 0.1%, 1/10W, 0603, METAL FILM, AEC-Q200	PANASONIC, ERA3AEB202V	
23	1	R33	RES., 7.5Ω, 1%, 1/10W, 0603	YAGEO, RC0603FR-077R5L	
24	1	RSN	RES., 0Ω, 1/10W, 0603, AEC-Q200	PANASONIC, ERJ3GEY0R00V	
25	1	RSP	RES., 1Ω, 1%, 1/10W, 0603, AEC-Q200	NIC, NRC06F1R00TRF	
26	1	U1	IC, 165A DC/DC µModule REG., OPEN-FRAME, 22mm × 24mm, SMD	ANALOG DEVICES, LTP8800-1AIPV#PBF	
Additio	nal Dem	o Board Circuit Component	5		
1	0	C23-C34	CAP., 22µF, FEEDTHRU, 4V, 20%, 05035, SMD, 3-TERM., EMI FILTER, 2A	MURATA, NFMJMPC226R0G3D	
2	0	C62-C65	CAP., OPTION,1206		
3	0	CFF	CAP, OPTION,0603		
4	0	D1	DIODE, OPTION, SOD-323		
5	1	PCB1	PCB, DC3190A	ADI APPROVED SUPPLIER, 600-DC3190A	
6	0	R22, R34, R37-R39, RFF	RES., OPTION, 0603		
ITEM	QTY	REFERENCE	PART DESCRIPTION	MANUFACTURER/PART NUMBER	
lardwar	e: For D	emo Board Only			
1	12	E3-E14	TEST POINT, TURRET, 0.064" MTG. HOLE, PCB 0.062 THK	MILL-MAX, 2308-2-00-80-00-07-0	
2	2	J1, J3	CONN., RF, BNC, RCPT, JACK, 5-PIN, ST, THT, 50ΩS	AMPHENOL RF, 112404	
3	1	J2	CONN., HDR, MALE, 1×3, 2.54mm, VERT, ST, THT	SAMTEC, TSW-103-07-L-S	
4	1	J4	CONN., HDR, SHROUDED, MALE, 1×4, 2.54mm, VERT, ST, THT	AMPHENOL, 69167-104HLF	
5	1	J5	CONN., SOCKET, FEMALE, 2×12, 2mm, SMD, BOTTOM ENTRY	SAMTEC, CLT-112-02-F-D-BE-A-K-TR	
6	2	J10, J11	CONN., BANANA JACK, FEMALE, THT, NON- INSULATED, SWAGE, 0.218"	KEYSTONE, 575-4	
7	4	MH1-MH4	STANDOFF, NYLON, SNAP-ON, 0.375"	KEYSTONE, 8832	
8	1	STNCL1	TOOL, STENCIL, 700-DC3190A-A	ADI APPROVED SUPPLIER, 830-DC3190A-A	

SCHEMATIC DIAGRAM



Information furnished by Analog Devices is believed to be accurate and reliable. However, no responsibility is assumed by Analog Devices for its use, nor for any infringements of patents or other rights of third parties that may result from its use. Specifications subject to change without notice. No license is granted by implication or otherwise under any patent or patent rights of Analog Devices.

REVISION HISTORY

REV	DATE	DESCRIPTION	PAGE NUMBER
Α	08/23	Release for product intro.	_

ESD Caution

ESD (electrostatic discharge) sensitive device. Charged devices and circuit boards can discharge without detection. Although this product features patented or proprietary protection circuitry, damage may occur on devices subjected to high energy ESD. Therefore, proper ESD precautions should be taken to avoid performance degradation or loss of functionality.

Legal Terms and Conditions

By using the evaluation board discussed herein (together with any tools, components documentation or support materials, the "Evaluation Board"), you are agreeing to be bound by the terms and conditions set forth below ("Agreement") unless you have purchased the Evaluation Board, in which case the Analog Devices Standard Terms and Conditions of Sale shall govern. Do not use the Evaluation Board until you have read and agreed to the Agreement. Your use of the Evaluation Board shall signify your acceptance of the Agreement. This Agreement is made by and between you ("Customer") and Analog Devices, Inc. ("ADI"), with its principal place of business at One Technology Way, Norwood, MA 02062, USA. Subject to the terms and conditions of the Agreement, ADI hereby grants to Customer a free, limited, personal, temporary, non-exclusive, non-sublicensable, non-

transferable license to use the Evaluation Board FOR EVALUATION PURPOSES ONLY. Customer understands and agrees that the Evaluation Board is provided for the sole and exclusive purpose referenced above, and agrees not to use the Evaluation Board for any other purpose. Furthermore, the license granted is expressly made subject to the following additional limitations: Customer shall not (i) rent, lease, display, sell, transfer, assign, sublicense, or distribute the Evaluation Board; and (ii) permit any Third Party to access the Evaluation Board. As used herein, the term "Third Party" includes any entity other than ADI, Customer, their employees, affiliates and in-house consultants. The Evaluation Board is NOT sold to Customer; all rights not expressly granted herein, including ownership of the Evaluation Board, are reserved by ADI. CONFIDENTIALITY. This Agreement and the Evaluation Board shall all be considered the confidential and proprietary information of ADI. Customer may not disclose or transfer any portion of the Evaluation Board to any other party for any reason. Upon discontinuation of use of the Evaluation Board or termination of this Agreement, Customer agrees to promptly return the Evaluation Board to ADI. ADDITIONAL RESTRICTIONS. Customer may not disassemble, decompile or reverse engineer chips on the Evaluation Board. Customer shall inform ADI of any occurred damages or any modifications or alterations it makes to the Evaluation Board, including but not limited to soldering or any other activity that affects the material content of the Evaluation Board. Modifications to the Evaluation Board must comply with applicable law, including but not limited to the RoHS Directive. TERMINATION. ADI may terminate this Agreement at any time upon giving written notice to Customer. Customer agrees to return to ADI the Evaluation Board at that time. LIMITATION OF LIABILITY. THE EVALUATION BOARD PROVIDED HEREUNDER IS PROVIDED "AS IS" AND ADI MAKES NO WARRANTIES OR REPRESENTATIONS OF ANY KIND WITH RESPECT TO IT. ADI SPECIFICALLY DISCLAIMS ANY REPRESENTATIONS, ENDORSEMENTS, GUARANTEES, OR WARRANTIES, EXPRESS OR IMPLIED, RELATED TO THE EVALUATION BOARD INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, TITLE, FITNESS FOR A PARTICULAR PURPOSE OR NONINFRINGEMENT OF INTELLECTUAL PROPERTY RIGHTS. IN NO EVENT WILL ADI AND ITS LICENSORS BE LIABLE FOR ANY INCIDENTAL, SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES RESULTING FROM CUSTOMER'S POSSESSION OR USE OF THE EVALUATION BOARD, INCLUDING BUT NOT LIMITED TO LOST PROFITS, DELAY COSTS, LABOR COSTS OR LOSS OF GOODWILL. ADI'S TOTAL LIABILITY FROM ANY AND ALL CAUSES SHALL BE LIMITED TO THE AMOUNT OF ONE HUNDRED US DOLLARS (\$100.00). EXPORT. Customer agrees that it will not directly or indirectly export the Evaluation Board to another country, and that it will comply with all applicable United States federal laws and regulations relating to exports. GOVERNING LAW. This Agreement shall be governed by and construed in accordance with the substantive laws of the Commonwealth of Massachusetts (excluding conflict of law rules). Any legal action regarding this Agreement will be heard in the state or federal courts having jurisdiction in Suffolk County, Massachusetts, and Customer hereby submits to the personal jurisdiction and venue of such courts. The United Nations Convention on Contracts for the International Sale of Goods shall not apply to this Agreement and is expressly disclaimed.

www.analog.com

ANALOG DEVICES, INC. 2023

Documents / Resources



ANALOG DEVICES LTP8800-1A 54V Input High Current DC Power Module with PMBus Interface [pdf] Instruction Manual

DC3190A-A, LTP8800-1A 54V Input High Current DC Power Module with PMBus Interface, LTP 8800-1A High Current DC Power Module with PMBus Interface, 54V Input High Current DC Power Module with PMBus Interface, High Current DC Power Module with PMBus Interface, High Current DC Power Module, DC Power Module, DC Module, Module

References

- Mixed-signal and digital signal processing ICs | Analog Devices
- Mixed-signal and digital signal processing ICs | Analog Devices
- LTpowerPlay | Analog Devices

