

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [iRiver](#) /
- › [iRiver T30 512 MB MP3 Player User Manual](#)

iRiver T30

iRiver T30 512 MB MP3 Player User Manual

Model: T30

INTRODUCTION

The iRiver T30 is a compact and portable MP3 player designed for on-the-go music playback and voice recording. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance.



Figure 1: iRiver T30 MP3 Player and included accessories.

PACKAGE CONTENTS

Verify that all items are present in the package:

- iRiver T30 Main Unit
- iRiver Earphones
- USB 2.0 Interface Cable
- Printed Manual
- Installation CD
- AAA Battery

SETUP

1. Battery Installation

1. Locate the battery compartment on the back of the iRiver T30.
2. Open the battery compartment cover.

3. Insert one AAA battery, ensuring correct polarity (+ and - terminals).
4. Close the battery compartment cover securely.

Note: The iRiver T30 operates on a single AAA battery, providing up to 24 hours of playback.

2. Connecting to a Computer

To transfer music files and manage your device, connect the iRiver T30 to a computer using the supplied USB cable.

1. Ensure your computer meets the minimum system requirements: Windows XP (SP1 or higher) and Windows Media Player 10.
2. Connect the small end of the USB cable to the USB port on the iRiver T30.
3. Connect the standard USB end of the cable to an available USB port on your computer.
4. The device will be recognized as a removable storage device.

3. Software Installation

The included Installation CD contains necessary drivers and software for your iRiver T30.

1. Insert the Installation CD into your computer's CD-ROM drive.
2. Follow the on-screen prompts to install the required software.
3. Restart your computer if prompted.

OPERATING INSTRUCTIONS

1. Powering On/Off

- To power on: Press and hold the Play/Pause button until the screen illuminates.
- To power off: Press and hold the Play/Pause button until the screen turns off.

2. Navigating Menus

Use the navigation buttons (Up, Down, Left, Right) to browse through menus and select options. The Play/Pause button typically confirms selections.



Figure 2: iRiver T30 display screen.

3. Transferring Music Files

The iRiver T30 supports MP3, WMA, and OGG music files. It is also PlaysForSure certified for subscription-based music services.

1. Connect the iRiver T30 to your computer (refer to "Connecting to a Computer" in the Setup section).
2. Open Windows Media Player 10 or drag and drop files directly to the iRiver T30's removable disk folder.
3. Once files are transferred, safely eject the device from your computer before disconnecting the USB cable.

4. Music Playback

- Navigate to the "Music" menu.
- Select a song or playlist using the navigation buttons.
- Press the Play/Pause button to start playback.
- Use the Volume buttons to adjust the sound level.
- Press the Skip buttons to move to the next or previous track.
- The iRiver T30 features enhanced 3D audio (SRS WOW) for an improved listening experience.

5. Voice Recorder

The iRiver T30 includes a built-in voice recorder.

1. Navigate to the "Record" or "Voice Memo" menu.
2. Press the Record button (often the Play/Pause button or a dedicated button) to start recording.
3. Press the button again to stop recording.
4. Recorded files are saved internally and can be transferred to your computer.

6. Recording Music from Any Source (Line-in Recording)

The iRiver T30 allows direct recording from external audio sources without a PC.

1. Connect an audio source (e.g., CD player, cassette player) to the Line-in jack on the iRiver T30 using an appropriate audio cable (not included).
2. Navigate to the "Record" menu and select "Line-in Record".
3. Adjust the recording volume if available in the settings.
4. Start playback on your audio source and press the Record button on the T30.
5. Press the Record button again to stop.

MAINTENANCE

1. Cleaning

- Wipe the device with a soft, dry cloth.
- Do not use liquid cleaners or solvents.

2. Battery Care

- Replace the AAA battery when the low battery indicator appears.
- Remove the battery if the device will not be used for an extended period to prevent leakage.

3. Firmware Updates

Periodically check the official iRiver website for available firmware updates. Firmware updates can improve performance and add new features. Follow the instructions provided on the iRiver website carefully when performing updates.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Device does not power on.	Ensure the AAA battery is inserted correctly with proper polarity. Replace with a fresh AAA battery. Press and hold the Power/Play button for a few seconds.
"No Music File" displayed.	Connect the device to a computer and verify that music files (MP3, WMA, OGG) have been transferred to the player's storage. Ensure files are not corrupted.

Problem	Possible Cause / Solution
Cannot transfer files to the device.	Check USB cable connection. Ensure your computer meets system requirements (Windows XP SP1+, WMP 10). Install drivers from the Installation CD. Try a different USB port on your computer.
Poor battery life.	Ensure you are using a fresh, high-quality AAA battery. Reduce backlight duration in settings if possible (some models may have limited options). Avoid extreme temperatures.

SPECIFICATIONS

- **Model Name:** T30
- **Memory Storage Capacity:** 512 MB
- **Supported Audio Formats:** MP3, WMA, OGG
- **Connectivity Technology:** USB 2.0
- **Special Feature:** Voice Recorder, Line-in Recording
- **Battery Type:** 1 x AAA
- **Battery Life:** Up to 24 hours (playback)
- **Display:** 0.96 inch screen
- **System Requirements:** Windows XP (SP1 or higher), Windows Media Player 10, USB Port
- **Included Components:** Main Unit, Headphones, USB cable
- **Dimensions:** Approximately 11 x 9 x 4 inches (Package)
- **Weight:** Approximately 12 ounces (Item)

WARRANTY AND SUPPORT

Warranty Information

The iRiver T30 MP3 Player comes with a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, warranty service, or further inquiries, please visit the official iRiver support website or contact their customer service department. Refer to the contact information provided in your product packaging or on the iRiver website.

