



Manuals.plus /

- › Casio /
- › Casio Collection Wake Up Timer Digital Alarm Clock DQ-583-1EF User Manual

Casio DQ-583-1EF

Casio Collection Wake Up Timer Digital Alarm Clock DQ-583-1EF User Manual

Model: DQ-583-1EF

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Casio Collection Wake Up Timer Digital Alarm Clock, model DQ-583-1EF. Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your device.



Figure 1: Front view of the Casio DQ-583-1EF Digital Alarm Clock, showing the digital display, time setting buttons (HR, MIN), and the top snooze/light button.

SETUP

1. Battery Installation

The Casio DQ-583-1EF alarm clock requires one AA battery for operation. A battery is typically included with the product.

1. Locate the battery compartment cover on the back of the clock.
2. Slide or unclip the cover to open the compartment.
3. Insert one AA battery, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Close the battery compartment cover securely.

2. Initial Time Setting

After installing the battery, the display will show a default time. You will need to set the current time.

1. On the side or back of the clock, locate the mode switch. Set it to the "TIME SET" position.
2. Press the **HR** button to adjust the hour. Press and hold to advance rapidly.
3. Press the **MIN** button to adjust the minute. Press and hold to advance rapidly.
4. Once the correct time is set, return the mode switch to the "NORMAL" or "ALARM OFF" position.
5. Note the AM/PM indicator if using 12-hour format.

OPERATING INSTRUCTIONS

1. Setting the Alarm

1. Locate the mode switch on the side or back of the clock. Set it to the "ALARM SET" position.
2. The alarm time will now be displayed.
3. Press the **HR** button to adjust the alarm hour.
4. Press the **MIN** button to adjust the alarm minute.
5. After setting the desired alarm time, return the mode switch to the "NORMAL" position.

2. Activating/Deactivating the Alarm

To turn the alarm on or off, use the alarm switch, typically located on the side or back of the clock.

- Slide the switch to "ALARM ON" to activate the alarm. An alarm indicator (e.g., a bell icon or "ON") will appear on the display.
- Slide the switch to "ALARM OFF" to deactivate the alarm. The alarm indicator will disappear.

3. Using the Snooze/Light Function

The large button on the top of the clock serves two primary functions:

- **Snooze:** When the alarm sounds, press the top button to temporarily stop the alarm. The alarm will sound again after a few minutes (typically 5-10 minutes, depending on the model). The "SNZ" indicator will flash on the display.
- **Light:** Press the top button at any time to illuminate the display for a few seconds, allowing you to read the time in low-light conditions.

4. 12-Hour / 24-Hour Format Selection

Your clock may allow you to switch between 12-hour (with AM/PM indicator) and 24-hour (military time) formats.

- While in "TIME SET" mode, repeatedly press the **HR** button. The display will cycle through 12-hour and 24-hour formats. Stop when your preferred format is shown.
- Alternatively, some models have a dedicated switch for this function, usually labeled "12/24H" or similar.

MAINTENANCE

1. Cleaning

To maintain the appearance of your clock:

- Wipe the clock with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the casing or display.

2. Battery Replacement

When the display becomes dim or the alarm sound weakens, it is time to replace the battery.

- Follow the battery installation steps outlined in the "Setup" section.
- Always use a fresh AA battery.
- Dispose of used batteries according to local regulations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	Low or dead battery; incorrect battery insertion.	Replace the battery with a new AA battery. Ensure correct polarity (+/-).
Alarm does not sound.	Alarm is not activated; alarm time is incorrect; low battery.	Ensure the alarm switch is set to "ALARM ON". Verify the alarm time is set correctly. Replace battery if low.
Time is incorrect.	Time was not set correctly; accidental button press.	Re-set the time following the "Initial Time Setting" instructions.
Snooze function not working.	Alarm not active; button not pressed firmly.	Ensure the alarm is active and sounding. Press the top button firmly.

SPECIFICATIONS

- **Model:** DQ-583-1EF
- **Brand:** Casio
- **Display Type:** Digital
- **Power Source:** Battery Powered (1 x AA battery)
- **Special Feature:** Beep alarm, Snooze, Light
- **Dimensions (LxWxH):** 10.5 x 4.3 x 7.1 Centimeters
- **Weight:** 70 g (0.07 Kilograms)
- **Frame Material:** Resin
- **Color:** Black
- **Mounting Type:** Tabletop

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Casio website. Keep your purchase receipt as proof of purchase.

For further assistance, you may contact Casio customer service through their official channels. Please have your model number (DQ-583-1EF) ready when contacting support.