

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ZIPRO](#) /

› [Zipro Pacemaker Treadmill User Manual - Bluetooth, LED Display, Folding, 150kg Capacity](#)

## ZIPRO Pacemaker 5942805

# Zipro Pacemaker Treadmill User Manual

Model: Pacemaker 5942805

## 1. INTRODUCTION

Thank you for choosing the Zipro Pacemaker Treadmill. This manual provides essential information for the safe assembly, operation, and maintenance of your new fitness equipment. Please read this manual thoroughly before using the treadmill and keep it for future reference.

The Zipro Pacemaker Treadmill is designed for home use, offering a robust construction, a wide running belt, and a powerful motor for various training intensities. Its folding design and transport wheels ensure convenient storage and mobility.

## 2. SAFETY INSTRUCTIONS

**WARNING: Before starting any exercise program, consult your physician, especially if you have pre-existing health conditions.**

- Always place the treadmill on a flat, stable surface with adequate clearance around it (at least 2 meters behind and 0.6 meters on each side).
- Keep children and pets away from the treadmill during operation.
- Wear appropriate athletic footwear and clothing. Avoid loose clothing that could get caught in moving parts.
- Always use the safety key/clip. Attach the clip to your clothing before starting your workout. In case of an emergency, pulling the safety key will immediately stop the treadmill.
- Do not step on or off the treadmill while the belt is moving. Start at a slow speed and gradually increase.
- Hold onto the handrails for balance, especially when starting or adjusting speed/incline.
- Do not attempt to service the treadmill yourself. Refer to qualified service personnel for repairs.
- Ensure the power cord is not damaged or placed under the treadmill.
- Maximum user weight capacity: 150 kg.

## 3. PACKAGE CONTENTS

Verify that all components are present in the package:

- 1 x Zipro Pacemaker Treadmill (main unit)
- 1 x User Manual
- Assembly tools (if applicable)
- Safety Key

## 4. SETUP AND ASSEMBLY

The Zipro Pacemaker Treadmill features a convenient folding design for easy setup and storage. Follow these general steps for assembly:

1. **Unpacking:** Carefully remove all components from the packaging.
2. **Positioning:** Place the treadmill on a level surface in your desired workout area. Ensure sufficient space around the unit.
3. **Unfolding:** Gently lower the running deck from its folded position until it locks into place. Refer to the specific instructions in your included manual for the exact unfolding mechanism.
4. **Securing Components:** Attach any loose components such as the console, handrails, or safety key holder as per the detailed assembly instructions.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet.



Image: The Zipro Pacemaker Treadmill in its fully unfolded, ready-to-use position. This shows the overall structure including the running deck, console, and uprights.



Image: A user demonstrating the folding mechanism of the Zipro Pacemaker Treadmill. The running deck is lifted upwards, allowing for compact storage.



Image: The Zipro Pacemaker Treadmill shown in its folded position, viewed from the side. This highlights its space-saving design for storage.

## 5. OPERATING INSTRUCTIONS

### 5.1 Console Overview

The treadmill features an intuitive LED display console that shows key workout metrics.



Image: A detailed view of the Zipro Pacemaker Treadmill's LED console, displaying speed, time, distance, calories, and pulse. It also shows control buttons and the safety key slot.



Image: The treadmill console with a smartphone placed in the integrated holder, demonstrating the device's multimedia capabilities and connectivity.



Image: A close-up view of the USB port and cup holder integrated into the treadmill console, providing convenience for charging devices and holding beverages.

## 5.2 Starting a Workout

1. Ensure the treadmill is plugged in and the safety key is in place.
2. Step onto the side rails of the treadmill.
3. Press the **START** button on the console. The belt will begin to move at a low speed.
4. Carefully step onto the moving belt and begin walking.

## 5.3 Adjusting Speed and Incline

- **Speed:** Use the **SPEED +** and **SPEED -** buttons to adjust the belt speed from 1 km/h to 22 km/h. Quick speed buttons may also be available for instant adjustments.
- **Incline:** Use the **INCLINE +** and **INCLINE -** buttons to adjust the incline level (0-15 levels). Quick incline buttons may also be available.

## 5.4 Stopping a Workout

- Press the **STOP** button to gradually slow down and stop the treadmill.
- In an emergency, pull the safety key to immediately stop the treadmill.

## 5.5 Using Bluetooth and USB

- **Bluetooth:** The treadmill supports Bluetooth connectivity. Pair your device to stream audio through the integrated speakers or connect to compatible fitness applications like Kinomap for interactive workouts.
- **USB:** Use the USB port to charge your mobile devices during your workout.



Image: The treadmill console displaying the Kinomap application logo, indicating compatibility with interactive training apps via Bluetooth.



Image: A tablet placed on the console holder, displaying the Kinomap app interface, showcasing the treadmill's integration with fitness applications.

## 6. PROGRAMS AND FEATURES

The Zipro Pacemaker Treadmill offers a variety of training options to suit your fitness goals:

- **Pre-set Programs:** The computer is equipped with 99 pre-set workout programs designed for various fitness levels and goals.
- **User Programs:** Create and save up to 3 individual user programs to customize your training experience.
- **Heart Rate Monitoring:** Integrated pulse sensors in the handrails allow you to monitor your heart rate during your workout.
- **Adjustable Incline:** Simulate uphill running with 15 levels of electronic incline adjustment.
- **Wide Speed Range:** Speeds from 1 to 22 km/h accommodate walking, jogging, and high-intensity running.

## 7. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your treadmill.

- **Cleaning:** Wipe down the console and other surfaces with a damp cloth after each use. Avoid abrasive cleaners.
- **Belt Lubrication:** Periodically lubricate the running belt according to the instructions in your specific manual (usually every few months depending on usage). This reduces friction and extends belt life.

- **Belt Tension and Alignment:** Check the running belt tension and alignment regularly. Adjust if necessary to prevent slipping or rubbing.
- **Motor Cover:** Keep the motor cover clean and free of dust to ensure proper ventilation.
- **Inspection:** Regularly inspect all nuts, bolts, and moving parts for tightness and wear. Tighten or replace as needed.



Image: A close-up view of the running belt surface, featuring the ZIPRO logo and textured material, highlighting the quality of the running surface.



Image: The rear view of the treadmill's base, showing the cushioning springs designed to absorb impact and provide a comfortable running experience.

## 8. TROUBLESHOOTING

If you encounter issues with your Zipro Pacemaker Treadmill, refer to the following common problems and solutions:

- **Treadmill does not power on:**

- Check if the power cord is securely plugged into a working outlet.
- Ensure the safety key is correctly placed in its slot.
- Check the circuit breaker or fuse in your home.

- **Running belt slips or hesitates:**

- The running belt may need lubrication. Refer to the maintenance section.
- The running belt may be too loose. Adjust the tension according to your specific manual.

- **Console display is not working correctly:**

- Ensure all cable connections to the console are secure.
- Try turning the treadmill off and on again.

- **Unusual noises during operation:**

- Check for any loose parts or foreign objects under the belt.
- Ensure the treadmill is on a level surface.

For persistent issues not covered here, please contact customer support or refer to the full troubleshooting guide in your included manual.

## 9. SPECIFICATIONS

Feature	Specification
Model Number	5942805
Brand	ZIPRO
Dimensions (Unfolded)	188 x 82 x 151 cm (L x W x H)
Dimensions (Folded)	118 x 82 x 151 cm (L x W x H)
Weight	81 kg
Maximum User Weight	150 kg
Speed Range	1 - 22 km/h
Incline Levels	15 (Adjustable)
Motor Horsepower	5 HP (Peak)
Display Type	LED (7 windows)
Workout Programs	99 Pre-set + 3 User Programs
Connectivity	Bluetooth, USB
Material	Polyethylene (PE), Metal, Plastic

Feature	Specification
Special Features	Adjustable incline, Bluetooth app compatibility, Elegant design, Transport wheels

## 10. WARRANTY AND SUPPORT

For information regarding warranty coverage, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official ZIPRO website. Keep your proof of purchase for any warranty claims.

© 2023 ZIPRO. All rights reserved.