



[Manuals.plus](#) /

› [Lenovo](#) /

› [Lenovo LP40 Pro TWS Earphones User Manual](#)

Lenovo LP40 Pro

Lenovo LP40 Pro TWS Earphones User Manual

Model: LP40 Pro | Brand: Lenovo

INTRODUCTION

Thank you for choosing the Lenovo LP40 Pro TWS Earphones. These wireless Bluetooth 5.1 earbuds are designed to provide a superior audio experience with touch controls and noise reduction capabilities. This manual will guide you through the setup, operation, and maintenance of your new earphones to ensure optimal performance and longevity.



Image: The Lenovo LP40 Pro TWS Earphones in white, displayed alongside their matching white charging case. The earbuds feature a sleek, in-ear design with metallic accents at the bottom of the stems. The charging case has "thinkplus" branding on its lid. The items are placed on a background with pink and blue geometric shapes.

SETUP

1. Charging the Earphones and Case

- Before first use, fully charge the charging case and earphones.

- Place the earphones into the charging case. Ensure they are correctly seated.
- Connect the charging case to a USB power source using the provided charging cable.
- The indicator light on the case will show charging status. A full charge typically takes 1-2 hours.

2. Pairing with Your Device

1. Ensure the earphones are charged.
2. Open the charging case lid. The earphones will automatically power on and enter pairing mode (indicator lights will flash).
3. On your device (smartphone, tablet, computer), enable Bluetooth.
4. Search for "Lenovo LP40 Pro" in the list of available Bluetooth devices.
5. Select "Lenovo LP40 Pro" to connect. Once connected, the indicator lights on the earphones will turn off or flash slowly.
6. If pairing fails, place the earphones back into the case, close the lid, wait a few seconds, and then repeat the steps.

OPERATING INSTRUCTIONS

Touch Controls

The LP40 Pro earphones feature intuitive touch controls on each earbud. The functions may vary slightly depending on your device and application.

Action	Function
Single Tap (Left/Right)	Play/Pause Music, Answer/End Call
Double Tap (Left)	Previous Track
Double Tap (Right)	Next Track
Triple Tap (Left/Right)	Activate Voice Assistant (Siri, Google Assistant)
Long Press (2 seconds)	Reject Call
Long Press (5 seconds)	Power On/Off (when not in case)

Call Management

- **Answering/Ending Calls:** Single tap either earbud.
- **Rejecting Calls:** Long press either earbud for 2 seconds.

Music Playback

- **Play/Pause:** Single tap either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.

MAINTENANCE

- **Cleaning:** Regularly clean the earphones and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earphones in their charging case to protect them and keep them charged.

Store in a cool, dry place away from direct sunlight and extreme temperatures.

- **Water Resistance:** The LP40 Pro earphones are designed for sport use and offer some resistance to sweat and light splashes. However, they are not waterproof. Do not submerge them in water or expose them to heavy rain.
- **Battery Care:** To preserve battery life, avoid fully discharging the earphones and case frequently. Charge them regularly, even if not used for extended periods.

TROUBLESHOOTING

Problem	Possible Solution
Earphones not pairing	<ul style="list-style-type: none">◦ Ensure earphones are charged.◦ Turn off and on Bluetooth on your device.◦ Forget "Lenovo LP40 Pro" from your device's Bluetooth list and re-pair.◦ Place earphones back in case, close lid, wait 10 seconds, then try pairing again.
Only one earphone working	<ul style="list-style-type: none">◦ Ensure both earphones are charged.◦ Place both earphones back into the charging case, close the lid, and then take them out again.◦ Try resetting the earphones (refer to manufacturer's specific reset instructions if available, otherwise, a full charge and re-pairing often works).
Low volume or poor sound quality	<ul style="list-style-type: none">◦ Adjust volume on your connected device.◦ Clean the earbud mesh and tips to remove any debris.◦ Ensure earphones are properly seated in your ears.◦ Try a different audio source or file.
Earphones not charging	<ul style="list-style-type: none">◦ Ensure the charging cable is securely connected to both the case and the power source.◦ Check if the charging case itself has power.◦ Clean the charging contacts on both the earphones and inside the case.◦ Try a different charging cable or power adapter.

SPECIFICATIONS

Feature	Detail
Model Number	LP40 Pro
Bluetooth Version	5.1
Ear Placement	In Ear
Form Factor	In Ear
Noise Control	Sound Isolation
Product Dimensions	12.01 x 9 x 3.5 cm; 59 g
Manufacturer	Lenovo
Color	White

WARRANTY AND SUPPORT

Lenovo products are designed for reliability and performance. For information regarding warranty coverage, technical support, or service, please refer to the warranty card included with your product or visit the official Lenovo support website. Keep your proof of purchase for warranty claims.

For further assistance, you may contact Lenovo customer service through their official channels.