

[Manuals.plus](#) /

› [Big Boss](#) /

› Big Boss 16Qt Large Glass Air Fryer User Manual

Big Boss 8605

Big Boss 16Qt Large Glass Air Fryer

Model: 8605 - User Instruction Manual

1. INTRODUCTION

Thank you for choosing the Big Boss 16Qt Large Glass Air Fryer. This innovative appliance utilizes powerful 360° convection heat to cook your favorite foods with little to no oil, offering a healthier alternative to traditional frying. Its versatile design allows for air frying, baking, roasting, grilling, and toasting, making it an essential tool for any kitchen. This manual provides detailed instructions for safe operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your air fryer.

The Big Boss Air Fryer is designed with your health in mind, being 100% free of Teflon and harmful forever chemicals. Its spacious 16-quart capacity and three cooking levels make it ideal for preparing meals for the entire family.



Figure 1: Big Boss 16Qt Large Glass Air Fryer with packaging.

2. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- Do not use appliance for other than intended household use.
- Ensure the glass bowl is properly seated in the carrier base before operating.
- Do not place food directly on the bottom of the glass bowl; always use the provided racks or mesh basket.

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

3. PRODUCT COMPONENTS

Familiarize yourself with the various parts of your Big Boss Air Fryer:

- **Temperature Control:** Dial to set desired cooking temperature.
- **Lid Handle:** For safely lifting and placing the lid.
- **Heat Indicator:** Light that illuminates when the heating element is active.
- **Power Light:** Light that indicates the unit is powered on.
- **Timer:** Dial to set cooking duration.
- **Glass Lid with Tight Seal:** Transparent lid for monitoring cooking.
- **Stainless Steel Extension Ring:** Increases cooking capacity.
- **Mesh Basket:** Ideal for smaller items like fries or onion rings.
- **Two Cooking Racks:** For multi-level cooking.
- **Glass Bowl:** The main cooking chamber.
- **Tray Tongs:** For safely handling hot racks and baskets.
- **Carrier Base:** Provides stability for the glass bowl.
- **Recipe Book:** Includes 50 popular recipes.

Fully Equipped

Includes Everything Needed for Endless Frying



Figure 2: Exploded view of the Big Boss Air Fryer components.

More Functions for Easier Frying.

Fries. Chicken. Veggies. Desserts.



Figure 3: Control panel with temperature and timer settings.

4. BEFORE FIRST USE

Before using your Big Boss Air Fryer for the first time, please follow these steps:

1. Unpack all components and remove any packaging materials.
2. Wash the glass bowl, mesh basket, cooking racks, and tray tongs with warm, soapy water. Rinse thoroughly and dry completely.
3. Wipe the main unit (lid with controls) with a damp cloth. Do not immerse the main unit in water.
4. Place the carrier base on a stable, heat-resistant surface.
5. Carefully place the clean glass bowl into the carrier base.
6. Insert the desired cooking rack or mesh basket into the glass bowl.
7. Place the lid securely on top of the glass bowl.

5. OPERATING INSTRUCTIONS

The Big Boss Air Fryer is designed for simple and efficient cooking. Follow these steps for operation:

5.1. Temperature and Timer Control

1. Prepare your food and place it on the appropriate cooking rack or in the mesh basket inside the glass bowl.
2. Ensure the lid is securely placed on the glass bowl.
3. Plug the power cord into a standard electrical outlet. The Power light will illuminate.
4. Set the desired cooking temperature using the TEMPERATURE dial. The range is from 180°F to 480°F.
5. Set the cooking time using the TIMER dial. The Heat light will illuminate, indicating the heating element is active.
6. The air fryer will begin cooking. You can monitor the cooking process through the transparent glass bowl.
7. Once the set time has elapsed, the timer will ding, and the unit will automatically shut off.
8. Carefully remove the lid using the handle and place it on a heat-resistant surface or the lid holder (if available).
9. Use the provided tray tongs to remove the cooked food and racks.

5.2. Cooking Guidelines

The control panel provides suggested settings for common foods. These are approximate and may vary based on food quantity and desired crispness.

Food Item	Temperature	Time
French Fries	450°F	20 min
Onion Rings	450°F	15 min
Fish	400°F	18 min
Chicken	375°F	35 min
Thaw/Wash	250°F	N/A

The air fryer's 16-quart capacity and multiple cooking levels allow you to cook various items simultaneously. For best results, ensure even distribution of food and avoid overcrowding.

Full Course Frying, for the **Family**

16Qt Capacity with 3 Cooking Sections

**3 Different
Cooking Levels**



Figure 4: Example of multi-level cooking in the air fryer.

Fry Faster. Fry Healthier.



Figure 5: The air fryer's efficient cooking process.

6. CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your Big Boss Air Fryer.

6.1. Auto-Clean Function

The Big Boss Air Fryer features a convenient auto-clean function:

1. After cooking, allow the unit to cool slightly.
2. Add a small amount of water and a few drops of dish soap to the glass bowl.
3. Place the lid back on the bowl.
4. Set the temperature to 250°F (Thaw/Wash setting) and the timer for 5-10 minutes.
5. The air fryer will heat the water and create a swirling action to help loosen food residue.
6. Once the cycle is complete, unplug the unit and carefully empty the water.
7. Wipe the interior of the glass bowl with a soft cloth or sponge.

6.2. Manual Cleaning

For thorough cleaning or parts not covered by auto-clean:

- Always unplug the air fryer and allow it to cool completely before cleaning.
- The glass bowl, mesh basket, cooking racks, and tray tongs are dishwasher safe. Alternatively, wash them with warm, soapy water and rinse thoroughly.
- Wipe the exterior of the main unit (lid with controls) with a damp cloth. Do not use abrasive cleaners or scouring pads.
- Ensure all parts are completely dry before reassembling or storing the appliance.

Quick, Automatic Cleaning

Simply add water, soap, and set to wash.



Auto-Clean

Dishwasher Safe

Nonstick Interior

Figure 6: Auto-clean function in progress.

7. TROUBLESHOOTING

If you encounter any issues with your Big Boss Air Fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; Timer not set; Temperature not set.	Ensure power cord is securely plugged into a working outlet. Set both the TIMER and TEMPERATURE dials.
Food is not cooked evenly.	Food overcrowded; Racks not positioned correctly.	Avoid overcrowding the basket/racks. Cook in smaller batches if necessary. Ensure racks are properly seated.
White smoke coming from the appliance.	Grease residue from previous use; Excess oil on food.	Clean the glass bowl and accessories thoroughly after each use. Trim excess fat from food before cooking.
Food is not crispy.	Temperature too low; Cooking time too short; Too much moisture.	Increase temperature or cooking time. Pat food dry before cooking.

If the problem persists after trying these solutions, please contact customer support.

8. TECHNICAL SPECIFICATIONS

- **Model Name:** 8605
- **Capacity:** 16 Quarts
- **Color:** Silver
- **Material:** Glass (Inner), Granitestone (Outer)
- **Product Dimensions:** 12.5"D x 16"W x 13.5"H
- **Item Weight:** 14.74 Pounds
- **Output Wattage:** 1300 Watts
- **Voltage:** 120 Volts
- **Control Method:** Touch (Dials)
- **Special Feature:** Programmable
- **Dishwasher Safe:** Yes (Removable parts)
- **Manufacturer:** E.Mishan & Sons, Inc.

9. WARRANTY AND CUSTOMER SUPPORT

The Big Boss Air Fryer comes with a 2-year limited warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal household use. It does not cover damage resulting from misuse, accident, alteration, neglect, or commercial use.

For warranty claims, technical assistance, or general inquiries, please contact Big Boss customer support. Keep your proof of purchase for all warranty-related requests.

Customer Support: Please refer to the contact information provided on the product packaging or the official Big Boss website for the most up-to-date support details.

