

## Bellman BE1350

# Bellman & Symfon Alarm Clock Classic (BE1350) User Manual

Model: BE1350

## 1. INTRODUCTION

This manual provides comprehensive instructions for the Bellman & Symfon Alarm Clock Classic (BE1350). This alarm clock is designed to assist individuals with deep sleep or hearing impairments by combining an extra loud alarm with a powerful bed shaker. It features a large, adjustable LCD display and a "Smart" Snooze function. Please read this manual thoroughly before using the device to ensure proper operation and longevity.

## 2. PACKAGE CONTENTS

Verify that all items are present in the package:

- Bellman & Symfon Alarm Clock Classic (BE1350)
- Bed Shaker
- Power Adapter

## 3. PRODUCT OVERVIEW

Familiarize yourself with the main components of your alarm clock.



Figure 3.1: Bellman & Symfon Alarm Clock Classic (BE1350) main unit and connected bed shaker.



Figure 3.2: Front view of the alarm clock, illustrating the large LCD display and control buttons.



Figure 3.3: The powerful bed shaker, designed to be placed under a pillow or mattress.

### 3.1 Main Unit

- **Large LCD Display:** Shows current time and alarm time.
- **Control Buttons:** Used for setting time, alarm, snooze, and backlight.
- **Speaker:** Emits the loud ascending alarm sound.
- **Power Input:** For connecting the power adapter.
- **Shaker Input:** For connecting the bed shaker.

### 3.2 Bed Shaker

The bed shaker connects to the main unit and provides strong vibrations to wake you up. It is designed to be placed under your pillow or mattress.

## 4. SETUP

---

1. **Connect Power:** Plug the power adapter into the DC input on the back of the alarm clock, then plug the adapter into a wall outlet. The display will illuminate.
2. **Install Battery Backup:** For uninterrupted operation during power outages, install 4 AAA batteries (not included) into the battery compartment located on the underside of the clock. Ensure correct polarity. The battery icon on the display indicates battery status.
3. **Connect Bed Shaker:** Plug the bed shaker cable into the designated shaker input port on the back of the alarm clock. Place the bed shaker under your pillow or mattress.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Setting the Time

1. Press and hold the **Time Set** button (refer to Figure 3.2 for button location) until the hour digits begin to flash.
2. Use the **Hour** and **Minute** buttons to adjust the time.
3. Press the **Time Set** button again to confirm and exit time setting mode.
4. To switch between 12-hour and 24-hour format, press the **12/24H** button.

### 5.2 Setting the Alarm

1. Press and hold the **Alarm Set** button until the alarm hour digits begin to flash.
2. Use the **Hour** and **Minute** buttons to set your desired alarm time.
3. Press the **Alarm Set** button again to confirm the alarm time.
4. To activate or deactivate the alarm, press the **Alarm ON/OFF** button. An alarm icon will appear on the display when the alarm is active.

### 5.3 Snooze Function

When the alarm sounds, press the large **Snooze** button on top of the clock. The "Smart" Snooze function will activate, silencing the alarm temporarily. The snooze duration automatically reduces from 9 minutes to 2 minutes in two-minute intervals with each subsequent snooze activation.

### 5.4 Backlight Adjustment

The LCD display features an adjustable backlight. Press the **Brightness** button (refer to Figure 3.2) repeatedly to cycle through different brightness levels or to turn the backlight off. Note that some users find the lowest setting still quite bright in a dark room.

## 6. MAINTENANCE

---

- **Cleaning:** Wipe the alarm clock and bed shaker with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace the AAA backup batteries annually or when the low battery indicator appears on the display to ensure continuous operation during power outages.
- **Storage:** If storing the device for an extended period, remove the backup batteries to prevent leakage.

## 7. TROUBLESHOOTING






Problem	Possible Cause	Solution
Clock display is blank.	No power or power outage.	Ensure power adapter is securely plugged in. Check if backup batteries are installed and charged.
Alarm does not sound/vibrate.	Alarm not activated or bed shaker not connected.	Verify alarm is set and activated (alarm icon visible). Ensure bed shaker is firmly plugged into the clock.
Display backlight is too bright/dim.	Incorrect brightness setting.	Press the <b>Brightness</b> button to cycle through different levels.
Time or alarm settings are lost.	Power interruption without backup batteries, or dead backup batteries.	Install fresh AAA backup batteries. Reset time and alarm.


## 8. SPECIFICATIONS

- **Model:** BE1350
- **Product Dimensions:** 6.2 x 5.6 x 5.6 inches
- **Item Weight:** 12 ounces
- **Power:** AC adapter (included), 4 x AAA batteries (backup, not included)
- **Alarm Volume:** Up to 100+ dB ascending alarm
- **Snooze Duration:** "Smart" Snooze, automatically reduces from 9 to 2 minutes

## 9. WARRANTY AND SUPPORT

The Bellman & Symfon Alarm Clock Classic (BE1350) is covered by a manufacturer's warranty. For specific warranty details, technical support, or service inquiries, please contact Bellman & Symfon customer service or refer to the official Bellman & Symfon website. Please retain your proof of purchase for warranty claims.

	<p><a href="#">Bellman Alarm Clock Classic BE1350: Instruction Manual</a></p> <p>Comprehensive instruction manual for the Bellman Alarm Clock Classic BE1350, detailing features, setup, usage, specifications, and quality assurance. Includes powerful vibration, sound alerts, and smart snooze.</p>
	<p><a href="#">Bellman BE1341 Alarm Clock User Manual - Features, Setup, Troubleshooting</a></p> <p>Comprehensive user manual for the Bellman BE1341 Alarm Clock. Learn about setup, functions, indicators, troubleshooting, and technical specifications for this hearing impaired assistance device.</p>
	<p><a href="#">Bellman BE1341 Alarm Clock User Manual - Features, Setup, and Troubleshooting</a></p> <p>Comprehensive user manual for the Bellman BE1341 Alarm Clock. Learn about its features, setup, functions, indicators, troubleshooting, and technical specifications. Designed for indoor use to alert users with sound, light, and vibration.</p>
	<p><a href="#">Bellman Alarm Clock Be1341 User Manual and Technical Information</a></p> <p>Comprehensive guide to the Bellman Alarm Clock Be1341, covering setup, functions, technical specifications, indicators, troubleshooting, and testing. Features sound, light, and vibration alerts for enhanced accessibility.</p>
	<p><a href="#">Bellman Visit Alarm Clock BE1345 - Technical Manual and Specifications</a></p> <p>Comprehensive technical manual for the Bellman Visit Alarm Clock BE1345. This document details its functions, installation, testing procedures, technical specifications, system settings, operational features, and troubleshooting guide. Designed for indoor use as part of the Bellman Visit System, it alerts users with light, sound, and vibration.</p>



[Bellman BE1521-433 Bridge Transceiver User Manual](#)

User manual for the Bellman BE1521-433 Bridge Transceiver, detailing setup, pairing, troubleshooting, and app installation for connecting to the Bellman Visit system.