



Manuals.plus /

› **Big Boss** /

› Big Boss 16 Quart Oil-Less Air Fryer Instruction Manual

Big Boss 9063

Big Boss 16 Quart Oil-Less Air Fryer Instruction Manual

Model: 9063

INTRODUCTION

The Big Boss 16-Quart Oil-Less Air Fryer reinvents traditional cooking by combining halogen heat, convection, and infrared technology. This energy-efficient tabletop cooker is designed to deliver food that is moist on the inside and browned and crispy on the outside, all without the need for added fats or oils. Its triple cooking power ensures efficient and thorough cooking, allowing you to fry, bake, grill, roast, and more with ease.



Image: The Big Boss Air Fryer, showcasing its transparent glass bowl filled with cooked food, highlighting its large capacity and design.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.

- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the glass bowl is properly seated in the carrier base before operation.
- Do not block any ventilation openings.

PRODUCT COMPONENTS

Familiarize yourself with the various parts of your Big Boss Air Fryer for optimal use and maintenance.



Image: Exploded view diagram of the Big Boss Air Fryer, detailing each component from the lid to the carrier base, including accessories like cooking racks and tongs.

1. **Lid Handle:** For safe lifting and placement of the lid.
2. **Heat Indicator:** Illuminates when the heating element is active.
3. **Power Light:** Indicates when the unit is powered on.
4. **Timer:** Dial to set cooking time.
5. **Temperature Control:** Dial to set desired cooking temperature.
6. **Glass Lid with Tight Seal:** Contains the heating element and fan, seals the cooking chamber.
7. **Stainless Steel Extension Ring:** Increases capacity for larger food items.
8. **Mesh Basket:** Ideal for air-frying smaller items like fries or onion rings.
9. **High Cooking Rack:** For cooking items closer to the heating element.
10. **Low Cooking Rack:** For cooking items further from the heating element or larger items.
11. **Glass Bowl:** The main cooking chamber, transparent for easy monitoring.
12. **Carrier Base:** Provides stability and support for the glass bowl.
13. **Tray Tongs:** Tool to safely lift hot racks and baskets from the bowl.

SETUP

Before first use, ensure all packaging materials are removed. Wash the glass bowl, cooking racks, mesh basket, and tongs with warm, soapy water. Wipe the main unit (lid) with a damp cloth. Ensure all parts are completely dry before assembly.

- Place the carrier base on a stable, heat-resistant surface.
- Carefully place the clean glass bowl into the carrier base.
- Depending on your recipe, place either the low rack, high rack, or mesh basket inside the glass bowl. If cooking larger items or multiple layers, use the stainless steel extension ring by placing it on top of the glass bowl before placing the lid.
- Place the food evenly on the rack or in the basket. Do not overfill.
- Carefully place the lid onto the glass bowl (or extension ring). Ensure it is seated securely.
- Plug the power cord into a grounded electrical outlet.

OPERATING INSTRUCTIONS

The Big Boss Air Fryer features simple dial controls for temperature and timer settings, making operation straightforward.

HIGH TEMPERATURE CAPABILITY

Adjustable Settings to Control Cooking



Image: Detailed view of the control panel, highlighting the temperature and timer dials, along with suggested cooking times and temperatures for various foods.

Setting Temperature and Time:

- Temperature Control:** Turn the upper dial (Temperature) to your desired cooking temperature. The range is typically from 180°F to 480°F. No preheating is required for most recipes.
- Timer Control:** Turn the lower dial (Timer) to set the cooking duration. The timer can be set up to 60 minutes. The unit will automatically shut off when the timer reaches zero.
- The Power light (green) and Heat light (red) will illuminate when the unit is operating. The Heat light will cycle on and off as the unit maintains the set temperature.
- You can monitor the cooking process through the transparent glass bowl without opening the lid.
- If you need to stop cooking mid-cycle, simply turn the timer dial to "OFF" or lift the lid handle (the unit has a safety switch that turns off the heating element when the handle is raised).
- Once cooking is complete, carefully remove the lid using the handle and place it on a heat-resistant surface. Use the provided tongs to remove the cooked food and racks.

Cooking Functions:

The Big Boss Air Fryer is versatile and can perform multiple cooking functions:

- **Air Fry:** Achieve crispy results with minimal to no oil.
- **Bake:** Ideal for pastries, cakes, and other baked goods.
- **Grill:** Perfect for meats and vegetables, giving them a grilled texture.
- **Roast:** For larger cuts of meat or whole poultry.
- **Toast:** Quickly toast bread or bagels.
- **Steam:** Can be used to steam vegetables (requires adding a small amount of water to the bottom of the bowl).

COOKING GUIDE AND TIPS

The following table provides general guidelines for cooking common foods. Adjust times and temperatures based on food quantity, desired crispness, and personal preference. Always ensure food is cooked to a safe internal temperature.



Image: Examples of various dishes prepared with the Big Boss Air Fryer, illustrating its versatility and the healthy cooking benefits.

Approximate Cooking Times and Temperatures

Food Item	Temperature	Time	Notes
French Fries (frozen)	450°F (232°C)	15-20 min	Shake basket halfway through.
Chicken Wings	400°F (204°C)	20-25 min	Flip halfway through.
Chicken Breast (boneless)	375°F (190°C)	15-20 min	Internal temp 165°F (74°C).
Fish Fillets	350°F (177°C)	10-15 min	Cook until flaky.
Steak (1 inch thick)	400°F (204°C)	10-18 min	Flip halfway, adjust for desired doneness.
Vegetables (broccoli, bell peppers)	380°F (193°C)	10-15 min	Toss with a little oil and seasoning.

General Tips:

- **Do not overcrowd:** Cook in batches if necessary to ensure even cooking and crispiness.
- **Shake or flip:** For best results, shake the basket or flip food items halfway through the cooking time.
- **Add a little oil:** While oil-less, a small amount of oil (1-2 teaspoons) can enhance crispiness for some foods, especially fresh vegetables or homemade fries.
- **Use parchment paper or foil:** For easy cleanup, you can line the bottom of the basket or rack with parchment paper or aluminum foil, ensuring it doesn't block airflow.
- **Frozen foods:** The air fryer can cook frozen foods directly without thawing, though cooking times may need to be extended.

CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and optimal performance of your Big Boss Air Fryer. Always unplug the unit and allow it to cool completely before cleaning.

- **Glass Bowl, Racks, and Mesh Basket:** These parts are dishwasher safe. For hand washing, use warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely.
- **Lid (Main Unit):** The lid contains electrical components and should NEVER be immersed in water. Wipe the exterior with a damp cloth. For the interior (heating element and fan area), use a damp cloth or a soft brush to gently remove food residue. For stubborn grease, a mild degreaser can be used on a cloth, then wipe clean with a damp cloth. Ensure no liquid enters the electrical components.
- **Carrier Base:** Wipe with a damp cloth.
- **Stubborn Stains:** For baked-on food in the glass bowl, you can fill it with warm, soapy water and let it soak for a while before cleaning.
- **Storage:** Store the air fryer in a clean, dry place once all parts are dry and reassembled.

TROUBLESHOOTING

If you encounter issues with your Big Boss Air Fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; Timer not set; Lid not properly seated.	Ensure power cord is securely plugged into a working outlet. Set the timer. Ensure the lid handle is fully lowered and the lid is correctly placed on the bowl/extension ring.
Food is not cooked evenly.	Overcrowding the basket/rack; Food not flipped/shaken.	Cook in smaller batches. Shake the basket or flip food items halfway through cooking.
Food is not crispy.	Too much moisture; Not enough cooking time/high enough temperature.	Pat food dry before cooking. Extend cooking time or increase temperature slightly. A light spray of oil can help.
White smoke coming from unit.	Grease/oil residue on heating element; Fatty food cooking.	This is usually normal for fatty foods. If excessive, clean the heating element area thoroughly after the unit cools. Ensure drip tray is clean.
Unit trips circuit breaker.	Overloaded circuit; Faulty unit.	Ensure the air fryer is on a dedicated circuit or not sharing with other high-wattage appliances. If problem persists, contact customer support.

SPECIFICATIONS

- **Model Number:** 9063
- **Capacity:** 16 Quarts
- **Power/Wattage:** 1300W (Note: Product description states 1300W, specifications list 1500W. Refer to product label for exact wattage.)
- **Voltage:** 120V AC
- **Material:** Glass (bowl), Stainless Steel, Plastic
- **Product Dimensions:** Approximately 30.48 x 30.48 x 30.48 cm (12 x 12 x 12 inches)
- **Item Weight:** Approximately 6.69 kg (14.75 lbs)
- **Special Features:** Programmable Timer, Halogen/Convection/Infrared Heating, Transparent Glass Bowl

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Big Boss website. Keep your purchase receipt as proof of purchase for any warranty claims.

Manufacturer: Big Boss

Place of Business: NEW YORK, NY, 10001 US