

Timex T466W

Timex Indiglo T466W Nature Sounds Alarm Clock User Manual

Model: T466W

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Timex Indiglo T466W Nature Sounds Alarm Clock. This device features an AM/FM stereo radio, multiple alarm settings, and a selection of nature sounds for a pleasant waking or sleeping experience. Please read this manual thoroughly before using your alarm clock to ensure proper function and longevity.

PRODUCT OVERVIEW



Figure 1: Front view of the Timex Indiglo T466W Nature Sounds Alarm Clock. The clock features a central digital display showing the time, flanked by two speaker grilles. Below the display, there are control buttons and a small slot, likely for a CD player or auxiliary input. The overall color is white.

The Timex Indiglo T466W is designed to be a versatile bedside companion. Key features include:

- Digital time display with Indiglo backlight.
- AM/FM stereo radio with digital tuning.
- Three independent alarms with wake-to-radio, buzzer, or nature sounds options.
- Multiple nature sound selections.
- Snooze function for temporary alarm pause.
- Sleep timer for falling asleep to music or nature sounds.

SETUP

1. Power Connection

Connect the AC power adapter to the DC input jack located on the back of the unit. Plug the adapter into a standard wall outlet (AC 120V, 60Hz). The clock display will illuminate, and the unit will be ready for operation.

2. Battery Backup (Not Included)

While the unit operates on AC power, it may have a battery backup compartment (typically for 2 "AA" batteries, not included) to maintain time and alarm settings during a power outage. If present, open the battery compartment cover on the bottom or back of the unit and insert the batteries, observing the polarity markings (+ and -). This feature ensures your settings are preserved.

3. Setting the Time

1. Press and hold the **TIME SET** button until the hour digits begin to flash.
2. Press the **HOUR** button repeatedly to adjust the hour. Observe the PM indicator if setting a PM time.
3. Press the **MINUTE** button repeatedly to adjust the minute.
4. Press the **TIME SET** button again to confirm and exit time setting mode.

OPERATING INSTRUCTIONS

1. Setting Alarms (Alarm 1, 2, 3)

The clock features three independent alarms. The process is similar for each:

1. Press and hold the desired **ALARM 1/2/3 SET** button until the alarm hour digits flash.
2. Press the **HOUR** button to set the alarm hour.
3. Press the **MINUTE** button to set the alarm minute.
4. Press the **ALARM 1/2/3 SET** button again to confirm the time.
5. Immediately after setting the time, use the **ALARM MODE** button (or similar) to cycle through wake options: Buzzer, Radio, or Nature Sound. An icon will appear on the display indicating your selection.
6. To activate/deactivate an alarm, press the corresponding **ALARM ON/OFF** button. An alarm icon will appear when active.

2. Radio Operation

- Press the **RADIO ON/OFF** button to turn the radio on or off.
- Press the **BAND** button to switch between AM and FM bands.
- Use the **TUNE +** or **TUNE -** buttons to manually tune to a station. Press and hold for automatic scanning to the next clear station.
- Adjust the volume using the **VOLUME +** or **VOLUME -** buttons.
- For optimal FM reception, extend the wire antenna fully. For AM reception, rotate the unit for best signal.

3. Nature Sounds

- Press the **NATURE SOUNDS** button to activate the nature sound playback.
- Press the **NATURE SOUNDS** button repeatedly to cycle through available sounds (e.g., ocean, rain, forest, white noise).
- Adjust the volume using the **VOLUME +** or **VOLUME -** buttons.
- To turn off nature sounds, press the **NATURE SOUNDS** button until it deactivates, or press the **POWER** button.

4. Snooze Function

When an alarm sounds, press the large **SNOOZE** button (usually located on top of the unit) to temporarily silence the alarm. The alarm will sound again after approximately 9 minutes.

5. Sleep Timer

The sleep timer allows you to fall asleep to the radio or nature sounds, which will automatically turn off after a set period.

1. While the radio or nature sounds are playing, press the **SLEEP** button.
2. Press the **SLEEP** button repeatedly to cycle through available sleep times (e.g., 10, 20, 30, 60, 90 minutes).
3. The unit will automatically turn off after the selected time. To cancel the sleep timer, press the **SLEEP** button until "OFF" or "0" is displayed.

6. Indiglo Backlight

The display features an Indiglo backlight for easy viewing in low light conditions. This backlight is typically always on or can be activated by pressing a specific button (refer to your unit's specific button layout if not always on).

MAINTENANCE

Cleaning

To clean the unit, use a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or sprays, as these may damage the finish or internal components. Ensure the unit is unplugged before cleaning.

Battery Replacement (for Backup)

If the battery backup feature is used, replace the batteries annually or when the unit experiences frequent power outages to ensure settings are retained. Always use the specified battery type (e.g., "AA" batteries) and dispose of old batteries responsibly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not power on.	Power adapter not properly connected or wall outlet is not active.	Ensure the AC adapter is securely plugged into the unit and a working wall outlet. Test the outlet with another device.
Alarm does not sound.	Alarm not activated, alarm volume too low, or incorrect alarm time set.	Verify the alarm is set to ON and the alarm time is correct. Increase the alarm volume. Ensure the wake mode (buzzer, radio, nature sound) is selected.
Poor radio reception.	Antenna not extended (FM) or unit position (AM). Interference from other electronics.	Fully extend the FM wire antenna. For AM, rotate the unit to find the best signal. Move the unit away from other electronic devices that may cause interference.
Time/settings lost after power outage.	Backup batteries are dead or not installed.	Install fresh backup batteries (if applicable) or replace existing ones.

SPECIFICATIONS

Model: T466W

Power Source: AC 120V, 60Hz

Battery Backup: Not included (typically 2 x "AA" batteries, if applicable)

Radio Bands: AM/FM Stereo

Alarms: 3 independent alarms

Display: Digital with Indiglo backlight

Features: Nature Sounds, Snooze, Sleep Timer

WARRANTY AND SUPPORT

Warranty Information

This product is covered by a limited warranty provided by Timex. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration. Retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact Timex customer support. Contact information can typically be found on the Timex official website or on the product packaging. You may also visit the official Timex store page for more information:[Timex Store on Amazon.ca](#)

© 2023 Timex. All rights reserved. Information in this manual is subject to change without notice.