

Philips HD9904/00

Philips HD9904/00 Double Layer Rack with Skewers Instruction Manual

For Compact Philips Airfryer Models

1. INTRODUCTION

Thank you for purchasing the Philips HD9904/00 Double Layer Rack with Skewers. This accessory is designed to enhance the versatility and cooking capacity of your compact Philips Airfryer, allowing you to prepare more food simultaneously or cook different items on separate levels. The included skewers are ideal for preparing various kabobs.

Please read this manual carefully before first use to ensure proper operation and maintenance.

2. SAFETY INFORMATION

- Always handle the rack and skewers with heat-resistant gloves when hot.
- Ensure the rack is properly seated in the Airfryer basket before cooking.
- Do not overload the rack or skewers, as this may affect cooking performance and stability.
- Keep out of reach of children.
- Inspect the accessory for any damage before each use. Do not use if damaged.

3. PACKAGE CONTENTS

The Philips HD9904/00 package includes the following items:

- 1 x Double Layer Rack (Stainless Steel)
- 4 x Skewers (Stainless Steel)




Image: The Philips HD9904/00 Double Layer Rack with four skewers, showcasing the complete accessory set.

4. SETUP AND COMPATIBILITY

4.1 Compatibility

This Double Layer Rack with Skewers is compatible with the following compact Philips Airfryer models:

- HD962x series
- HD964x series
- HD922x series
- HD923x series

Ensure your Airfryer model is listed above for proper fit and function.

4.2 Inserting the Double Layer Rack

1. Open the Airfryer drawer and remove the basket.
2. Place the Double Layer Rack directly into the Airfryer basket. Ensure it sits securely on the bottom of the basket.
3. The rack is designed to fit snugly, providing a stable second cooking surface.



Image: The Philips Double Layer Rack positioned inside the Airfryer basket, ready for use.

5. OPERATING INSTRUCTIONS

5.1 Using the Double Layer Rack

The double layer rack allows you to cook two different types of food or a larger quantity of the same food simultaneously.

1. Place the desired food items on the bottom of the Airfryer basket.
2. Insert the Double Layer Rack into the basket, above the first layer of food.
3. Place additional food items on the top layer of the rack.
4. Slide the basket back into the Airfryer and operate as usual according to your Airfryer's instructions and recipe guidelines.
5. **Note:** Cooking times may vary when using two layers. Monitor food closely and adjust cooking time or temperature as needed. For even cooking, consider rotating or shaking the basket halfway through, if applicable to your food items.



Image: An Airfryer basket containing food items arranged on both the bottom and the double layer rack for simultaneous cooking.

5.2 Using the Skewers

The four included skewers are perfect for preparing meat, vegetable, or fruit kabobs.

1. Prepare your ingredients by cutting them into uniform pieces suitable for skewering.
2. Thread the ingredients onto the skewers.
3. Place the skewers onto the designated slots on the Double Layer Rack. The rack is designed to hold the skewers securely in place during cooking.
4. Insert the rack with skewers into the Airfryer basket and cook according to your recipe.



Image: Prepared vegetable skewers arranged on a serving plate, demonstrating the type of food that can be cooked using the accessory.

6. CLEANING AND MAINTENANCE

Proper cleaning ensures the longevity and hygiene of your accessory.

- Allow the rack and skewers to cool completely before cleaning.
- The Double Layer Rack and skewers are dishwasher-safe.
- Alternatively, wash them by hand using hot water and a mild dishwashing liquid. Use a non-abrasive sponge or brush to remove food residue.
- For stubborn food particles, soak the items in warm, soapy water for a few minutes before scrubbing.
- Rinse thoroughly and dry completely before storing.



Image: The Philips Double Layer Rack and skewers displayed, indicating their readiness for cleaning after use.

7. TROUBLESHOOTING

Food not cooking evenly:

- Ensure the Airfryer is not overloaded. Overloading can restrict airflow.
- For best results, arrange food in a single layer on each level if possible.
- Consider rotating the rack or shaking the basket halfway through cooking, especially for smaller items.
- Adjust cooking time or temperature as needed.

Rack does not fit:

- Verify your Airfryer model is listed under the compatible models in Section 4.1. This accessory is designed for compact Philips Airfryers.

8. SPECIFICATIONS

Feature	Detail
Model Number	HD9904/00
Material	Stainless Steel
Color	Silver
Special Features	Dishwasher Safe
Item Weight	0.7 Pounds
Item Dimensions (L x W)	2.95"L x 7.08"W
UPC	075020040039

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your original Philips Airfryer or visit the official Philips website. Keep your proof of purchase for any warranty claims.

For additional recipes and tips, you may visit the [Philips Store on Amazon](#).