

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Jocca](#) /

› [Jocca Air Fryer 1000W 2.2L User Manual](#)

Jocca JOC-AFC1000B

Jocca Air Fryer 1000W 2.2L User Manual

Model: JOC-AFC1000B

[Overview](#) [Setup](#) [Operation](#) [Safety Instructions](#) [Product Maintenance](#) [Troubleshooting](#) [Specifications](#) [Support](#)

INTRODUCTION

Thank you for choosing the Jocca Air Fryer. This appliance uses rapid air circulation technology to cook your favorite foods with little to no oil, resulting in healthier meals. Please read this manual thoroughly before use to ensure safe and optimal operation.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting the appliance.
- Do not place anything on top of the appliance.
- Keep the appliance away from walls or other appliances, leaving at least 10 cm free space on the back and sides and 10 cm free space above the appliance.

PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the parts of your Jocca Air Fryer:



Figure 1: Front view of the Jocca Air Fryer, showing the main unit with its black finish, silver handle, and control dials.

1. **Temperature Control Dial:** Adjusts cooking temperature (80-200°C).
2. **Timer Dial:** Sets cooking time (up to 30 minutes).
3. **Air Inlet:** Located at the top of the unit.
4. **Air Outlet:** Located at the back of the unit.
5. **Frying Basket:** Non-stick, removable basket for food.
6. **Basket Handle:** For safely removing and inserting the frying basket.

7. **Power Indicator Light:** Illuminates when the appliance is on.
8. **Heating Indicator Light:** Illuminates when the heating element is active.



Figure 2: The Jocca Air Fryer with its non-stick frying basket partially removed, showing the interior cavity.



Figure 3: Close-up view of the Jocca Air Fryer's analog control dials for temperature and timer settings.

SETUP AND FIRST USE

- 1. Unpacking:** Remove all packaging materials, stickers, and labels from the appliance.
- 2. Cleaning:** Wash the frying basket and pan thoroughly with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the appliance with a damp cloth. Do not immerse the main unit in water.
- 3. Placement:** Place the appliance on a stable, horizontal, and level surface. Ensure there is at least 10 cm of free space around the back, sides, and above the appliance for proper ventilation.
- 4. Pre-heating (Optional but Recommended):** For the first use, it is recommended to run the air fryer empty for about 10 minutes at 180°C to eliminate any manufacturing odors. A slight smell or smoke may occur, which is normal.

OPERATING INSTRUCTIONS

- 1. Prepare Food:** Place the ingredients into the frying basket. Do not overfill the basket to ensure even

cooking.

- Insert Basket:** Slide the frying basket back into the appliance until it clicks into place.
- Set Temperature:** Turn the temperature control dial to your desired temperature (80-200°C).
- Set Timer:** Turn the timer dial to the required cooking time (up to 30 minutes). The appliance will start heating immediately.
- Monitor Cooking:** During cooking, you may pull out the basket to shake or turn ingredients for even browning. The appliance will pause heating when the basket is removed and resume when reinserted.
- Completion:** When the timer reaches zero, a bell will sound, indicating cooking is complete. The appliance will automatically shut off.
- Remove Food:** Carefully pull out the basket using the handle. Place it on a heat-resistant surface. Use tongs to remove cooked food.

Cooking Guide

The following table provides general guidelines. Adjust times and temperatures based on food quantity and desired crispness.



Figure 4: Top panel of the Jocca Air Fryer displaying recommended cooking times and temperatures for various food types like chicken, steak, chips, cake, bread, and meat.

| Food Item | Temperature | Time | Notes |
|-----------|-------------|-----------|--------------|
| Chicken | 200°C | 15-22 min | Flip halfway |

| Food Item | Temperature | Time | Notes |
|----------------|-------------|-----------|-------------------------------|
| Steak | 200°C | 8-14 min | Depends on thickness |
| Chips (Fries) | 200°C | 12-16 min | Shake basket frequently |
| Cake | 200°C | 15-18 min | Use appropriate baking tin |
| Bread | 180°C | 5-8 min | For reheating or toasting |
| Meat (General) | 200°C | 10-15 min | Adjust for type and thickness |

MAINTENANCE AND CLEANING

Clean the appliance after every use.

- Unplug and Cool:** Always unplug the air fryer and allow it to cool completely before cleaning.
- Clean Basket and Pan:** The frying basket and pan are non-stick. They can be washed with hot water, dish soap, and a non-abrasive sponge. For stubborn food residues, soak them in hot water for about 10 minutes.
- Wipe Main Unit:** Wipe the exterior of the appliance with a damp cloth. Never immerse the main unit in water or any other liquid.
- Clean Heating Element:** Use a cleaning brush to remove any food residues from the heating element inside the appliance.
- Storage:** Ensure all parts are dry before storing the appliance in a cool, dry place.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------------------------------------|---|--|
| Air fryer does not work. | Appliance is not plugged in. Timer is not set. | Plug the main plug into an earthed wall socket. Turn the timer dial to the required cooking time. |
| Food is not cooked evenly. | Basket is overfilled. Food not shaken/turned. | Reduce the amount of ingredients. Shake or turn ingredients halfway through cooking. |
| White smoke comes from the appliance. | Fat residues from previous use. Basket/pan not cleaned properly. | Clean the basket and pan thoroughly after each use. Ensure no fat residues remain. |
| Fresh fries are not crispy. | Too much water on fries. Not enough oil. | Pat fresh potatoes dry before adding oil. Add a little more oil for crispier results. |

SPECIFICATIONS

- Model:** JOC-AFC1000B
- Brand:** Jocca
- Power:** 1000 Watts
- Voltage:** 230 Volts
- Capacity:** 2.2 Liters

- **Temperature Range:** 80°C - 200°C
- **Timer:** Up to 30 minutes
- **Dimensions (Depth x Width x Height):** 25.8 cm x 29.1 cm x 31.8 cm
- **Weight:** 2.99 kg
- **Special Feature:** Automatic shut-off



Figure 5: Diagram illustrating the dimensions of the Jocca Air Fryer: 31.8cm height, 29.11cm width, and 25.81cm depth.

WARRANTY AND CUSTOMER SUPPORT

For warranty information, technical support, or any questions regarding your Jocca Air Fryer, please refer to the warranty card included with your purchase or visit the official Jocca website. You may also contact your retailer for assistance.

Jocca Official Website: www.jocca.es (Example link, actual link may vary)

Related Documents - JOC-AFC1000B

| | |
|---|---|
|  REF: 2219P | <p>JOCCA 2219P Air Fryer: User Manual & Operating Guide</p> <p>Discover the JOCCA 2219P Air Fryer. This comprehensive guide provides essential safety information, operating instructions, preset cooking programs, and maintenance tips for healthier, convenient home cooking.</p> |
|  REF: 2157RF (EN) Instructions manual (ES) Manual de instrucciones (FR) Mode d'emploi (IT) Manuale d'istruzioni (PT) Manual de instruções | <p>JOCCA 2157RF Air Fryer: User Manual, Instructions, and Safety Guide</p> <p>Comprehensive user manual for the JOCCA 2157RF Air Fryer by ROBIN FOOD. Includes safety warnings, product description, operating instructions, cooking programs, cleaning guide, and technical specifications.</p> |
|  Ref: 1507 | <p>JOCCA Air Fryer 1507: User Manual and Instructions</p> <p>Comprehensive user manual for the JOCCA Air Fryer 1507, providing detailed instructions, safety warnings, cleaning guidelines, and technical specifications in multiple languages.</p> |
|  105.00mm 145.00mm Ref: 1599-2141 | <p>JOCCA Air Fryer 1599-2141 User Manual and Instructions</p> <p>Comprehensive user manual and instructions for the JOCCA Air Fryer model 1599-2141, covering safety warnings, operating instructions, cleaning and maintenance, technical specifications, and warranty information.</p> |
|  Ref: 1588 <small>(EN) Instructions manual (ES) Manual de instrucciones (FR) Mode d'emploi (IT) Manuale d'istruzioni (PT) Manual de instruções</small> <small>Para usar con precisión debe leer este manual con atención. Servicio de atención al cliente: JOCCHA INTERNACIONAL 1000-000-0000</small> | <p>Jocca Kitchen Scale Instruction Manual</p> <p>This manual provides instructions and safety warnings for the Jocca Kitchen Scale, model ref: 1588. Learn how to use, clean, and maintain your scale for accurate measurements.</p> |



[JOCCA Sport Mini Exercise Bike - User Manual and Instructions](#)

Comprehensive user manual for the JOCCA Sport Mini Exercise Bike, covering setup, operation, safety guidelines, and maintenance. Learn how to use your pedaler for effective home workouts.