

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Timex](#) /

› [Timex Marathon Mid-Size Digital Watch TW5K84800M6 Instruction Manual](#)

Timex TW5K84800M6

Timex Marathon Mid-Size Digital Watch Instruction Manual

Model: TW5K84800M6

PRODUCT OVERVIEW

The Timex Marathon Mid-Size Digital Watch is designed for active lifestyles, offering essential timekeeping functions in a durable, water-resistant design. Key features include a daily alarm, two time zone settings, a 24-hour stopwatch, and the Indiglo night-light for low-light visibility. It is water resistant up to 50 meters.



Image: Front view of the Timex Marathon Mid-Size Digital Watch, showing the digital display and button labels.

BUTTON FUNCTIONS

The watch features four primary buttons:

- **MODE:** Cycles through time, alarm, stopwatch, and second time zone modes.
- **RESET:** Used to clear stopwatch, adjust settings, or reset values.
- **ST/STP (Start/Stop):** Starts and stops the stopwatch, or increases values during setting.
- **LIGHT:** Activates the Indiglo night-light for illumination.

Your browser does not support the video tag.

Video: A 21-second demonstration of the Timex Marathon Mid-Size Digital Watch, showcasing its design and button placement.

SETUP INSTRUCTIONS

Setting Time and Date

1. From the time display, press and hold the **RESET** button until the seconds begin to flash.
2. Press the **MODE** button to cycle through seconds, hours, minutes, month, date, and day of the week.
3. Use the **ST/STP** button to adjust the flashing value. Hold **ST/STP** to change values quickly.
4. Once all settings are correct, press the **RESET** button to exit setting mode.

Setting the Alarm

1. From the time display, press the **MODE** button until "AL" or "ALARM" appears on the screen.
2. Press and hold the **RESET** button until the alarm hours begin to flash.
3. Use the **ST/STP** button to adjust the alarm hour. Press **MODE** to select minutes.
4. Use the **ST/STP** button to adjust the alarm minutes.
5. Press the **RESET** button to save the alarm time.
6. To activate/deactivate the alarm, press **ST/STP** while in alarm mode. An alarm icon will appear/disappear.

Setting Second Time Zone (T2)

1. From the time display, press the **MODE** button until "T2" or "DUAL TIME" appears.
2. Press and hold the **RESET** button until the hours begin to flash.
3. Use the **ST/STP** button to adjust the flashing value. Press **MODE** to cycle through hours and minutes.
4. Press the **RESET** button to save the second time zone.

OPERATING INSTRUCTIONS

Using the Stopwatch

1. From the time display, press the **MODE** button until "ST" or "STOPWATCH" appears.
2. Press **ST/STP** to start the stopwatch.
3. Press **ST/STP** again to pause the stopwatch.
4. Press **RESET** to clear the stopwatch to zero.
5. To resume, press **ST/STP**.

Using Indiglo Night-Light

Press the **LIGHT** button at any time to illuminate the watch display for a few seconds. This feature is useful in low-light conditions.

MAINTENANCE

- **Cleaning:** Clean the watch with a soft, damp cloth. Avoid harsh chemicals.
- **Water Resistance:** This watch is water resistant to 50 meters (164 feet). It is suitable for short periods of recreational swimming, but not for diving or snorkeling. **Do not press any buttons while the watch is submerged in water.**
- **Battery Replacement:** Battery replacement should be performed by a qualified watch technician to ensure water resistance is maintained. The watch uses 1 Lithium Metal battery.



Image: The Timex Marathon Mid-Size Digital Watch, designed for water resistance up to 50 meters.

TROUBLESHOOTING

- **Display is blank or dim:** The battery may be low or depleted. Replace the battery.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though not specified for this model). If issues persist, a soft reset (removing and reinserting battery) by a professional may be required.
- **Time is inaccurate:** Re-set the time and date following the setup instructions. If inaccuracy persists, the watch module may require service.
- **Water inside the watch:** If water appears inside the watch, immediately take it to a qualified service center. This indicates a breach in the water resistance seal.

SPECIFICATIONS

Feature	Detail
Model Number	TW5K84800M6
Brand	Timex
Display Type	Digital

Movement Type	Quartz
Case Material	Resin
Band Material	Resin
Water Resistance Depth	50 Meters (164 Feet)
Power Source	Battery Powered (1 Lithium Metal battery included)
Product Dimensions	3.4 x 3 x 2.6 inches
Item Weight	1.12 ounces



Image: Close-up of the watch face, showing digital display and button labels.

WARRANTY AND SUPPORT

The Timex Marathon Mid-Size Digital Watch comes with a **1-year manufacturer's warranty**. For warranty claims or technical support, please refer to the official Timex website or contact their customer service. Keep your proof of purchase for warranty validation.

For additional support and detailed manuals, visit the [Timex Official Website](#).