

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [L-com](#) /
- › [L-com PR175B16BLK 16-Port 1U BNC Patch Panel User Manual](#)

L-com PR175B16BLK

L-com PR175B16BLK 16-Port 1U BNC Patch Panel User Manual

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of the L-com PR175B16BLK 16-Port 1U BNC Patch Panel. Please read this manual thoroughly before using the product to ensure proper functionality and safety.

2. PRODUCT OVERVIEW

The L-com PR175B16BLK is a 1U rack-mountable BNC patch panel designed for efficient management and routing of coaxial signals. It features 16 BNC ports, providing a centralized connection point for various BNC-terminated devices within a rack environment. This panel is ideal for applications requiring organized and flexible BNC signal distribution.



Figure 1: Front view of the L-com PR175B16BLK 16-Port 1U BNC Patch Panel. This image displays the front view of the L-com PR175B16BLK 16-Port 1U BNC Patch Panel. It features sixteen BNC connectors arranged horizontally across a black 1U rack-mountable chassis. Each port is numbered from 1 to 16 for easy identification. The panel is designed for efficient cable management and signal routing in rack environments.

3. SETUP AND INSTALLATION

Follow these steps for proper installation of the BNC patch panel:

1. **Unpacking:** Carefully remove the patch panel from its packaging. Inspect for any signs of damage during transit.
2. **Rack Mounting:** The PR175B16BLK is a 1U rack-mountable unit. Align the mounting holes on the patch panel with the corresponding holes on your standard 19-inch equipment rack. Secure the panel using

appropriate rack screws (not included) on both sides.

3. **Cable Connection:** Connect your BNC-terminated coaxial cables to the desired ports on the front of the patch panel. Ensure each BNC connector is fully inserted and twisted clockwise until it locks securely into place.
4. **Cable Management:** Utilize proper cable management techniques (e.g., cable ties, cable management panels) to organize connected cables and prevent strain on the connectors.

4. OPERATING INSTRUCTIONS

The L-com PR175B16BLK patch panel operates passively, facilitating signal routing without requiring external power. Its primary function is to provide a convenient and organized interface for BNC connections.

- **Connecting Cables:** To connect a BNC cable, align the connector with the port, push it in, and twist clockwise until it clicks into place.
- **Disconnecting Cables:** To disconnect, twist the BNC connector counter-clockwise and pull it straight out from the port.
- **Signal Routing:** Use the numbered ports to clearly identify and manage your BNC signal paths.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your patch panel.

- **Cleaning:** Periodically clean the exterior of the patch panel with a soft, dry, lint-free cloth. Avoid using abrasive cleaners or solvents.
- **Inspection:** Routinely inspect all BNC connectors for signs of wear, corrosion, or damage. Ensure all cables are securely connected.
- **Environmental Conditions:** Ensure the patch panel is operated within a stable environment, free from excessive dust, moisture, and extreme temperatures.

6. TROUBLESHOOTING

If you encounter issues with signal transmission, consider the following troubleshooting steps:

- **No Signal/Intermittent Signal:**
 - Verify that all BNC cables are securely connected to both the patch panel and the connected devices.
 - Inspect cables for damage (e.g., kinks, cuts, loose connectors).
 - Test cables individually if possible to isolate a faulty cable.
 - Ensure the source device is transmitting a signal and the receiving device is properly configured.
- **Loose Connections:** Re-seat any BNC connectors that appear loose. Ensure they are twisted clockwise until fully locked.

7. SPECIFICATIONS

Feature	Specification
Model Number	PR175B16BLK



Feature	Specification
Brand	L-com
Connector Type	BNC Patch Panel
Number of Ports	16
Rack Unit Height	1U
Manufacturer	L-COM
Date First Available	July 15, 2015



8. WARRANTY AND SUPPORT

Warranty information for the L-com PR175B16BLK patch panel is typically provided by the manufacturer at the time of purchase or can be found on the official L-com website. For technical support, product inquiries, or warranty claims, please contact L-com directly through their official support channels.


L-com Contact Information: Please refer to the official L-com website (www.l-com.com) for the most current contact details and support resources.

Related Documents - PR175B16BLK

	<p>L-COM TRG504-T4T Series M12 to RJ45 Industrial Outdoor High Flex Cable Datasheet</p> <p>Datasheet for L-COM TRG504-T4T series Category 5e M12 IP68 4-position D-coded to RJ45 industrial outdoor high flex cables. Features CMX, SF/UTP, teal CMX TPE jacket, and detailed specifications.</p>
	<p>L-com CPLR Cxx SHLD RJ45 IP68 Coupler Datasheet and Specifications</p> <p>Technical specifications, part details, dimensions, and component breakdown for the L-com CPLR Cxx SHLD RJ45 IP68 coupler, designed for shielded RJ45 connections with IP68 ingress protection.</p>
	<p>L-com HGX-PMT06 Antenna Mounting Bracket Specifications</p> <p>Detailed specifications and compatibility information for L-com antenna mounting brackets, including horizontal and vertical adjustment, weight, and compatible antenna models. Information on additional mounting kit options.</p>
	<p>L-com SRAQ-D701 Multifunction Air Quality Sensor Module User Guide</p> <p>User guide for the L-com SRAQ-D701, a MODBUS-RTU air quality sensor module detecting CO2, dust, temperature, humidity, TVOC, and formaldehyde. Includes technical specifications, communication protocols, and data calculation methods.</p>

	<p>Wireless CPE, Access Points, and Adapters: A Networking Tutorial</p> <p>Explore wireless networking fundamentals with this comprehensive tutorial covering CPEs, Access Points, and adapters. Learn about different modes of operation, 802.11 standards, and discover a range of products from L-com, PLANET, and EnGenius.</p>
	<p>Assembly Instructions for Bariloche Wardrobe</p> <p>Comprehensive assembly instructions, parts list, safety warnings, and care guide for the Bariloche Wardrobe. Includes step-by-step visual guides and warranty information.</p>

Documents - L-com – PR175B16BLK



[\[pdf\] Specifications Datasheet Dimension Guide](#)

PR175B16BLK Sheet1 dfrisiello Data Sheet Patch Panels Newark 1706386 farnell cad |||

8 7 6 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF L-COM, INC. ANY REPRODUCTION ... RACK PANELS PRODUCT DESCRIPTION 1.75 X19 W/16 BNC F-F INS BLK A SIZE FSCM NO. DWG. NO. 43321 PR175B16BLK SCALE: NONE CAD FILE: **PR175B16BLK.SLDDRW** REV. B SHEET 1 OF 1 4 3 2 1 ...

lang:i-klingon **score:25** filesize: 75.55 K page_count: 1 document date: 2011-02-24



[\[pdf\] Catalog](#)

2K15M1 235 Coaxial and Audio Video Rack Panels l com multimedia catalog page

PATCH PANELS/RACKS 2015 Master Catalog 1.0 Coaxial and Audio/Video Rack Panels 235 .5 1.3cm D- ... Panel, 32 0.5 1.3cm D-Holes N/A 3.50 8.9cm Panel, 32 0.5 1.3cm D-Holes and Cable Minder **PR175B16BLK** PR35B32BLK A 1.75 4.4cm Panel, 16 BNC Couplers, 50 Ohm Insulated A 3.50 8.9cm ...

lang:en **score:18** filesize: 525.87 K page_count: 1 document date: 2014-12-08




[pdf] Catalog

2K16M1 235 Coaxial and Audio Video Rack Panels | com multimedia catalog page

PATCH PANELS/RACKS 2016 Master Catalog 1.0 Coaxial and Audio/Video Rack Panels 235 .5 1.3cm D- ... Panel, 32 0.5 1.3cm D-Holes N/A 3.50 8.9cm Panel, 32 0.5 1.3cm D-Holes and Cable Minder **PR175B16BLK** PR35B32BLK A 1.75 4.4cm Panel, 16 BNC Couplers, 50 Ohm Insulated A 3.50 8.9cm ...

lang:en score:18 filesize: 550.08 K page_count: 1 document date: 2015-12-07




[pdf] Datasheet

1644474 farnell datasheets

A B Best Seller Coaxial and Audio/Video Rack Panels Patch Panels / Racks Choice of .5 1.3cm or .375 0.1cm D-holes Optional cable management bracket A complete selection of panel configurations for coaxial connections is available to system designers. Each panel features a numerical legen...

lang:en score:13 filesize: 742.05 K page_count: 1 document date: 2011-11-29



[pdf] Specifications Datasheet Guide

L com 800 343 1455 Wired Wireless Product Guide the numerous factors affecting operating range of radio frequency 698 2700 MHz Cellular LTE WiFi Multi Band Rubber Duck Antenna HG72703RDR NM Com HTS2700 datasheet octopart 134157353 Datasheet 5 feb 2023 — HGX PMT03 Indoor Mounting Kit Medium Plastic Tilt Swivel 15 00 13 80 12 60 CALL PMT04 Large Metal Bracket for IBS Electronics 9e4883b0493b0abbd1ec933600244e73 us rs online m d Octopart CPE Access Points Adapters 24 27 RF Filters GROM 9 Replacement Grommets SDC SDRA Backshells 0 82 75 |||

Wired Wireless Product Guide 2017 L-com.com 800-343-1455 Global Leader in Connectivity Solutions ... Panel, 32 0.5 1.3cm D-Holes N/A 3.50 8.9cm Panel, 32 0.5 1.3cm D-Holes and Cable Minder **PR175B16BLK** PR35B32BLK A 1.75 4.4cm Panel, 16 BNC Couplers, 50 Ohm Insulated A 3.50 8.9cm ...

lang:en score:12 filesize: 47.59 M page_count: 272 document date: 2017-08-18