

Vivitar VBTS20158

Vivitar Neon Mini Bluetooth Speaker User Manual

Model: VBTS20158

INTRODUCTION

Thank you for purchasing the Vivitar Neon Mini Bluetooth Speaker. This manual provides important information regarding the setup, operation, maintenance, and troubleshooting of your new speaker. Please read this manual thoroughly before using the device to ensure proper functionality and to extend the product's lifespan.




Image: Vivitar Neon Mini Bluetooth Speaker. This image displays the compact, portable design of the speaker, highlighting its pink color variant.

SETUP

1. What's in the Box

- Vivitar Neon Mini Bluetooth Speaker
- USB Charging Cable
- User Manual

2. Charging the Speaker

1. Locate the charging port on the speaker.
2. Connect the small end of the USB charging cable to the speaker's charging port.
3. Connect the larger end of the USB charging cable to a USB power adapter (not included) or a computer's USB port.
4. The LED indicator light will illuminate to show that the speaker is charging.
5. Once fully charged, the LED indicator light will change or turn off (refer to specific LED behavior in the Operating section). A full charge typically takes 2-3 hours.

Note: For optimal battery life, fully charge the speaker before first use.

3. Powering On/Off

- To power on: Press and hold the Power button for approximately 3 seconds. An audible tone or LED indicator will confirm the speaker is on.
- To power off: Press and hold the Power button for approximately 3 seconds. An audible tone or LED indicator will confirm the speaker is off.

4. Bluetooth Pairing

1. Ensure the speaker is powered on and within 1 meter (3 feet) of your Bluetooth-enabled device (e.g., smartphone, tablet).
2. The speaker will automatically enter pairing mode, indicated by a flashing LED light (typically blue).
3. On your Bluetooth device, go to the Bluetooth settings menu and enable Bluetooth.
4. Search for available devices. You should see "Vivitar Neon Speaker" or a similar name appear in the list.
5. Select "Vivitar Neon Speaker" to connect.
6. Once successfully paired, the speaker will emit an audible tone, and the LED indicator light will stop flashing and remain solid (typically blue).
7. If pairing fails, power off the speaker and your device, then repeat the steps.

Note: The speaker will attempt to reconnect to the last paired device automatically when powered on, if that device is within range and has Bluetooth enabled.

OPERATING INSTRUCTIONS

1. Playing Music

- After successful pairing, open your music application on your connected device and begin playback.
- **Play/Pause:** Press the Play/Pause button once to play or pause the current track.
- **Volume Control:** Use the volume controls on your connected Bluetooth device to adjust the speaker's volume. Some speakers may have dedicated volume buttons; refer to the speaker's physical layout.
- **Next/Previous Track:** This model typically relies on the connected device for track navigation.

2. LED Indicator Status

- **Flashing Blue:** Speaker is in pairing mode, waiting for a connection.
- **Solid Blue:** Speaker is connected to a Bluetooth device.
- **Solid Red:** Speaker is charging.

- **Red LED Off (after charging):** Speaker is fully charged.
- **Flashing Red (or other color):** Low battery warning.

MAINTENANCE

1. Cleaning

- Wipe the speaker's exterior with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, benzene, or other chemical solvents, as these may damage the surface or internal components.
- Avoid getting moisture into any openings.

2. Battery Care

- To preserve battery life, charge the speaker regularly, even if not in frequent use.
- Avoid fully discharging the battery frequently.
- Do not expose the speaker to extreme temperatures (hot or cold), as this can degrade battery performance.

3. Storage

Store the speaker in a cool, dry place away from direct sunlight and excessive dust. If storing for an extended period, ensure the battery is partially charged (around 50%) to prevent deep discharge.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is discharged.	Charge the speaker using the provided USB cable.
Cannot pair with Bluetooth device.	Bluetooth is not enabled on the device; speaker is out of range; speaker is already paired to another device.	<ul style="list-style-type: none">• Ensure Bluetooth is enabled on your device.• Move the speaker closer to your device (within 1 meter).• Turn off Bluetooth on other nearby devices that might be connected.• Power cycle both the speaker and your Bluetooth device, then try pairing again.
No sound or low volume.	Volume on speaker or device is too low; speaker is not connected; audio source issue.	<ul style="list-style-type: none">• Increase the volume on both the speaker and your connected device.• Ensure the speaker is successfully paired and connected.• Check if the audio is playing correctly on your device's internal speaker.

Problem	Possible Cause	Solution
Charging indicator not working.	Cable or power source issue; speaker fault.	<ul style="list-style-type: none">• Try a different USB cable or power adapter.• Ensure the charging cable is securely connected.• If the issue persists, contact customer support.

SPECIFICATIONS

Model Number	VBTS20158
Brand	Vivitar
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Power Source	Battery Powered (2 Lithium Ion batteries included)
Audio Output Mode	Stereo
Speaker Maximum Output Power	3 Watts
Item Weight	11.2 ounces (0.7 pounds)
Item Package Dimensions	12.953 cm L x 10.668 cm W x 7.62 cm H
Country Of Origin	China
Manufacturer	Sakar International, Inc.

WARRANTY INFORMATION

Vivitar products are designed and manufactured to the highest quality standards. This product is covered by a limited warranty against defects in materials and workmanship. The specific warranty period and terms may vary by region and product. Please refer to the warranty card included in your product packaging or visit the official Vivitar website for detailed warranty information.

Note: This warranty does not cover damage caused by misuse, neglect, accident, alteration, or unauthorized repair.

CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your Vivitar Neon Mini Bluetooth Speaker that are not addressed in this manual, please contact Vivitar Customer Support.

- **Online Support:** Visit the official Vivitar website for FAQs, product registration, and support resources.
- **Contact Information:** Refer to your product packaging or the Vivitar website for specific customer service phone numbers or email addresses for your region.

When contacting support, please have your product model number (VBTS20158) and purchase information ready.

