

## Jocca 5529

# Jocca Air Fryer User Manual

Model: 5529

## INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Jocca Air Fryer, Model 5529. Please read all instructions carefully before first use and retain this manual for future reference.

## IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance features **Protection against overheating**. If the unit overheats, it will automatically shut off.
- The appliance has a **Cool touch handle** for safe operation.

## PRODUCT OVERVIEW



Figure 1: The Jocca Air Fryer with its cooking basket extended, showing perfectly cooked fries. This image highlights the main unit and the removable basket.



Figure 2: A side view of the Jocca Air Fryer, showcasing its compact design and the control panel on the top. The handle for the cooking basket is visible.



Figure 3: The Jocca Air Fryer positioned on a kitchen counter, providing a sense of its size relative to other kitchen items. The clean, modern aesthetic is visible.

The Jocca Air Fryer is designed to cook food using rapid hot air circulation, requiring minimal oil. Key components include the main unit, removable cooking basket, temperature control dial, and timer dial.

## SETUP

---

1. Unpack the air fryer and all accessories from the box.
2. Remove any packaging materials, stickers, or labels.
3. Clean the cooking basket and pan with hot water, dish soap, and a non-abrasive sponge.
4. Wipe the inside and outside of the appliance with a damp cloth.
5. Place the air fryer on a stable, horizontal, and level surface. Do not place the appliance on non-heat-resistant surfaces.
6. Ensure there is sufficient space (at least 10 cm) around the appliance for proper air circulation.
7. Insert the cooking basket into the pan, then slide the pan back into the air fryer until it clicks into place.

## OPERATING INSTRUCTIONS

---

### General Operation

1. Plug the main power cord into a grounded wall outlet.
2. Carefully pull the pan out of the air fryer.
3. Place the ingredients into the cooking basket. For best results, add approximately half a tablespoon of oil to your ingredients.
4. Slide the pan back into the air fryer.
5. Turn the temperature control dial to the required temperature.
6. Turn the timer dial to the required cooking time. The appliance will automatically stop and alert you with a beep when the timer reaches zero.
7. Some ingredients require shaking halfway through the preparation time. To shake the ingredients, pull the pan out of the appliance by the handle and shake it. Then slide the pan back into the air fryer.
8. When you hear the timer bell, the set preparation time has elapsed. Pull the pan out of the appliance and place it on a heat-resistant surface.
9. Check if the ingredients are ready. If not, simply slide the pan back into the appliance and set the timer for a few extra minutes.
10. Empty the basket into a bowl or onto a plate.
11. The air fryer is immediately ready for preparing another batch.

### Cooking Guide (Approximate Times & Temperatures)

The following table provides general guidelines. Adjust times and temperatures based on ingredient quantity and desired crispiness.

Food Item	Temperature	Time	Notes
Chips (Fries)	180°C - 200°C	12 minutes	Shake halfway through.
Chicken	180°C - 200°C	15 minutes	Ensure internal temperature is safe.
Meat	180°C - 200°C	10-15 minutes	Varies by cut and thickness.
Cake	200°C	20-25 minutes	Use a suitable baking pan.

Food Item	Temperature	Time	Notes
Bread	180°C	5-8 minutes	For toasting or reheating.

## MAINTENANCE AND CLEANING

Clean the appliance after every use. The pan and the basket have a non-stick coating. Do not use metal kitchen utensils or abrasive cleaning materials to clean them, as this may damage the non-stick coating.

1. Remove the main plug from the wall socket and let the appliance cool down.
2. Wipe the outside of the appliance with a damp cloth.
3. Clean the pan and basket with hot water, some dish soap, and a non-abrasive sponge.
4. For stubborn dirt, fill the pan with hot water and some dish soap and let it soak for approximately 10 minutes.
5. Clean the inside of the appliance with hot water and a non-abrasive sponge.
6. Clean the heating element with a cleaning brush to remove any food residues.
7. The pan and basket are **not dishwasher safe**.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
The air fryer does not work.	The appliance is not plugged in.	Plug the main plug into a grounded wall socket.
The timer has not been set.	Turn the timer dial to the required preparation time.	Set the timer.
Ingredients are not cooked evenly.	Some ingredients need to be shaken halfway through the preparation time.	Shake the basket during cooking.
White smoke comes out of the appliance.	Fat residues from previous use.	Clean the pan and basket thoroughly after each use.
The appliance overheated.	The appliance has an overheating protection feature.	Unplug the appliance and let it cool down for 30 minutes before restarting.

## SPECIFICATIONS

**Brand:** Jocca

**Model Name:** 5529

**ASIN:** B01FMD0CMU

**Capacity:** 2.5 Liters

**Color:** Silver

**Material:** Plastic

**Output Wattage:** 1500 Watts

**Voltage:** 230 Volts

**Control Method:** Touch

**Item Weight:** 4.11 Kilograms (9.04 pounds)

**Product Dimensions:** 14.17 x 12.99 x 11.61 inches

**Special Feature:** Automatic Shut-Off

**Is Dishwasher Safe:** No

**Recommended Uses:** Bake, Dehydrate, Roast

**Manufacturer:** QUALIMAX INTERNATIONAL LTD.

**Date First Available:** August 25, 2016

© 2024 Jocca. All rights reserved.