

[Manuals.plus](#) /

› [Timex](#) /

› [Marathon by Timex Full-Size Watch Instruction Manual](#)

## Timex B01I9PWJCE

# Marathon by Timex Full-Size Watch Instruction Manual

Model: B01I9PWJCE

## INTRODUCTION

---

Thank you for choosing the Marathon by Timex Full-Size Watch. This digital sports watch is designed for durability and functionality, featuring a daily alarm, two time zone settings, a 24-hour stopwatch, and the Indiglo night-light. It is also water resistant to 50 meters, making it suitable for various activities. This manual will guide you through the setup, operation, and maintenance of your watch.



Figure 1: Front view of the Marathon by Timex Full-Size Watch, showing the digital display and button layout.

## SETUP

### Setting Time and Date

To ensure accurate timekeeping, follow these steps to set the current time and date:

1. In Time mode, press and hold the **SET** button until the seconds begin to flash.
2. Press the **MODE** button to cycle through the settings: seconds, hour, minute, year, month, day.
3. Use the **START/STOP** button to adjust the flashing value.
4. Once all settings are correct, press the **SET** button again to exit the setting mode.

### Setting the Daily Alarm

Your watch features a daily alarm. To set it:

1. From Time mode, press the **MODE** button repeatedly until you reach the Alarm mode (indicated by an alarm icon).
2. Press and hold the **SET** button until the alarm hour flashes.
3. Use the **START/STOP** button to adjust the hour. Press **MODE** to move to minutes, then adjust with **START/STOP**.
4. Press **SET** to confirm and exit.
5. To activate/deactivate the alarm, press the **START/STOP** button in Alarm mode.

## Setting Dual Time Zone

The watch allows you to set a second time zone for travel or convenience:

1. From Time mode, press the **MODE** button until you reach the T2 (Time Zone 2) display.
2. Press and hold the **SET** button until the hour flashes.
3. Use the **START/STOP** button to adjust the hour. Press **MODE** to move to minutes, then adjust with **START/STOP**.
4. Press **SET** to confirm and exit.



Figure 2: Side view of the watch, highlighting the function buttons used for settings and mode changes.

## OPERATING

### Using the Indiglo Night-Light

The Indiglo night-light illuminates the watch display for easy viewing in low-light conditions.

- Press the **LIGHT** button (typically located on the top left side of the watch) to activate the Indiglo night-light.
- The light will remain on for a few seconds.

### Using the 24-Hour Stopwatch

The stopwatch function allows you to measure elapsed time up to 24 hours.

1. From Time mode, press the **MODE** button repeatedly until you reach the Stopwatch mode (indicated by 'STP' or a stopwatch icon).
2. Press the **START/STOP** button to start the stopwatch.
3. Press **START/STOP** again to pause the stopwatch.

4. To reset the stopwatch to zero, press the **RESET** button (often the same as **SET** or a dedicated button) while the stopwatch is paused.

## Water Resistance

This watch is water resistant to 50 meters (164 feet). This means it is suitable for recreational swimming, showering, and fishing. It is not suitable for diving or snorkeling. Do not operate buttons underwater.



Figure 3: The Marathon by Timex watch displayed on a wrist, illustrating its practical appearance.

## MAINTENANCE

---

### Cleaning Your Watch

To maintain the appearance and functionality of your watch:

- Wipe the watch case and strap regularly with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the watch's finish or seals.
- For watches with a resin strap, rinse with fresh water after exposure to saltwater or chlorine.

### Battery Information

The watch is powered by a long-lasting battery. When the display becomes dim or functions become erratic, it may be time for a battery replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance seal is properly maintained.

## TROUBLESHOOTING GUIDE

---

If you encounter issues with your watch, refer to the following common problems and solutions:

- **Display is blank or flickering:** This often indicates a low battery. Replace the battery as described in the Maintenance section.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though this model typically does not have one). If the issue persists, a battery replacement might be needed, or a soft reset by removing and reinserting the battery (recommended to be done by a professional).
- **Time is inaccurate:** Re-set the time and date following the instructions in the Setup section. If the watch continues to lose or gain time significantly, it may require servicing.
- **Water inside the watch:** If moisture appears inside the watch, stop using it immediately and have it inspected by a professional. This indicates a compromised water resistance seal.

## SPECIFICATIONS

---

Feature	Detail
Brand Name	Timex
Model Number (ASIN)	B01I9PWJCE
Item Type Name	Sport Watch
Department	Mens
Manufacturer	Timex Corporation
Water Resistance	50 Meters (164 Feet)
Key Features	Daily Alarm, Two Time Zone Settings, 24-Hour Stopwatch, Indiglo Night-Light

## WARRANTY AND CUSTOMER SUPPORT

---

Your Marathon by Timex watch is covered by a limited warranty. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official Timex website. Keep your proof of purchase for warranty claims.

For further assistance, technical support, or service inquiries, please contact Timex customer service directly. Contact information can typically be found on the Timex official website or within the product packaging.

Official Timex Website: [www.timex.com](http://www.timex.com)